

# *User Manual*

*Network Video Recorder*

Please read this manual carefully before operating the unit and keep it for further reference

# Notes

- Please read this user manual carefully to ensure that you can use the device correctly and safely.
- There may be several technically incorrect places or printing errors in this manual. The updates will be added into the new version of this manual. The contents of this manual are subject to change without notice.
- This device should be operated only from the type of power source indicated on the marking label. The voltage of the power must be verified before using the same. Kindly remove the cables from the power source if the device is not to be used for a long period of time.
- Do not install this device near any heat sources such as radiators, heat registers, stoves or other devices that produce heat.
- Do not install this device near water. Clean only with a dry cloth.
- Do not block any ventilation openings and ensure proper ventilation around the machine.
- Do not power off the device at normal recording condition.
- This machine is for indoor use only. Do not expose the machine in rain or moist environment. In case any solid or liquid gets inside the machine's case, please turn off the device immediately and get it checked by a qualified technician.
- Do not try to repair the device by yourself without technical aid or approval.
- In this manual, the trademarks, product names, service names, company names, and products that are not owned by our company are the properties of their respective owners.
- It is recommended to back up and clear the personal data stored in the device before the device is returned to us for repair or replacement except those data that are essential for purposes of repair or replacement. The device will be restored to the default factory settings, and all personal data will be cleared after repair or replacement. Our company ensures that the customer's data is not made available to third parties if the device is exchanged.
- This manual is suitable for many models. All examples and pictures used in the manual are from one of the models for reference.
- The local language versions of this manual will be provided to users in the corresponding regions and countries.

# Disclaimer

- With regard to the product with internet access, the use of product shall be wholly at your own risks. Our company shall be irresponsible for abnormal operation, privacy leakage or other damages resulting from cyber attack, hacker attack, virus inspection, or other internet security risks; however, our company will provide timely technical support if necessary.
- Surveillance laws vary from country to country. Check all laws in your local region before using this product for surveillance purposes. We shall not take responsibility for any consequences resulting from illegal operations. In the event of any conflicts between this manual and the applicable law, the latter prevails.
- The storage of the personal data depends on the capacity of the storage devices the users

use, and all data stored in the device shall be handled by themselves. Our company shall not be responsible for the data loss.

## Cybersecurity Recommendations

- Use a strong password. At least 8 characters or a combination of characters, numbers, and upper and lower case letters should be used in your password.
- Set the password expiration time and regularly change the passwords of your devices to ensure that only authorized users can access the system. (recommended time is 90 days).
- The system will automatically check the latest firmware version once a day. Once the latest version is checked, you'd better update it to ensure the system is current with the latest security patches and fixes.
- It is recommended to change the service default ports (like HTTP-80, HTTPS-443, etc.) to reduce the risk of outsiders being able to access.
- It is recommended to set the firewall of your router. But note that some important ports cannot be closed (like HTTP port, HTTPS port, Data Port).
- It is not recommended to expose the device to the public network. When it is necessary to be exposed to the public network, please set the external hardware firewall and the corresponding firewall policy.
- It is not recommended to use the v1 and v2 functions of SNMP.
- In order to enhance the security of WEB client access, please create a TLS certificate to enable HTTPS.
- Use black and white list to filter the IP address. This will prevent everyone, except those specified IP addresses from accessing the system.
- If you add multiple users, please limit functions of guest accounts.
- If you enable UPnP, it will automatically try to forward ports in your router or modem. It is very convenient for users, but this will increase the risk of data leakage when the system automatically forwards ports. Disabling UPnP is recommended when the function is not used in real applications.
- Check the log. If you want to know whether your device has been accessed by unauthorized users or not, you can check the log. The system log will show you which IP addresses were used to log in your system and what was accessed.

# Regulatory Information

## FCC Information

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### 1. FCC compliance

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### 2. FCC conditions:

- This device complies with part 15 of the FCC Rules. Operation of this product is subject the following two conditions:
- This device may not cause harmful interface.
- This device must accept any interference received, including interference that may cause undesired operation.

## EU Compliance Statement



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the Directive 2014/30/EU (EMCD), Directive 2011/65/EU (RoHS).

Note: The products with the input voltage of within 50 to 1000 VAC or 75 to 1500 VDC comply with Directive 2014/35/EU (LVD), and the rest products comply with Regulation (EU)2023/988(GPSR). Please check the specific power supply information for reference.



Directive 2012/19/EU (WEEE Directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: [www.recyclethis.info](http://www.recyclethis.info).

According to the Waste Electrical and Electronic Equipment Regulations 2013: Products marked with this symbol cannot be disposed of as unsorted municipal waste in the United Kingdom. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: [www.recyclethis.info](http://www.recyclethis.info).

Packaging and Packaging Waste Regulation (EU) 2025/40: This Regulation establishes requirements for the entire life-cycle of packaging as regards environmental sustainability and labeling, to allow its placing on the market. It also establishes requirements for extended producer responsibility, packaging waste prevention, such as the reduction of unnecessary packaging and the re-use or refill of packaging, as well as the collection and treatment, including recycling, of packaging waste.

REACH (Regulation (EC) No 1907/2006): REACH concerns the Registration, Evaluation, Authorization and Restriction of Chemicals, which aims to ensure a high level of protection of human health and the environment through better and earlier identification of the intrinsic properties of chemical substances. The product in this manual refers to conforms to the rules and regulations of REACH. For more information of REACH, please refer to DG GROWTH or ECHA websites.

# Table of Contents

<b>1</b>	<b>Introduction .....</b>	<b>1</b>
1.1	Summary .....	1
1.2	Features .....	1
1.3	Front Panel Descriptions .....	5
1.4	Rear Panel Descriptions .....	5
1.5	Connections.....	9
<b>2</b>	<b>Basic Operation Guide.....</b>	<b>12</b>
2.1	Startup & Shutdown .....	12
2.1.1	Startup .....	12
2.1.2	Shutdown.....	12
2.2	Remote Controller.....	12
2.3	Mouse Control.....	14
2.4	Text-input Instruction .....	15
2.5	Common Button Operation .....	15
<b>3</b>	<b>Wizard &amp; Main Interface .....</b>	<b>17</b>
3.1	Startup Wizard.....	17
3.2	Main Interface .....	25
3.2.1	Main Interface Introduction.....	25
3.2.2	Setup Panel.....	27
3.2.3	Main Functions.....	28
<b>4</b>	<b>Camera Management.....</b>	<b>30</b>
4.1	Add/Edit Camera.....	30
4.1.1	Add Camera.....	30
4.1.2	Edit Camera.....	35
4.2	Add/Edit Camera Group.....	36
4.2.1	Add Camera Group.....	36
4.2.2	Edit Camera Group.....	37
4.2.3	IP Planning .....	37
4.3	IP Speaker Management.....	38
<b>5</b>	<b>Live View Introduction .....</b>	<b>40</b>
5.1	Live View Interface Introduction .....	40
5.2	View Mode.....	41
5.2.1	Preview by Display Mode .....	41
5.2.2	Quick Sequence View.....	44
5.2.3	Camera Group View in Sequence.....	44
5.2.4	Scheme View in Sequence.....	45
5.3	POS Settings .....	47
5.4	Preview Image Configuration .....	50
5.4.1	OSD Settings.....	50
5.4.2	Image Settings.....	51
5.4.3	Mask Settings.....	52
5.4.4	Fisheye Settings.....	53
5.4.5	Smart Supplement Light.....	54

5.4.6 Splicing .....	55
5.4.7 Image Adjustment .....	56
<b>6 PTZ.....</b>	<b>60</b>
6.1 PTZ Control Interface Introduction.....	60
6.2 Preset Settings.....	65
6.3 Cruise Settings .....	65
6.4 Cruise Group Settings .....	66
6.5 Trace Settings.....	67
6.6 Task Settings .....	68
6.7 Smart Tracking Settings .....	69
6.8 Protocol Settings .....	70
6.9 Home Position Settings .....	71
<b>7 Record &amp; Disk Management.....</b>	<b>72</b>
7.1 Record Configuration.....	72
7.1.1 Mode Configuration .....	72
7.1.2 Schedule Settings .....	74
7.1.3 Advanced Configuration.....	77
7.2 Encode Parameters Settings .....	77
7.3 Record Mode.....	78
7.3.1 Manual Recording.....	78
7.3.2 Timing Recording.....	78
7.3.3 Motion-based Recording .....	78
7.3.4 Sensor Based Recording.....	78
7.3.5 AI Event Recording.....	79
7.4 Disk.....	79
7.4.1 Disk Management .....	79
7.4.2 Storage Mode Configuration .....	83
7.4.3 View Disk Information .....	84
<b>8 Playback &amp; Backup.....</b>	<b>86</b>
8.1 Instant Playback .....	86
8.2 Playback Interface Introduction .....	86
8.3 Rules Playback .....	92
8.4 Record Search, Playback & Backup.....	94
8.4.1 Search, Playback & Backup by Time-sliced Image.....	94
8.4.2 Search, Playback & Backup by Time .....	96
8.4.3 Search, Playback & Backup by Event .....	97
8.4.4 Search & Playback by Tag.....	98
8.4.5 Image Management .....	98
8.4.6 View Backup Status.....	99
<b>9 AI Event Management.....</b>	<b>100</b>
9.1 Face Recognition.....	100
9.1.1 Face Detection Settings .....	100
9.1.2 Face Database Management .....	103
9.1.3 Face Recognition Settings .....	105
9.2 License Plate Recognition .....	108
9.2.1 License Plate Detection Settings .....	108

9.2.2 Plate Database Management.....	109
9.2.3 License Plate Recognition Settings .....	110
9.3 Perimeter Detection.....	111
9.3.1 Line Crossing Detection.....	111
9.3.2 Region Intrusion Detection.....	113
9.3.3 Region Entrance Detection.....	114
9.3.4 Region Exiting Detection .....	115
9.4 Abandoned/Missing Object Detection.....	115
9.5 Crowd Density Detection.....	116
9.6 Target Counting by Line.....	116
9.7 Target Counting by Area .....	118
9.8 Exception Detection .....	119
9.9 Fire Detection.....	120
9.10 Temperature Detection .....	121
9.11 Audio Exception.....	123
9.12 Loitering Detection .....	124
9.13 Illegal Parking Detection.....	125
9.14 People Counting.....	126
9.15 Heat Map.....	128
9.16 People Gathering Detection.....	129
9.17 Video Metadata .....	130
<b>10 Intelligent Analytics .....</b>	<b>132</b>
10.1 Target Detection View .....	132
10.1.1 People/Vehicle Detection View .....	132
10.1.2 Face Detection/Match View .....	133
10.1.3 License Plate Detection/Recognition View .....	136
10.1.4 Object Attribute View.....	137
10.2 Smart Search .....	138
10.2.1 Face Search .....	138
10.2.2 Track.....	142
10.2.3 Face Search by Snapshot.....	143
10.2.4 People Search .....	144
10.2.5 Human Attribute Search .....	145
10.2.6 Vehicle Search .....	145
10.2.7 Event Search.....	146
10.2.8 PicSearch.....	147
10.3 View Statistical Information.....	150
10.4 Enabling AI Mode .....	151
<b>11 General Event Management.....</b>	<b>152</b>
11.1 Sensor Alarm.....	152
11.2 Motion Alarm .....	153
11.2.1 Motion Configuration.....	153
11.2.2 Motion Alarm Handling Configuration .....	154
11.3 Combination Alarm.....	155
11.4 Exception Alarm.....	156
11.4.1 Camera Offline Settings .....	156
11.4.2 Exception Alarm Settings .....	156
11.4.3 Relay.....	156

11.5 Alarm Event Notification .....	158
11.5.1 Alarm-out .....	158
11.5.2 E-mail .....	158
11.5.3 Display .....	158
11.5.4 Buzzer.....	159
11.5.5 Push .....	159
11.5.6 Audio .....	159
11.5.7 Light .....	162
11.5.8 Alarm Server.....	163
11.6 Manual Alarm.....	163
11.7 View Alarm Status.....	164
11.8 System Disarming .....	165
<b>12 Application.....</b>	<b>166</b>
12.1 Face Attendance .....	166
12.2 Face Check-In .....	167
12.3 Parking Lot Settings .....	168
12.3.1 Basic Settings .....	168
12.3.2 Parking Space Settings .....	169
12.3.3 Entrance/Exit Management .....	169
12.3.4 Parking Lot Management .....	170
12.3.5 Search Vehicle Entry/Exiting Records.....	171
12.4 Access Control Management.....	172
12.4.1 Access Control Settings.....	173
12.4.2 Open the Door Manually .....	174
12.5 People Flow.....	174
<b>13 Account &amp; Permission Management .....</b>	<b>176</b>
13.1 Account Management.....	176
13.1.1 Add User.....	176
13.1.2 Edit User.....	177
13.2 User Login & Logout .....	179
13.3 Permission Management .....	179
13.3.1 Add Permission Group .....	179
13.3.2 Edit Permission Group .....	180
13.4 Black and White List.....	180
13.5 Preview on Logout .....	181
13.6 Network Security .....	181
13.7 Password Security .....	182
13.8 Password Retrieval Settings .....	182
13.9 Double Verification .....	182
13.10 View Online User.....	183
<b>14 Device Management.....</b>	<b>184</b>
14.1 Network Configuration .....	184
14.1.1 TCP/IP Configuration.....	184
14.1.2 Port Configuration .....	186
14.1.3 PPPoE Configuration .....	190
14.1.4 DDNS Configuration.....	190
14.1.5 E-mail Configuration.....	192

14.1.6 UPnP Configuration .....	194
14.1.7 802.1X.....	194
14.1.8 NAT Configuration.....	195
14.1.9 FTP Configuration.....	196
14.1.10 SNMP.....	197
14.1.11 Cloud Upgrade.....	198
14.1.12 Platform Access.....	198
14.1.13 UPnP Report Access.....	199
14.1.14 ONVIF.....	200
14.1.15 HTTP POST .....	200
14.1.16 Network Status .....	201
14.2 Basic Configuration.....	202
14.2.1 Common Configuration.....	202
14.2.2 Date and Time Configuration .....	203
14.2.3 Recorder OSD Settings.....	203
14.2.4 PoE Power Management .....	204
14.2.5 RS485 Settings .....	204
14.3 Factory Default.....	205
14.4 Device Software Upgrade .....	206
14.5 Backup and Restore.....	206
14.6 Restart Automatically .....	207
14.7 View Log .....	207
14.8 View System Information.....	208
14.9 Diagnostic Data.....	208
<b>15 Remote Surveillance.....</b>	<b>210</b>
15.1 Mobile Client Surveillance.....	210
15.2 Web LAN Access .....	210
15.3 Web WAN Access.....	211
15.4 Web Remote Control .....	213
15.4.1 Remote Preview .....	214
15.4.2 Remote Playback.....	218
15.4.3 Remote Search and Backup.....	219
15.4.4 Intelligent Analysis.....	219
15.4.5 Application .....	219
15.4.6 Remote Configuration .....	220
<b>Appendix A FAQ .....</b>	<b>221</b>
<b>Appendix B Calculate Recording Capacity .....</b>	<b>228</b>
<b>Appendix C Compatible Device List .....</b>	<b>230</b>
<b>Appendix D Communication Port List.....</b>	<b>231</b>

# 1 Introduction

## 1.1 Summary

Based on the advanced SOC technology and embedded system in the field, this series of the NVR adopts the new designed human interface and supports the smart management of the IP camera and the record search of slice. This series of the NVR which are powerful and easy to use are provided with excellent image quality and stable system. They are centralized monitoring management products with high performance and high quality specially designed for network video monitoring field.

This series of the NVR can be widely used to security system of banks at home and abroad, schools, intelligent mansions, traffic, environmental protection, supermarkets, petrol service stations, residential quarters and factories and so on.

## 1.2 Features

### Basic Functions

- Supports network device access including our company's and third-party IP cameras
- Some NVRs support the H.265S/H.265+/ H.265 and H.264 IP cameras
- Supports standard ONVIF protocol
- Supports dual stream recording for each camera
- Supports the addition of IP cameras both automatically and manually
- Supports collective or individual configuration of the cameras' OSD, video parameters, mask, motion and so on
- Supports multiple smart detection access and linkage for IPC's, such as scene change, video color cast detection, video blur detection, intrusion detection (region entrance/exiting detection), target counting, abandoned object detection, missing object detection, crowd density detection, face detection, license plate detection, smart tracking, fire detection, temperature detection, video metadata, etc.
- Supports playback and backup
- Supports multiple user permission groups, including Administrator, Advanced and common, which are the default permission groups of the system
- Supports multiple web client logins by using one username at the same time and the ability to enable or disable user permissions
- Supports multiple web client logins at the same time
- Supports binding NVR to the account of the mobile APP
- Supports parking lot management

### Live View

- Supports 4K×2K/1920×1080/1280×1024 HDMI and 1920×1080/1280×1024 VGA high definition synchronous display
- Supports multi-screen modes such as 1/4/6/8/9/13/16/25/36 (varies by model)
- Some models support face capture view, face match view, license plate recognition view, people/motor vehicle /non-motor vehicle view

- Supports auto adjustment of the camera's image display proportion
- Supports enabling or disabling audio monitoring of a camera
- Supports manual snapshot of a camera live view
- Supports camera sequence adjustment
- Supports adding and saving display modes, and saved modes can be recalled directly
- Supports quick tool bar operation from the preview window
- Supports camera group view and scheme view in sequence, quick sequence view and dwell time setting
- Supports motion detection and video masking
- Supports multiple popular PTZ control protocols and setup of preset and cruise
- Supports direct mouse control of the IP dome including rotating, zoom, focusing and so on
- Supports the zoom of a single camera image by sliding the scroll wheel of the mouse
- Supports the zoom of any area of a camera image up to a maximum of 16 times of the current size
- Supports image and lens adjustment (only available with some cameras)
- Supports quick camera addition in the camera window of the live view interface
- The live camera sequence of the web client will stay consistent with the NVR after adjusting the live camera sequence of the NVR, but the live camera sequence of the NVR will not be changed if the web client is changed

#### **Disk Management**

- The NVRs with the 3U case can add a maximum of 16 SATA HDDs; a maximum of 8 SATA HDDs with the 2U case, a maximum of 4 SATA HDDs with the 1.5U case, a maximum of 2 SATA HDDs with the 1U case and a maximum of 1 SATA HDD with the small 1U case
- Each SATA interface (varies by unit) on the NVR supports HDDs with a max storage capacity of 10TB. Some models may support a max storage capacity of 12TB per HDD
- Supports hot swap
- Supports disk group configuration and management and each camera can be added into different disk groups with different storage capacity
- Supports disk information and viewing of disk operating status
- Supports formatting disks in batches

#### **Record Configuration**

- Supports main stream and sub stream recording, as well as collective or individual configuration of the recording stream
- Supports custom and auto recording modes
- Supports schedule recording, sensor alarm recording and motion detection recording, etc
- Supports schedule recording and event recording setting with different recording streams
- Supports recording schedule setting and recycled recording
- Supports pre-recording and delay recording configuration of an event

#### **Record Playback**

- Supports time scale operation in quick playback and the playback date and time can be set randomly by scrolling the mouse; the time interval of the time scale can be zoomed
- Supports record searching by time slice/time/event/tag

- Supports smart playback by drawing grid, line or quadrilateral and vehicle smart playback (some models also support smart playback by face)
- Supports time view and camera view in searching by time slice mode
- Supports time slice searching by month, by day, by hour and by minute and time slice to be displayed with camera thumbnail
- Supports a maximum of 4/8/16 cameras to be searched at a time (varies by unit channel size)
- Supports event search by manual/motion/sensor/intelligent events
- Supports tag searching by the manual added tags
- Supports instant playback of the selected camera in the live view interface
- Supports a maximum of 16 synchronous playback cameras
- Supports acceleration (to a maximum 32 times the normal speed), deceleration (to a minimum 1/32 times the normal speed) and 30s' addition or reduction to current playing time

#### **Record Backup**

- Supports backup of a recording through USB (U disk, mobile HDD)
- Supports backup of a recording by time/event/image search
- Supports record cutting for backing up when playing back
- Supports multiple backup tasks in background and backup status viewing

#### **Event Management**

- Supports alarm schedule setting
- Supports enabling or disabling of the motion detection, external sensor alarm input, combination alarm, intelligent alarm and exception alarms including IP address conflict alarm, disk IO error alarm, disk full alarm, no disk alarm, illegal access alarm, network disconnection alarm, camera offline alarm and so on, alarm trigger configuration supportable
- Supports camera offline alarm trigger configuration of PTZ, snap, pop-up video, etc.
- Supports event notification modes of alarm-out, pop-up video, pop-up message box, buzzer, e-mail and so on
- Captured images can be attached to an e-mail when an alarm is triggered
- Supports alarm status view of alarm-in, alarm-out, motion detection and exception alarm
- Supports triggering and clearing an alarm manually
- Supports auto-reboot of the system when an exception happens
- Supports alarm linkage based on face detection, vehicle detection and license plate recognition
- Some models support face match alarm

#### **Face Recognition (available for some models)**

- Supports adding 5000 face pictures to the face database (some models support adding 10,000 face pictures to the face database)
- Supports face capture and face match
- Supports image search by image, track playback and database management
- Supports face information statistics
- Supports face match alarm

#### **LPR Function**

- Supports registration of up to 50,000 license plates (some models only support registration of 1,000 license plates)
- Supports license plate detection, search and matching (available for some models)
- Supports vehicle information statistics
- Supports license plate match alarm (available for some models)

#### **Application**

- Supports parking lot management (available for some models)
- Supports access control management
- Supports face attendance and face check in (available for some models)

#### **Network Functions**

- Supports TCP/IP and PPPoE, DHCP, DNS, DDNS, UPnP, NTP, SMTP protocol and so on
- Supports allow and block list function and the allow and block IP address/IP segment address can be set
- Supports multiple browsers including IE11, Firefox, Opera, Chrome and Safari on Macs
- Supports remote configuration, import and export of the NVR parameters and other system maintenance operations including remote upgrading and system restart
- Supports remote camera configuration through the NVR including video parameters, image quality and so on
- Supports remote search, playback and backup through the NVR
- Supports triggering and clearing manual alarms remotely
- Motorized zoom cameras can be adjusted through the web client
- Supports NVMS or other platform management software to access the NVR and manage it
- Supports NAT function and QR Code scanning by mobile phones and tablets
- Supports mobile surveillance by phones or tablets with iOS or Android OS
- If one camera recording is enabled or disabled manually through the web client, it will be simultaneously enabled or disabled on the NVR
- Supports direct jumping from NVR web client to IPC web client
- The installation mode and display mode of the fisheye camera can be set via Web client

#### **Other Functions**

- The NVR can be controlled and operated by the buttons on the front panel (on applicable models), the remote controller and the mouse
- Setup interfaces can be conveniently switched by clicking the main menus at the top
- Supports NVR information viewing including basic, camera status, alarm status, record status, network status, disk and backup status
- Supports factory restore, import and export of the system configuration, log view and export and local upgrading by USB mobile device
- Supports auto recognition of the displayer's resolution
- You can click the right mouse button at any interface to go back to the upper interface
- You can click the mouse wheel at any interface to go to the live view interface
- The display language and video format of the NVR will not be changed and the system logs will be preserved if you restore to the default parameters





## 1.3 Front Panel Descriptions

The following descriptions are for reference only.

Type I:

Name	Descriptions
REC	When recording, the light is blue
Net	When access to network, the light is blue
Power	Power indicator. When connected, the light is blue.
Fn	Currently no function


Type II:

Name	Descriptions
Power	Power indicator. When connected, the light is blue.
HDD	When reading/writing HDD, the light is blue.
Net	When access to network, the light is blue.
Backup	When backing up files and data, the light is blue.
Play	When playing video, the light is blue.
REC	When recording, the light is blue
AUDIO +/-	1. Adjust audio 2. Increase the value in setup
P.T.Z / -	1. Enter PTZ mode 2. Decrease the value in setup
MENU	Enter Menu in live
INFO	Check the information of the device
BACKUP	Enter backup mode in live
SEARCH	Enter search mode in live
Exit	Exit the current interface
	Manually record
	Play/Pause
	Speed down
	Speed up
1-9	Input digital number and select camera
0/--	Input number 0, the number above 10
Direction Key	Change direction
Multi-Screen Switch	Change the screen mode
Enter	Confirm selection
USB	To connect external USB device like USB mouse or USB flash


## 1.4 Rear Panel Descriptions

Here we only take a part of real panels for example to introduce their interfaces and


connections. The interfaces and locations of the interfaces are only for references. Please take the real object as the standard.



No.	Name	Descriptions
1	ALARM OUT	Relay output; connect to external alarm
2	GND	Grounding
3	AUDIO IN	Audio input; connect to audio input device, like microphone, pickup, etc.
4	DC12V	DC12V power input
5	LAN	Network port
6	VGA	Connect to monitor
7	ALARM IN	Alarm inputs for connecting sensors
8	HDMI	Connect to high-definition display device
9	USB	Connect USB storage device or USB mouse
10	AUDIO OUT	Audio output; connect to sound box
11	RS485	Connect to keyboard. A is TX+; B is TX-




No.	Name	Descriptions
1	VGA	Connect to monitor
2	e-SATA	Connect to HDD with e-SATA interface
3	RS485 Y/Z interface	RS485 interface. Y is TX+, Z is TX- (This interface of some models is unavailable.)
4	RS485 A/B interface	Connect to a keyboard. A is TX+; B is TX-
5	AUDIO OUT	Audio output; connect to sound box
6	LAN	Network port
7	HDMI	Connect to high-definition display device
8	USB	Connect USB storage device or USB mouse
9	GND	Grounding
10	ALARM OUT	Relay output; connect to external alarm
11	ALARM IN	Alarm inputs for connecting sensors
12	AUDIO IN	Audio input; connect to audio input device, like microphone, pickup, etc
13	Power Switch	Press the switch to turn on/off the NVR
14	Power Supply	Power supply interface




No.	Name	Descriptions
1	VGA	Connect to monitor
2	RS485 Y/Z interface	RS485 interface. Y is TX+, Z is TX- (This interface of some models is unavailable.)
3	ALARM OUT	Relay output; connect to external alarm
4	GND	Grounding
5	AUDIO OUT	Audio output
6	e-SATA1/ e-SATA2	Connect to HDD with e-SATA interface
7	LAN1/LAN2	Network port
8	HDMI1	Connect to 4K×2K high-definition display device
9	USB3.0/USB	USB3.0 and USB 2.0 interface, connect USB storage device or USB mouse

No.	Name	Descriptions
10	HDMI2	Connect to 1920×1080 high-definition display device. Connect to monitor as an AUX output channel by channel. Only video display, no menu show
11	RS485 A/B interface	Connect to a keyboard. A is TX+; B is TX-
12	ALARM IN	Alarm inputs for connecting sensors
13	AUDIO IN	Audio input
14	Power Switch	Press the switch to turn on/off the NVR
15	Power Supply	Power supply interface



No.	Name	Descriptions
1	Power Supply	DC48V power supply interface
2	PoE port	8 PoE network ports; connect to 8 PoE IP cameras
3	LAN	Network port
4	VGA	Connect to monitor
5	HDMI	Connect to 1920×1080 high-definition display device
6	USB3.0	USB3.0 interface, connect USB storage device or USB mouse
7	AUDIO IN	Audio input; connect to audio input device, like microphone, pickup, etc.
8	AUDIO OUT	Audio output; connect to sound box
9	Power Supply	DC12V power supply interface



No.	Name	Descriptions
1	e-SATA	Connect to HDD with e-SATA interface
2	LAN1/LAN2	Network port
3	HDMI2	Connect to 1920×1080 high-definition display device. Connect to monitor as an AUX output channel by channel. Only video display, no menu show
4	USB	USB interface, connect USB storage device or USB mouse
5	HDMI1	Connect to 4K×2K high-definition display device
6	VGA	Connect to monitor
7	RS485 Y/Z interface	RS485 interface. Y is TX+, Z is TX- (This interface of some models is unavailable.)
8	RS485 A/B interface	Connect to keyboard. A is TX+; B is TX-
9	ALARM OUT	Relay output; connect to external alarm
10	GND	Grounding
11	ALARM IN	Alarm inputs for connecting sensors
12	AUDIO IN	Audio input; connect to audio input device, like microphone, pickup, etc.
13	AUDIO OUT	Audio output; connect to sound box
14	Power Switch	Press the switch to turn on/off the NVR
15	Power Supply	Power supply interface

## 1.5 Connections

### ● Video Connections

Video Output: Supports VGA/HDMI video output. You can connect to a monitor through these video output interfaces simultaneously or independently.


### ● Audio Connections

Audio Input: Connect to microphone, pickup, etc.

Audio Output: Connect to headphone, powered speaker (ex, ASPC20), amplifier, or other audio output devices.

### ● Alarm Connections

Some models may not support this function. Take 16 CH alarm inputs and 1 CH alarm output for example.




Alarm Input:

Alarm IN 1~16 are 16 CH alarm input interfaces. There are no type requirements for sensors. NO type and NC type are both available.

The way to connect sensor and the device is as shown below:



The alarm input is an open/closed relay. If the input is not an open/closed relay, please refer to the following connection diagram:




Alarm Output:

The way to connect alarm output device:


Pull out the green terminal blocks and loosen the screws in the alarm-out port. Then insert the

signal wires of the alarm output devices into the port of NO and COM separately. Finally, tighten the screws. Provided that the external alarm output devices need power supply, you can connect the power supply as per the following figures.



### ● RS485 Connection

There are two types of RS485 interfaces:



(Type 1)



(Type 2)

Type 1: P/Z interfaces are used to connect the third-party device which supports RS485 protocol. K/B interfaces are used to connect keyboard.

Type 2: The RS485 interfaces are used to connect keyboard. A is TX+; B is TX-.

## 2 Basic Operation Guide

### 2.1 Startup & Shutdown

Please make sure all the connections are done properly before you power on the unit. Proper startup and shutdown are crucial to extending the life of your device.

#### 2.1.1 Startup

- ① Connect the output display device to the VGA/HDMI interface of the NVR.
- ② Connect the mouse and power. When powered on, the device will boot and the power LED would turn blue.
- ③ After you read the privacy statement, a WIZARD window will pop up (you should select the display language the first time you use the NVR). Refer to [Startup Wizard](#) for details.

#### 2.1.2 Shutdown

You can power off the device by using remote controller or mouse.

##### By remote controller:

- ① Press Power button. This will take you to a shutdown window. The unit will power off after clicking the “OK” button and verifying the username and password.
- ② Disconnect the power.

##### By mouse:

- ① Click **Start**→**Shutdown** to open the Shutdown window. Select “Shutdown” in the window. The unit will power off after clicking the “OK” button and verifying the username and password.
- ② Disconnect the power according to the prompt shown on the screen.

### 2.2 Remote Controller

- ① Uses two AAA size batteries. (Not included)
- ② Open the battery cover of the remote controller.
- ③ Place batteries. Please note the polarity (+ and -) and insert properly.
- ④ Replace the battery cover.

Key points to check in case the remote doesn't work.


1. Check batteries polarity.
2. Check the remaining charge in the batteries.
3. Check IR controller sensor for any masking.

If it still doesn't work, please contact your distributor. Note that the remote control is the same for all units of the same model. Be sure to point the IR sensor of the remote control directly towards the IR receiver of the NVR you wish to control if you have multiple devices.

It's also recommended to place the recorders away from each other if possible.

There are two kinds of remote controller. The interface of remote controller is shown below.

### Type I:









Button	Function
Power Button	Turn device on and off
Record Button	To start recording
-/-- /0-9	Input number or choose camera
Fn1 Button	Currently no function
Multi Button	Choose multi screen display mode
Next Button	Switch camera
SEQ	Go to sequence view mode
Audio	Enable audio output in live mode
SPOT	Currently no function
Direction button	Move cursor in setup or pan/title PTZ
Enter Button	Confirm a choice or setup
Menu Button	Go to the main menu
Exit Button	Exit the current interface
Focus/IRIS/Zoom/PTZ	Control PTZ camera
Preset Button	Enter into preset setting in PTZ mode
Cruise Button	Go to cruise setting in PTZ mode
Track Button	Currently no function
Wiper Button	Currently no function
Light Button	Currently no function
Clear Button	Currently no function
Fn2 Button	Currently no function
Info Button	Get information about the device
	Control playback. Play(Pause)/Stop/Previous
	Frame/Next Frame/Speed Down/Speed Up
Snap Button	Take snapshots manually
Search Button	Go to the search and backup interface
Cut Button	Currently no function
Backup Button	Go to the search and backup interface
Zoom Button	Zoom in
PIP Button	Currently no function

**Calling login box:** After the device starts successfully, the login box will appear by pressing “Menu” or “Enter” button.

**Password input:** Move to the password edition box by pressing ▲ ▼ ◀ ▶ and then



press the digital numbers to enter the password; press “Exit” to delete the input digital number; But the “digital number + letter” password cannot be input by the remote controller. You need to input by mouse-click.

**Playback control:** Press  to enter the playback interface. Press  or  to speed down or up the recorded video; press “Next” to switch the playback camera (channel); press “Multi” to switch the screen display mode; press  to stop playing; press  to pause; after the playback pauses, press  to play the previous or next frame.

**PTZ control:** Select the PTZ camera through the direction buttons and then press “PTZ” button to go to the PTZ control mode. Press the direction buttons to move the PTZ camera; press “Preset”+ “digital number” (eg. 3) to call preset 3; press “Cruise” + “digital number” (eg.1) to call cruise 1. Note that the corresponding preset and cruise must be set by mouse-click in advance, or they cannot be called.

### Type II:



Button	Function
REC	Record manually
Search	Enter the search and backup interface
MEUN	Enter the main menu
Exit	Exit the current interface
ENTER	Confirm the choice or setup
Direction button	Move cursor in setup
ZOOM	Zoom in
PIP	Currently no function
 	Control playback. Play(Pause)/Next Frame/Speed Up/Stop/Previous Frame/Speed Down
Multi	Choose multi-screen display mode
Next	Switch camera
SEQ	Go to sequence view mode
INFO	Get information about the device

**Playback control:** the operations are the same as above.

**PTZ control:** select the PTZ camera and then press “Enter” to go to the PTZ control mode. Press the direction buttons to move the PTZ camera.

**Note:** Before using the remote controller without digital numbers, you need to log in the device by mouse-click first. Then turn the IR sensor of the remote controller towards the IR receiver of the NVR to control it.

## 2.3 Mouse Control

### ➤ Mouse control in Live Display & Playback interface

In the live display & playback interface, double click on any camera window to show the window in single screen mode; double click the window again to restore it to the previous size.

In the live display & playback interface, if the interfaces display in full screen, move the mouse to the top of the interface to have the tool bar appear. The tool bar will disappear automatically after you move the mouse away from it; move the mouse to the right side of the interface to pop up a panel and the panel will disappear automatically after you move the mouse away from it.

### ➤ Mouse control in text-input

Move the mouse to the text-input box and then click the box. The input keyboard will pop up automatically.

*Note: Mouse is the default tool for all operations unless an exception is indicated.*






## 2.4 Text-input Instruction



The interface has two types of input boxes. Refer to the above pictures. The left box is the number-only input box and the right box provides inputs of numbers, letters and punctuation characters. The introductions of keys on the input boxes are shown below.




Button	Meaning	Button	Meaning
	Backspace key		Switch keyboard to see more punctuation characters
	Delete Key		Enter key
	Switch between upper and lower letter		Space key
	Switch language		

## 2.5 Common Button Operation

Button	Meaning
	Click to show the menu list.
 	Click to change the sequence of the list.
	Click to change the camera display mode.
	Click to close the current interface.
Earliest	Click to go to the earliest date of camera recording.
Latest	Click to go to the latest date of camera recording.


## 3 Wizard & Main Interface

### 3.1 Startup Wizard

The disk icons will be shown on the top of the startup interface. You can view the number and status of each disk quickly and conveniently through these icons ( : no disk; : unavailable disk; : RW available disk).

You can quickly configure the NVR by wizard setup to make the NVR work normally. You must configure the wizard if you start the NVR for the first time (or click “Skip” to cancel the wizard until the next time you login). Maybe different versions have different wizard steps. The following wizard steps are for reference only.

- ① Choose the language and locality as needed if it is the first time for you to use the wizard and then read the privacy statement, checkmark “*I have read and agree*” and click “OK”.
- ② **Date and Time Configuration.** The date and time of the system needs to be set up if you use the wizard for the first time. Refer to the following figure. Set the time zone, system time, date format, time format and video format. The DST will be enabled by default if the time zone selected includes DST. Click “Next” to continue.




The screenshot shows a 'Wizard' configuration window with the following settings:

Field	Value
Time Zone	GMT-08 Las Vegas, San Francisco, Vancou
System Time	03/18/2025 09:34:08 AM
Date Format	Month/Day/Year
Time Format	12-Hour
DST	ON
Synchronous	Manual
NTP Server	time.windows.com
Interval Time[Min]	180
Video Format	NTSC

At the bottom right, there are 'Previous' and 'Next' buttons.


- ③ **System Login.** Set your own password when you use the wizard for the first time (the default username of the system is *admin*); select the login username and enter the corresponding password next time.




The screenshot shows the 'Wizard' interface for 'admin Password Setup'. It includes the following elements:

- Username:** A text field containing 'admin'.
- New Password:** A text field with 'Enter Password' and a strength indicator below it.
- Confirm Password:** A text field with 'Enter Password' and a strength indicator below it.
- Display Password:** A checked checkbox.
- Pattern Lock:** An unchecked checkbox and an 'Edit' button.
- Requirements:** '1.8 to 16 characters' and '2.Contains two or more numbers/lowercase/uppercase letters/symbols.'
- Navigation:** 'Previous' and 'Next' buttons at the bottom.

Enable pattern lock and click “Edit” to set the pattern lock.




Click “Next” to set the default password which is used to activate IPC.



The screenshot shows the 'Wizard' interface for 'Channel IP Planning'. It includes the following elements:

- Navigation:** 'Camera Default Password' and 'Channel IP Planning' tabs at the top.
- Default Password:** A text field with 'Enter Password' and a strength indicator below it.
- Display Password:** An unchecked checkbox.
- Instructions:** '\*Use this password when activating IPC' and requirements: '1.8 to 16 characters' and '2.Contains two or more numbers/lowercase/uppercase letters/symbols.'
- Navigation:** 'Previous' and 'Next' buttons at the bottom.


Click “Channel IP Planning” to enable the channel IP planning as needed. If enabled, the NVR will automatically assign IP addresses to ensure quickly added cameras are online after successful authentication when the cameras and the NVR are not in the same network segment.



Click “Next” to set Email or questions and answers for password reset of admin. If you forget the password, you can reset the password via E-mail or security question. See Appendix-1 question 4 for details.

Click “Next” to continue. Then click “Wizard Setup”.

④ **Network Settings.** Select the network parameters as required. Check “Obtain an IP address automatically” and “Obtain DNS automatically” to get the IP address and DNS automatically (the DHCP function of the router in the same LAN should also be enabled) or manually enter them. Enter the HTTP port, HTTPS port and Server port (please see [Port Configuration](#) for details). Click “Next” to continue.





**Note:**


- If you use the NVR with the PoE network ports, the online state of the internal Ethernet port will be shown on the interface. Refer to the picture below. Please refer to [TCP/IP Configuration](#) for detail introduction of the internal Ethernet port.

The screenshot displays the 'Wizard' configuration screen for network settings. It is divided into two columns. The left column shows settings for a primary network interface: Subnet Mask (255.255.0.0), Gateway (10.20.0.1), an unchecked 'Obtain DNS automatically' checkbox, Preferred DNS (8.8.8.8), and an empty Alternate DNS field. The right column shows settings for a secondary network interface: Subnet Mask (255.255.255.0), Gateway (192.168.4.1), an unchecked 'Obtain DNS automatically' checkbox, Preferred DNS (8.8.8.8), and an empty Alternate DNS field. A red rectangular box highlights the 'Internal Ethernet Port (Online)' section, which includes: Address (10.151.151.1), Subnet Mask (255.255.255.0), Mode (Non-long line mode), and Default Route (Ethernet Port 1). Below these sections are fields for HTTP Port (80), HTTPS Port (443), and Server Port (6036). At the bottom right, there are 'Previous', 'Next', and 'Cancel' buttons.

- If the NVR has two or more network ports, you can select TOE (varies by model) as needed. Select the work pattern: Network Fault Tolerance and Multiple Address Setting are available. Refer to the pictures below. Please refer to [TCP/IP Configuration](#) for more detailed information.



⑤ **Add Camera.** Click “Refresh” to refresh the list of online IP cameras which are in the same local network with NVR.



In the above interface, the device activation state can be viewed. For the activated device, you can click **+** to add the searched camera. Click “Add All” to add cameras in batches.


If the IP addresses of the added IPCs are not in the same local network segment as the NVR’s, the NVR will automatically assign the IP addresses in the same local network segment for the added IPCs. Note that the prerequisite for successfully assigning IP addresses for IPCs and adding is that the password of the IPCs must be the same as the set default activation password in the NVR and the channel IP planning function is enabled.

If the default password is not used by the activated device, you need to modify it manually.

If a camera has multiple channels, the multiple channels of the camera in the camera list can be searched. You can add them as needed.

Note: \* Only one channel of the multi-channel ONVIF camera can be searched.

\* Only one channel of the optical and thermal camera of lower versions can be searched.




Click **[trash icon]** to delete the added camera. Click “Delete All” to delete all the added cameras.


For the unactivated devices, you can activate one by one or in batches. Check the unactivated device and click “Activate” to pop up an activation box.


You can use default password to activate.

If your camera needs to be activated by self-defined password, you need to manually enter the password to activate.

For unactivated private protocol IPCs (not the third-party device), you can click  to directly add and the IPCs will be automatically activated through the default password; If multiple IPCs have the same IP address and are not activated, you can also click “Add All” to automatically activate and add. In addition, the NVR will automatically assign IP addresses for them (IP channel planning should be enabled first).

**Note:** During the activation, the device cannot disconnect with the NVR, or the activation will fail.

Click  to edit the searched IP camera as shown on the below left. Enter the new IP address, subnet mask, gateway, username and the password of the camera. Click “OK” to save the settings.

Click  to edit the added camera as shown on the above right. Enter the new camera name, IP address, port, username and the password of the camera. You can check “Sync to IPC” to modify the IP address of the IPC via different network segments for being in the same network segment with the NVR. Then click “Test” to test the connection. Click “OK” to save the settings. You can change the IP camera name only when the added camera is online. Click

“Next” to continue.

⑥ **Disk Settings.** You can view the disk number, disk capacity of the NVR and serial number, R&W status of the disk. Click “Format” to format the disk. Click “Next” to continue.


**Tips:** Please skip Step ⑦ and ⑧ if the NVR does not support RAID function.

⑦ **Disk Mode.** Click “Enable RAID” to enable the RAID function. Click “Next” to continue.


⑧ **Create an array.** Set the array name and select array type which includes RAID0, RAID1, RAID5, RAID6 and RAID10. The global hot spares and array capacity can also be viewed here. See [Disk](#) for details. Click “Next” to continue.

⑨ **Record Settings.** Two record modes are available: auto and customization.

**Auto:** Select one auto mode in the interface as shown below and then click the “Next” to save the settings. Click “Customized” to self-define record mode. See [Mode Configuration](#) for details.



**Customization:** Set the “All events record”, and “Schedule Record” of each camera. Click “OK” to save the settings. See [Mode Configuration](#) for details.




⑩ **QRCode.** Enable the NAT function in the interface or set it in the network configuration after exiting the wizard (please refer to [NAT Configuration](#) for details). You can scan the

QRCode through mobile client which is installed in the mobile phone or tablet PC to log in the mobile client instantly. Please refer to [Mobile Client Surveillance](#) for details. Click “OK” to save the settings.

⑪ **Cloud Upgrade.** Enable “Cloud Upgrade” and then click “OK” to save. If this function is enabled, you can get the latest version from the cloud server. Please refer to [Cloud Upgrade](#) for details. Only user levels with “Network” access will be able to enable/disable cloud upgrades.














## 3.2 Main Interface

### 3.2.1 Main Interface Introduction



The buttons in area ① are described in the table below.


Button	Meaning
	Start button. Click to pop up area ③.
	Full screen button. Click to show full screen; click it again to exit the full screen.
	Screen mode button.
	Dwell button (see <a href="#">Quick Sequence View</a> and <a href="#">Scheme View in Sequence</a> for details).
	Click to enable OSD; click again to disable OSD.
	PicSearch; you can search for specific targets of interest (human body or face) with one click. Refer to <a href="#">PicSearch</a> for details.


Button	Meaning
	Click  to set the default playback time before starting instant playback ( <a href="#">Instant Playback</a> ) or going to the playback interface for playback operations ( <a href="#">Playback Interface Introduction</a> ); click  to go to the playback interface. For instance, if you choose “5 minutes ago” as the default playback time, you can playback the recording from the past five minutes.
	Manual record button. Click to enable/disable record.
	Manual alarm button. Click to trigger or clear the alarm-out manually in the popup window.
	Record status button. Click to view the record status.
	Alarm status button. Click to view the alarm status.
	Voice broadcast button. Click to select the channel to broadcast.
	Disk status button. Click to view the disk status and RAID status.
	Network status button. Click to view the network status.
	Information button. Click to view system information.
	RS485 button. Click to select the relevant operation as need.
	Click to enable the cloud upgrade feature.


**Note:** Different models may have different buttons on the live view interface. All pictures in this manual are for reference only; the real product shall prevail.

Introduction of area ②:

Area ② is hidden by default. Move the cursor to the right to reveal this area. Click “Camera” to view all the added cameras in the camera list. Select one camera window on the left side of the interface and then double click one camera in the list to preview the camera image in the selected window.










Click  on the top right corner and then select “Single Channel Sequences” to view all the added groups in the group list; click one group in the list to view all the added cameras in the group (refer to [Add/Edit Camera Group](#) for detail configuration of the camera group). Select one camera window on the left side of the interface and then double click one group in the group list to preview the cameras’ images one by one in the selected window.

Click  on the top right corner and then select “Customize Display Modes” to view all the display modes in the display mode list (refer to [Preview by Display Mode](#) for detail configuration of the display mode). Double click one display mode in the list to switch to the display mode for previewing.

Click  on the top right corner and then select “Target Detection” to go to target detection interface. This tab will show the captured images of people, vehicles, and license plates. (This


function is only available for some models). Note that only some models support multi-channel target detection display.

Introduction of area ③:

Icon / Button	Meaning
	It shows the current login user. Click the QR code icon to view the QR code and verification code. Users can quickly add the NVR to the server list of the mobile APP by scanning this QR code.
	Click to go to the intelligent analytics interface.
	Click to set parking lot, access control, face attendance and face check-in (varies by models)
	Click to go to record search and backup interface, see <a href="#">Record Search, Playback &amp; Backup</a> for details.
	Click to go to playback interface (click  on the tool bar at the bottom of the live view interface to set the default playback time), see <a href="#">Playback Interface Introduction</a> for details.
	Click to open the setup panel, see <a href="#">Setup Panel</a> for details.
	Click to log out the system.
	Click it and then select “Logout”, “Reboot” or “Shutdown” in the popup window.


## 3.2.2 Setup Panel

Click **Start** → **Settings** to open the setup panel as shown below.




The setup panel includes seven modules. Each module provides some functional entries with links for convenient operation.

Here we take **Camera** module as an example. The **Camera** module provides convenient links such as “Add Camera”, “Edit Camera”, “Image Settings”, “Motion” and “PTZ”. Click **Camera** to go to the camera management interface as shown below.



There are some function items on the left side of the camera management interface. Click each item to go to corresponding interface or window. For instance, click “Add Camera” to open the window as shown below.



Click the main menus on the top of the camera management interface to go to corresponding interfaces. Refer to the picture below. For instance, you can go to system setup interface by clicking “System” tag.



### 3.2.3 Main Functions

#### ➤ Camera

The module covers the functions such as **Camera Management** (see [Camera Management](#) for details), **Image Settings** (see [Preview Image Configuration](#) for details), **Motion Alarm** (see [Motion Alarm](#) for details), and **PTZ** (see [PTZ](#) for details) and so on.

#### ➤ Record

The module covers the functions such as **Encode Parameters** and **Record Schedule** and so on. Please see [Record & Disk Management](#) for details.

#### ➤ AI/Event

The module covers the functions such as **Smart Event**, **Combination Alarm**, **Exception**,

*Sensor and Motion Alarm Handling* and *Alarm Out Settings*. Please see [AI Event Management](#) and [General Event Management](#) for details.

➤ **Disk**

The module covers the functions such as *Disk Management*, *Storage Mode* and *Disk Information* and so on. Please see [Record & Disk Management](#) for details.

➤ **Network**

The module covers the functions such as *TCP/IP*, *DDNS*, *Port*, *E-mail* and *Network Status* and so on. Please see [Network Configuration](#) for details.

➤ **Account and Authority**

The module covers the functions such as *Account Management* (see [Account Management](#) for details) and *Permission Management* (see [Permission Management](#) for details) and so on.

➤ **System**


The module covers the functions such as *Basic Configuration* (see [Basic Configuration](#) for details), *Device Information* (see [View System Information](#) for details), *Log Information* (see [View Log](#) for details) and *Configuration File Import & Export* (see [Backup and Restore](#) for details) and so on.



## 4 Camera Management

### 4.1 Add/Edit Camera



#### 4.1.1 Add Camera

The network parameters of the NVR should be set before adding an IP camera (see [TCP/IP Configuration](#) for details).


Refer to the pictures below. Click **Add Camera** in the setup panel or  in the top right corner of the preview window to open the “Add Camera” window as shown below. You can quickly add from a list or add the IP camera manually.




#### ➤ Quickly Add


Check the cameras and then click “Add” to add cameras. Click  to edit the camera’s IP address, subnet mask and so on. Click “Refresh” to refresh the device list. If the activation state is “Unactivated”, you can check the device and click “Activate” to activate it. Click “More” and select “Camera Default Password” to set the default username and password of each camera. Double click the password box in the “Camera Default Password” window and modify the password as needed; click  and verify the permission to view the default password. Click “More” and select “Channel IP Planning” to enable the channel IP planning as needed. If enabled, the NVR will automatically assign IP addresses to ensure quickly added cameras are online after successful authentication when the cameras and the NVR are not in the same network segment.

### Descriptions of the Channel Numbers:

- For PoE models, when quickly or manually adding cameras, the channel number will be started from No.1. If a channel number is occupied by a manually added camera and another PoE camera is connected to the PoE port whose port number is the same with the channel number, an occupied prompt will appear. You need to delete the manually added camera and then the PoE camera can be added successfully.
- If the channel number is occupied by a PoE camera which is directly connected through PoE port of the PoE NVR, this channel number cannot be selected when manually adding other cameras.
- The channel number will not be shown when quickly adding cameras. Only when a channel is checked, can its channel number be viewed. You can click  next to the channel number to change the channel number as needed.




If a camera has multiple channels, the multiple channels of the camera in the camera list can be searched. You can add them as needed.




- Note:
- \* Only one channel of the multi-channel ONVIF camera can be searched.
  - \* Only one channel of the optical and thermal camera of lower versions can be searched.

For other detailed operations of quickly adding, see [Startup Wizard](#).



### ➤ Add Manually


Enter the IPv4/IPv6 address or domain name (click  in the IP address column to open the IPv4/IPv6/domain name input window), port, username and password of the camera and then select the channel no. and the protocol. Click “Test” to test the accuracy of the input information and then click the “Add” button (you can input one camera’s information or above such as IP address, username and password before clicking the “Add” button). Click  to delete the camera. Click “Default Password” to set the default username and password of each camera. If a camera has multiple channels, you can add them as needed.




Click **Start** → **Settings** → **System** → **Basic** → **General Settings** to check “Enable Add IPC by Zero Operation”. If the NVR has unoccupied channels, it can add IPC without any operation by restarting.

**Note:** Some models may not support this function.

### ➤ Add Recorder




- **Quickly Add:** Select the searched NVR/NVR and the click “Add” to add NVR in the same local network.
- **Manually Add:** Click “Manual Add” and then enter the IP address or domain name, port, username and password of the NVR/NVR. Check the added remote channel number and click “Test”. Then click “OK” to return to the previous interface.



**Note:** IPC from other NVR/DVR on the same local network can only be added if your NVR has open channels and the added IPCs support previewing and recording.

### ➤ Auto Report

You can add IPCs in the NVR by auto report.



Click the “Auto Report” tab to enter auto report interface. You can view the IPCs reported automatically. Select a camera and click “Test” to test the connection. If the login password of the IPC is the same as the camera default password, you can directly click [Add] to add it. If the password is not the same one, you need to modify the password and then add it.

IPC auto report settings:

Here taking the IPC of our company as an example

1. Log in the web client of the IPC. Click **Config**→**Network**→**Server** to enter the server configuration interface.

Port	Server	Onvif	DDNS	SNMP	802.1X	RTSP	RTMP
<input checked="" type="checkbox"/> Enable							
Server Port		2009					
Server Address		192.168.1.5					
Device ID		1					
<b>Save</b>							

2. Check “Enable”.

3. Enter server port, server address and device.

Server Port: the auto report port of NVR, 2009 by default. You can go to **Start**→**Settings**→**Network**→**Port** interface to view in the NVR.

Server Address: the IP address of NVR.

Device ID: set it as needed. It is the sub ID in the NVR.

4. Click “Save” to save the settings.

After that, you can view the IPC in the auto report interface.

For some cameras with multiple channels, you can select the server type (“Channel” or “Device”) as needed.

<input checked="" type="checkbox"/> Enable	
Server Port	<input type="text" value="2009"/>
Server Address	<input type="text" value="10.15.1.122"/>
Device ID	<input type="text" value="1"/>
Server Type	<input type="text" value="Channel"/>
<input type="button" value="Save"/>	







If the server type is set to “Device”, a single channel will be automatically reported by default.


Add Camera							
Quickly Add   Add Manually   Add Recorder <b>Auto Report</b>							Refresh
<input type="checkbox"/>	No.	Sub-device ID	Remote Chan...	Channel No.	Address	Protocol	Username
<input type="checkbox"/>	1	1	1		10.15.1.201		admin

If the server type is set to “Channel”, multiple channels will be automatically reported by default.

Add Camera							
Quickly Add   Add Manually   Add Recorder <b>Auto Report</b>							Refresh
<input type="checkbox"/>	No.	Sub-device ID	Remote Chan...	Channel No.	Address	Protocol	Username
<input type="checkbox"/>	1	1	3		10.15.1.201		admin
<input type="checkbox"/>	2	1	4		10.15.1.201		admin
<input type="checkbox"/>	3	1	5		10.15.1.201		admin


### 4.1.2 Edit Camera

Click “Edit Camera” in the setup panel to go to the interface as shown below. Click  to view the live image of the camera in the popup window. Click  to edit the camera (see *Add camera* in [Startup Wizard](#) for details). Click  to delete the camera. Click  in the “Edit” header line and then click “Modify IPC Password” to open a window(check the IPCs in the window, set the new password and then click “OK”; only the online IPCs’ passwords can be modified and a batch of IPCs’ passwords can be modified at the same time). Click  to upgrade an online IPC ( or click  in the “Upgrade” header line and then click “IPC Batch Upgrade” to upgrade a batch of IPCs), select the device which stores the upgrade file in the “Device Name” item of the popup window and the upgrade file in the list(you should select the upgrade IPC model in the window if a batch of IPCs’ passwords need to be modified) and then click “Upgrade” to start upgrading(the IPC will restart automatically after the upgrade is completed successfully).



### Note:

If you use the NVR with the PoE network ports, the IP cameras (with PoE function) which are directly connected to the PoE port of the NVR will be displayed automatically in the camera list. Refer to the picture below. The PoE camera directly connected to the PoE port has a prefix shown before its camera name. The prefix consists of PoE plus PoE port number. A PoE camera directly connected to the PoE port cannot be deleted from the camera list manually.



- An IP camera directly connected to the PoE port of the NVR through private protocol will be shown automatically in the camera list.
- One of the two conditions must be met if an IP camera directly connected to the PoE port of the NVR through ONVIF protocol to be shown automatically in the camera list.
  - ✓ The IP camera which is directly connected to the PoE port is in the same network segment with the internal Ethernet port.
  - ✓ The DHCP (obtain an IP address automatically) of the IP camera which is directly connected to the PoE port is enabled.


If the IP camera which is connected to the PoE port cannot be displayed automatically in the camera list, please refer to Q6 in [Appendix A FAQ](#) for details.

## 4.2 Add/Edit Camera Group


### 4.2.1 Add Camera Group



Click “Edit Camera Group” in the above interface to go to the interface as shown below.




Click “Add Group” to open the window as shown below. Set the group name and dwell time (the dwell time of the camera group sequence view) in the window. Check the cameras and then click “Add” to add group. Click  to view the cameras in the group after adding


group.






You can also add the camera group in the live view interface. Click  on the top right corner of the live view interface and then select “Single Channel Sequences”. Click  to add the camera group



### 4.2.2 Edit Camera Group




Click  to modify the group information such as group name and dwell time. Click  to delete the group. Click  to add cameras to the group.


### 4.2.3 IP Planning



Some models may not support this function.

Click “IP Planning” to go to the interface as shown below. This function supports searching other NVRs/DVRs that is in the same local network as the local NVR. You may add the IPC of other NVRs/DVRs into the unoccupied channels of the local NVR.

For the searched channel, if its state is “unactivated”, you can activate it first and then add it.




Click  to edit the IP address, user name or password and other information of the NVRs.

Click  behind the “Add” button to add the IPC selected and the user may edit the IP address, user name or password by clicking  behind the “Edit” button.

### 4.3 IP Speaker Management

You can add IP Speaker to the NVR via ONVIF protocol and bind the added IP speaker to the corresponding IPC or NVR for two-way talk or audio alarm. After enabling two-way talk or audio alarm, the built-in speaker or external audio output of the IPC or NVR will not take effect.

Go to **Start** → **Settings** → **Camera** → **IP Speaker** interface and click “Add” to add an IP speaker.



**IPv4:** enter the IPv4 address of the IP Speaker you want to add.

**Protocol:** ONVIF


**Port:** 80 by default.

**Username and Password:** the login user name and password of the IP Speaker

**Linkage:** select the camera or NVR you want to link with the IP Speaker

After the IP Speaker is successfully added and linked, you can view it in the IP Speaker interface.


In addition, you can modify the IP Speaker name or change the linkage item as needed.



## 5 Live View Introduction







### 5.1 Live View Interface Introduction



You should add a camera when first logging on to the system (see [Add Camera](#) for details). Refer to the interface as shown below and drag one camera in the preview window to another window to exchange windows. Click **OSD** button and then you can view the record symbols. The record symbols with different colors in the live view window refer to different record types when recording: green stands for manual record, red stands for sensor-based record, yellow stands for motion-based record, blue stands for schedule record and cyan stands for AI record.




Click the preview window to show the tool bar as shown in area ①; right click the preview window to show the menu list. The tool bar and menu list are introduced in the table below.

Button	Menu List	Meaning
	--	Move tool. Click to move the tool bar anywhere.
	<b>Manually Record On</b>	Click to start recording.
	<b>Instant Playback</b>	Click  to playback the record; click “Instant Playback” to select or self-define the instant playback time. See <a href="#">Instant Playback</a> for details.
	<b>Enable Audio</b>	Click to enable audio. You can listen to the camera audio by enabling audio.
--	<b>Original Proportions/ Overspread window</b>	Click to select the display proportion of the window.

Button	Menu List	Meaning
	<b>Snapshot</b>	Click to pop up the snap window. Click “Save” in the window to save the image. Click “Export” to export the image.
	<b>PTZ Control</b>	Click to go to PTZ control interface. See <a href="#">PTZ</a> for details.
--	<b>Wiper</b>	Click to start or stop wiper for some PTZ cameras
	<b>Zoom In</b>	Click to go to single channel amplification interface.
	--	Click to go to image adjustment interface. Refer to <a href="#">Image Adjustment</a> for details.
	<b>Start/Close Talk</b>	Click to start talk.
	<b>Target detection</b>	Click to go to single channel target detection interface; the target includes faces, people and vehicles. <b>(only some models support)</b>
--	<b>Camera Info</b>	Click to view the camera information.


The single channel zoom amplification interface is as shown below. Press and drag the blue box to select the area to zoom in. Click  /  to zoom the image. Click the camera selection box to select other cameras for amplification. Click “Back” to return to the live view interface.



## 5.2 View Mode



### 5.2.1 Preview by Display Mode

Set different screen modes and camera display sequences as needed and then save the display modes classified by surveillance areas, priorities and so on. Refer to the picture below. Double click one display mode in the display mode list to view the live images in this mode.




### ➤ Add Display Mode



#### Method One:

- ① Click “Customize Display Modes” in the above interface
- ② Click  to add a display mode name and then set the screen mode.
- ③ Add the cameras and adjust the cameras’ display sequence as required.
- ④ Click  under the display mode list.

#### Method Two:

- ① Click **Start**→**Settings**→**System**→**Basic**→**Output Settings** to go to the interface and then set the screen mode.
- ② Double click the camera or camera group in the list to add them to the selected window.
- ③ Click  to save the current display mode (refer to [Scheme View in Sequence](#) for detail configurations). The display mode will be saved and displayed in the display mode list in the live view interface.


### ➤ Edit Display Mode

Click “Customize Display Modes” tab in the live view interface and then select one display mode in the list. Click  to edit the display mode name; click  to delete the display mode.

### ➤ Corridor Pattern

Some models may not support this function.

Select corridor pattern in display mode. You can change the direction of the video image by using this function. Please refer to User Manual of relevant camera.




Change to corridor mode

➤ Fisheye Mode

Some models may not support this function.

In the live view interface, select the view mode according to the installation mode and display mode of the fisheye camera. Please refer to User Manual of the relevant fisheye camera.


**Note:** If multiple channels of one fisheye camera are added, only fisheye channel supports the adjustment of installation mode and display mode.






In addition, if this function is unavailable in the device, you can set the display mode and the installation mode via Web Client. To log in the web client, please refer to [Remote Surveillance](#) for details.

### 5.2.2 Quick Sequence View

You can start quick sequence view if the scheme has not been created. If the scheme has been created, please refer to [Scheme View in Sequence](#) for details.




Go to the live view interface and then click  to open a small window. Set the dwell time in the window and then click  to view the live group by group according to the camera number of the current screen mode. Double click the sequence view interface to pause the view; double click again to restore the view. Click  to stop the view.




### 5.2.3 Camera Group View in Sequence

You can start camera group view in sequence if camera group has been created (see [Add Camera Group](#) for details).

- ① Go to the live view interface and then select a camera window.






② Double click one camera group on the right side of the interface. The cameras in the group will start camera group view one by one in the selected camera window. You can also drag the group directly to any preview window. Right click on the group view window and then click “Close Dwell” to stop the view.

Click  to add camera group. Select a group and click  to modify the group name and dwell time; Select a group and click  to delete the group.



## 5.2.4 Scheme View in Sequence

Click *Start* → *Settings* → *System* → *Basic* → *Output Settings* to go to the interface as shown below.


Area ① displays all the dwell schemes; area ② shows the detailed information of the scheme; area ③ displays all the cameras and groups; area ④ is the tool bar (: clear button; : favorite button, click to open a window, enter the display mode name in the window and then click “OK” to save the current display mode; other buttons are screen mode buttons).






### ➤ Add Scheme

Click  in area ① to create a new scheme. Click  on the top right corner of the scheme to delete it.

### ➤ Configure Scheme


- Select a scheme in area ① and then click the screen mode button on the tool bar to set the screen mode of the scheme.
- Select a camera window in area ② and then double click the camera or group in area ③. The camera or group will be added into the selected window. You cannot repeat a camera in the same scheme. You can click the right-click menu “Clear” in area ② to remove a single camera or click  to remove all the cameras.
- Click “Apply” to save the settings.

### ➤ Start Sequence View

Go to the live view interface and then click  to open a window. Set the dwell time in the window and then click  to start scheme view in sequence. Double click the sequence view interface to pause the view; double click again to restore the view. Click  to stop the view.

### Note:

You can set the secondary output preview if the NVR has dual outputs. Refer to the interface as shown below.



Check “Dwell” and then set scheme view in sequence of the adjutant output. The setting steps are similar to that of the main output.

Set quick sequence view if “Dwell” is not checked. The setting steps are as follows:


- ① Set screen mode by clicking the relevant buttons on the tool bar.
- ② Select one window and then double click one camera or group in the list.
- ③ Click “Apply” to save the settings after adding cameras or groups to the windows.

For some devices with multi-output mode and AI mode, the secondary output may be unavailable after AI mode is enabled. If you want to enable secondary output, please click **Start** → **System** → **Output Settings**.




## 5.3 POS Settings


- ① Click **Start** → **Settings** → **Basic** → **POS Settings** to go to the interface.
- ② Enable POS and click “Configure” under “Connection Settings” to go to the following interface. The connection method includes TCP Server, TCP Client, UDP and Multicast.
- ③ Enter IP address of the POS you want to add.
- ④ Check “POS port” and then enter POS port.



- ⑤ Select the POS protocol.
- ⑥ Check “Trigger Camera” and click “Configure” under it to bind POS to the camera. One POS can be bound to multiple channels, but one channel can only be bound to one POS.




- ⑦ Click “Configure” under “Display Settings” to set the general settings, the position and display color of the POS information. Set the start character and the end character and display time-out period in the general settings interface. Drag your mouse to set the position of the POS information in the display position interface. Then click “OK” to confirm your settings.




Click the “Display Color” tag and then choose the color you want to display on the screen. Multi-color can be selected at the same time. In addition, print method and preview display can be set here. If “Preview Display” is enabled, the POS contents can be displayed on the live view/playback interface.

- ⑧ Select the encoding format as needed.
  - ⑨ Choose the manufacturer of the POS device.
  - ⑩ Click “Apply” to save the settings and then the transaction information will be displayed on the preview image in real-time.
- One POS is bound to one camera:




One POS is bound to multiple cameras:



## 5.4 Preview Image Configuration


### 5.4.1 OSD Settings

Click **Start** → **Settings** → **Camera** → **Image** → **OSD Settings** to go to the interface as shown below.




Select the camera, enter the camera name (or double click the camera name in the camera list to change the camera name), enable or disable the name and time OSDs (if enabled, drag the red name and time OSDs directly in the image view area to change the OSDs' display position) and select the date and time format (24h or 12h is optional). Additionally, water mark can be enabled or disabled here. Having enabled the water mark function, you can enter the information of the water mark as needed. Finally, click “Apply” to save the settings.

## 5.4.2 Image Settings


Click *Start*→*Settings*→*Camera*→*Image*→*Image Settings* to go to the following interface. Select the camera and then set the brightness, contrast, saturation and hue of the camera. Click the “Advanced” button or  in the camera list on the right side of the interface to open the “Image Adjust” interface and then set the relevant setting items. Please refer to [Image Adjustment](#) for detailed introductions of these items.


You can click “Default” to restore the image settings to the default factory settings.




### 5.4.3 Mask Settings


Some areas of the image can be masked for privacy. Up to four mask areas can be set for each camera. Click **Start**→**Settings**→**Camera**→**Image**→**Mask Settings** to go to the interface as shown below.



Select the camera and click the “Draw” button and then drag the mouse on the image area to set the mask area; if the mask area is not satisfactory, you can click the “Delete” button to delete the mask areas. In addition, you can set the color of the mask area by clicking “”.



For some cameras, you can also set mosaic mode as shown below.



After the mask areas are added, you can set the mask schedule as needed. The mask areas only take effect during the scheduled period.

The mask areas only take effect during the scheduled period. Choose a mask area and click “Delete” to delete the mask area.

### 5.4.4 Fisheye Settings

Some models may not support this function.

#### ➤ Add Fisheye Camera

You can add multiple channels of a fisheye camera through quickly adding/manually adding/auto report. For example, the current stream mode of the fisheye camera is “Fisheye + panoramic view + 3PTZ” mode, so the channel 1 is fisheye channel, the channel 2 is panoramic view and the remaining channels are PTZ channels. After it is added successfully, it will show as below.

No.	Camera Name	Address	Sub-device ID	Remote Channel ...	Port	Status	Protocol	Model	Preview	Edit
1	IP01	172.20.74.201	--	1	9008	Online				
2	IP Camera01	192.168.258.105	--	1	9008	Online		FR		
3	IPC	10.100.50.29	--	1	9008	Online		T1		
4	IPC	10.15.1.282	--	1	9008	Online		I-A		
5	IPC	10.15.1.282	--	2	9008	Online		I-A		
6	IPC	10.15.1.282	--	3	9008	Online		I-A		
7	IP Camera02	172.20.74.21	--	1	9008	Online		PA		
8	IPC	10.100.50.29	--	1	9008	Online		T1		
9	IPC	10.15.1.282	--	4	9008	Online		I-A		
10	IPC	10.15.1.282	--	5	9008	Online		I-A		

If you add a fisheye camera through PoE direct connection(only PoE NVR supported), the first channel of the fisheye camera will be added by default.

**Remote Channel:** if a network camera you have added has multiple channels, the system will automatically assign the remote channel number for each channel of this camera. If a network camera you have added has only one channel, the remote channel is “1” by default.

➤ **Fisheye Settings**

Click *Start* → *Settings* → *Camera* → *Image* → *Fisheye* Settings to go to the interface as shown below. Select the camera and the mode of fisheye and installation.

Camera Name	Fisheye Mode	Installation Mode	Enable
Camera01	Fisheye+4PTZ	Desktop	<input checked="" type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>


Camera:   
 Fisheye Mode:   
 Installation Mode:   
 Enable:

Apply

**5.4.5 Smart Supplement Light**

After you add the camera with smart supplement light function, you can go to the smart

supplement light interface by clicking *Start* → *Settings* → *Camera* → *Smart Supplement Light*.



1. Set the duration of the white light. In low ambient light, the system will automatically turn on the visible infrared light. Once there are people/vehicles appearing in the set alarm area, it will automatically switch to full-brightness visible white light. When people/vehicles leaving the alarm area exceed the set duration and no other persons/vehicles are detected during the period, it will resume to infrared light.

**Note:** If the people/vehicles staying and not moving in the detection area exceed the set duration, it will resume to infrared light too.

2. Set alarm areas. Select the alarm area number. Four alarm areas can be added.

Click around the area where you want to set as the alarm area in the image (the alarm area should be a closed area). Click “Clear” to clear the set area; click “Clear All” to clear all set areas.


3. Set the detection target and sensitivity. “People” is selected by default. You can also select “Motor Vehicle” or “Non-motor Vehicle” as needed.

**Sensitivity:** The higher the value is, the easier the white light will be triggered by targets.

4. Click “Apply” to save the settings.

## 5.4.6 Splicing


After a splicing network camera is added to the NVR, you can set the splicing parameters as needed by going to *Start* → *Settings* → *Camera* → *Splicing*.



1. Select the type. The default setting is “Splice by Distance”.
2. Set the slicing distance. Please set it according to the actual situation.
3. Click “Apply” to save the settings.

### 5.4.7 Image Adjustment

Go to the live view interface and then click  button on the tool bar under the camera window to go to the image adjustment interface.



#### ➤ Image Adjustment

Select the camera and then click “Image Adjustment” to go to image adjustment tab. Refer to the picture above. Drag the slider to set the camera’s brightness, contrast, saturation and hue value. Check sharpness, wide dynamic and denoise and then drag the slider to set the value. Click “Default” button to set these parameters to default values.


**Note:** For some IPCs, if you have set HWDR in the NVR, these IPCs will automatically reboot after setting the following image parameters, including exposure/shutter mode, gain mode, gain, corridor pattern or smart IR. After these IPCs successfully reboot, HWDR will be disabled.

The introductions of these parameters are as follows:

Parameter	Meaning
Brightness	The brightness level of the camera's image.
Contrast	The color difference between the brightest and darkest parts.
Saturation	The degree of color purity. The image appears brighter, the purer the color is.
Hue	Relates to the total color degree of the image.
Sharpness	Relates to the resolution level of the image plane and the sharpness level of the image edge.
Wide Dynamic	The wide dynamic range (WDR) function helps the camera provide clear images even under back light circumstances. When there are both very bright and very dark areas simultaneously in the field of view, WDR balances the brightness level of the whole image and provides clear images with details.
Denoise	Decrease the noise and make the image more thorough. Increasing the value will make the noise reduction better but it will reduce the image resolution.
White Balance	Adjust the color temperature according to the environment automatically.
BLC	HLC: lowers the brightness of the entire image by suppressing the brightness of the image's bright area and reducing the size of the halo area. BLC: If enabled, the auto exposure will activate according to the scene so that the object of the image in the darkest area will be seen clearly.
Corridor Pattern	0°, 90°, 180° or 270° can be selected. (Only some cameras support this pattern)
Image Mirror	Turn the current video image horizontally.
Image Flip	Turn the current video image vertically.
High FPS Mode	High frame rate mode, if it is enabled, the frame rate of the camera's main stream can be set to 1080P/720P @60fps/50fps. (Only some cameras support this mode)
Gain Mode	Choose "Auto" or "Manual". If "Auto" is selected, the gain value will be automatically adjusted according to the actual situation. If "Manual" is selected, the gain value shall be set manually. The higher the value is, the brighter the image is.
Infrared Mode	Choose "Auto", "On" or "Off" as needed.
Shutter Mode	Choose "Auto" or "Manual". If manual is chosen, the digital shutter speed can be adjusted.
Day & Night Mode	Choose "Auto", "Day", "Night" or "Timing" as needed.
White Light Mode	"Auto", "Manual" or "Off" can be selected. (Only some cameras support this mode).
EIS	Electronic image stabilization; increase the stability of video image by using jitter compensation technology (only some IPCs support this function)
Digital Zoom	Please select it as needed (only some PTZ cameras support this function)

Parameter	Meaning
Supplement Light Mode	Choose “White Light”, “Infrared Light” or “Smart Supplement Light” as needed (this function is only available for dual-illumination cameras)

**Note:** The above-mentioned descriptions of the image parameters are for reference only. The cameras made by different manufacturers may have different parameter settings.

**Thermal image adjustment:** click  on the toolbar of the thermal camera window to enter the image adjustment interface.



**Color code:** set the display color of the thermal image as needed. The thermal colors vary by model.

**Dual image fusion:** overlay the images of two channels (thermal and optical image channels).



**Distance:** set the value according to the distance between the lens of the camera and the main target. The fusion distance between optical image and thermal image will be adjusted along with the adjustment of the distance. The system will automatically adjust the image effect of fusion according to the fusion distance.


**Fusion Level:** the lower the value is, the clearer the optical image is. The higher the value is, the clearer the thermal image is.

**Calibration Adjustment:** correct the distance between optical image and thermal image by clicking the direction buttons.

**Speed:** the speed of image movement after clicking a direction button.

### ➤ Lens Control

Select the camera and then click “Lens Control” to go to lens control tab. Click  or  to adjust the zoom and focus parameters of the camera’s lens. Click “Save” to save the settings.



The introductions of these parameters and buttons are as follows.


Button/Parameter	Meaning
	Click  /  to zoom in/out the image.
Focus Mode	If manual mode is selected, focus button & “One Key Focus” & “Day/night mode switch autofocus” will be available; if auto mode is selected, the time interval setup will be available.
	Click  /  to increase/decrease the focal length.
One key Focus	Click to focus instantly.
Day/night mode switch autofocus	If checked, the lens will focus automatically when the camera is switching day/night mode.
Time Interval	It is the time interval when camera lens is auto focusing. The interval can be set in the drop-down list.


**Note:** This function is only available for motorized zoom cameras.

## 6 PTZ


### 6.1 PTZ Control Interface Introduction

You can control the IP dome or PTZ connected to the IP camera for PTZ control.




























Click  on the tool bar at the bottom of the live preview window to go to the PTZ control interface as shown below.



The direction, zoom, focus, iris and speed can be controlled in the small PTZ control window. Right click the PTZ/speed dome camera window and select “PTZ Control” to go to the PTZ control panel as shown below.



Introductions of the buttons on the bottom right of the interface:

Button	Meaning
	Click  /  /  /  /  /  /  /  to rotate the dome. Click  to stop rotating the dome.
	Click  /  to zoom in / out the camera image.
	Click  /  to increase / decrease the focal length.
	Click  /  to increase / decrease the iris of the dome.
	Drag the slider to adjust the rotating speed of the dome.
	Click  /  to start / stop recording.
	Click  /  to hide / show the analog joystick.
	Click to return to the live view interface.

### ➤ Analog Joystick Control


The analog joystick on the left side of the interface provides quick PTZ control. The dome or PTZ will rotate when you drag the analog joystick. The farther you drag the analog joystick from the middle of the image, the faster the dome or PTZ rotates. The dome or PTZ will stop rotating when you stop dragging the analog joystick.

### ➤ 3D Control

Click the camera image on any area and then the image will be centered on the clicked point. Refer to the picture as shown below. Drag the mouse from A to B to get a green rectangle and the rectangle area will be zoomed in.



Refer to the picture as shown below. Drag the mouse from C to D to get a green rectangle and the rectangle area will be zoomed out.



### ➤ Advanced 3D Control


Double click the left button of the mouse on any area of the camera image and then the image size will be doubled and centered on the clicked point.

Press and hold the left button of the mouse on any area of the camera image to zoom in the image; press and hold the right button to zoom out the image.


Move the cursor of the mouse to the camera image and then slide the scroll wheel of the mouse forward to zoom in the image, slide the scroll wheel of the mouse backward to zoom out the image.

### ➤ Preset Settings

Click “Preset” to go to preset operation tab and then click “Add” to open the window as shown below. Select the preset and then enter the preset name in the window; finally click “OK” to save the settings.






Adjust the dome’s direction and then click “Save Position” to save the current preset position (you can also click another preset in the preset list and then save the preset position after



adjusting the dome's direction); click  in the preset list to call the preset; click “Delete” to delete the selected preset.



You can also go to preset setting interface for preset setting, see [Preset Setting](#) for details.

### ➤ Cruise Settings

On the right panel, click  to go to cruise operation tab and then click “Add” to open the window as shown below. You can add up to 8 cruises for each dome.





- ① Enter the cruise name in the “Add Cruise” window and then click “Add preset” to open the “Add Preset” window (Before adding preset to the cruise, please add preset of the dome first).
- ② In the “Add Preset” window, select the preset name, preset time and preset speed and then click “OK”.
- ③ In the “Add Cruise” window, you can click  to reselect the preset, then change the preset time and speed. Click  to delete the preset. Click “Add” to save the cruise.

Click  to start the cruise and click  to stop the cruise in the cruise list of the cruise operation tab; click “Delete” to delete the selected cruise.

You can also go to cruise setting interface for cruise setting, see [Cruise Setting](#) for details.


### ➤ Cruise Group Settings


On the right panel, click  to go to the cruise group setting tab. Click “Add” to add a cruise group as shown below.





In the “Add Cruise” window, select the cruise group name. After that, click “Play” to play the cruise groups in sequence.

### ➤ Trace Settings


On the right panel, click  to go to the trace setting tab. Click “Add” to add the trace name. Then click “OK” to save this name. Please refer to the following picture.





After that, click “Start Record” to record the trace. Then click “Stop Record” to finish recording. Click  to play the recorded trace. Click  to delete the trace.

## 6.2 Preset Settings


Click *Start*→*Settings*→*Camera*→*PTZ*→*Preset* to go to the interface as shown below.



### ➤ Add preset

Select camera and then click “Add” to add preset; or click  in the camera list on the right side of the interface to display the preset information of the dome and then click  to add preset. The operations of the “Add Preset” window are similar to that of the PTZ control interface; please see [PTZ Control Interface Introduction](#) for details.

### ➤ Edit preset


Select camera and preset. You can enter the new name of the preset and then click  to save the new preset name. Adjust the rotating speed, position, zoom, focus and iris of the preset and then click “Save Position” to save the preset.

### ➤ Delete Preset



Select camera and preset and then click “Delete” to delete the preset.

## 6.3 Cruise Settings








Click *Start*→*Settings*→*Camera*→*PTZ*→*Cruise* to go to the interface as shown below.





### ➤ Add Cruise

Click  in the camera list on the right side of the interface to display the cruise information of the dome and then click  to add cruise. The operations of the “Add Cruise” window are similar to that of the PTZ control interface; please see [PTZ Control Interface Introduction](#) for details.

### ➤ Edit Cruise


Select the camera and cruise in the “Cruise” interface. Enter the new cruise name and then click  to save the cruise name. Click “Add Preset” to add preset to the cruise. Click  to edit the preset. Click  to delete the preset from the cruise. Click one preset in the preset list and then click  to move down the preset and click  to move up the preset. Click  to start the cruise and click  to stop it.

### ➤ Delete Cruise

Click  in the camera list on the right side of the interface to display the cruise information of the dome and then click  on the top right corner of the cruise to delete the cruise.

## 6.4 Cruise Group Settings

Click *Start* → *Settings* → *Camera* → *PTZ* → *Cruise Group* to go to the interface as shown below.



### ➤ Add Cruise Group

Click “Add Cruise” to add the cruise, or click  to extend the cruise list and then click  to add the cruise. After that, click “Play” on the left panel as shown below to play the cruise lines in sequence.



### ➤ Delete Cruise


In the cruise list, click  to delete the cruise.

## 6.5 Trace Settings



Click *Start*→*Settings*→*Camera*→*PTZ*→*Trace* to go to the interface as shown below.

### ➤ Trace Record



Select the PTZ camera and then click “Add” or extend the IPC information by clicking  and then click  to add a trace name. After that, click “Start Record” and move the speed dome to change its position and set its trace. Then click “Stop Record” to complete the trace record.



### ➤ Play or Stop Trace


Select the trace and click  to play the trace; click  to stop the trace.



### ➤ Delete the Trace

Click  to delete the trace. Or put the cursor on the trace name (right panel) and then  will appear on the right corner of the trace name; click to delete this trace.

## 6.6 Task Settings

Click *Start* → *Settings* → *Camera* → *PTZ* → *Task* to go to the interface as shown below.



- ① Select a PTZ camera.
- ② Select functions, such as preset, cruise, trace, random scanning, etc.
- ③ Select a name, such as preset name, cruise name, etc.
- ④ Select the start and end time.
- ⑤ Click “Add” to add the task.
- ⑥ Click  to extend the tasks of the PTZ camera. Click  beside “Enable” to enable the task. After the task is enabled, the PTZ camera will start the specific task at the specified time.


## 6.7 Smart Tracking Settings

This function is only available for AI PTZ camera. Please add an AI PTZ camera to the NVR for this function to take effect.

**Smart Tracking:** When people or vehicles cross the alarm line or intrude into the predefined area, the PTZ camera can automatically track them, and the target image will be automatically zoomed in and centered on the screen until the target disappears from the screen. After that, the PTZ camera will return to the tracking start position.

To set smart tracking:

1. Click *Settings* → *Camera* → *Smart Tracking* to go to the smart tracking interface.



2. Select the tracking mode and set the “still time” as needed.

**Tracking Mode:** choose “PTZ Auto Tracking Priority” or “Manual PTZ Control Priority”

**PTZ Tracking Priority:** if this mode is selected, after enabling “Trigger track” in one of the following events, you cannot control PTZ by clicking the buttons on the PTZ control panel in the live view interface.


**Manual PTZ Control Priority:** if this mode is selected, after enabling “Trigger track” in one of the following events, you can control PTZ by clicking the buttons on the PTZ control panel in the live view interface during the process of smart tracking. After you stop controlling for 5 seconds, the PTZ camera will return to the pre-defined detection area and start tracking again

when detecting a target.

**Still time:** If it is enabled and the time is set, when the target stops, the PTZ camera will return to the tracking start position after the set time expires. During this time, if the target moves, the PTZ will continue tracking. If it is not enabled, when the target stops for 5 seconds, the PTZ camera will return to the start tracking position.

For example: At the stoplight, if a car is waiting for the red light for 30 seconds, and the still time is set as 20 seconds, the tracking will stop following; however, if the still time is set as 40 seconds, when the red light changes to green and the car starts to move, the PTZ will continue tracking this car.

3. Click **Settings** → **AI/Event** → **AI Event**. Select the AI PTZ camera and the event as needed. For example: Region intrusion.



4. Enable the event, set the rule and then click “Locked”. This button will be changed to “Unlock”. Now the PTZ control panel in the above interface will be activated. Set the detection area by clicking the directional buttons in the above interface. After that, click “Unlock” to lock the detection area.

**Note:** The home position of the PTZ must be locked, or the smart tracking cannot take effect.

5. Click “Draw area” and then draw the area of the region intrusion on the screen.

6. Set the detection target and target size.

7. Check “Trigger Track”.

8. Click “Apply” to save settings. After that, the PTZ can start smart tracking when detecting a target.

## 6.8 Protocol Settings

This series of products support remote configuration of the PTZ protocol of the added IPC.




# 7 Record & Disk Management

## 7.1 Record Configuration

### 7.1.1 Mode Configuration

Please format the HDDs before recording (refer to [Disk Management](#) for details). Click **Start**→**Settings**→**Record**→**Mode Settings** to go to the mode settings interface. You can set the record time under the “Manual Record Settings” and then click “Apply” to save the settings. There are two record modes: auto mode and customization mode.




#### ➤ Auto Mode

**All Events Record:** motion/sensor/intelligent events/target record will be enabled when motion/sensor/intelligent event alarm happens.

**Always (24x7) Record + All Events Record:** Normal record is enabled all the time; motion/sensor /intelligent event/target record will be enabled when motion/sensor/intelligent event alarm happens.

You can add more auto record modes. Click “Customized” to pop up a window as shown below. Check the modes in the window and then click “Add” to show the modes in the record mode list (in the window, the checked modes can be shown in the record mode list while the unchecked modes cannot).



Select the record types as needed.

**Motion Record:** Motion alarm record will be enabled when motion alarm happens.

**Sensor Record:** Sensor alarm record will be enabled when sensor alarm happens.

**Always (24x7) Record:** Normal record is enabled all the time.

**Intelligent Event Record:** Intelligent event record will be enabled when AI event happens.

**Target Record:**

1. When AI events by IPC (targets of these AI events, including people, motor vehicle and/or non-motor vehicle are checked) and motion detection are enabled simultaneously, target record will be triggered upon detection of moving people/motor vehicles/non-motor vehicles.
2. When face detection is enabled, target record will be triggered upon detection of human faces.
3. If no AI event is enabled for all cameras, but the SMD (smart motion detection) of one or more cameras is enabled (people/motor vehicle checked), target record will be triggered when detecting moving people or motor vehicles.
4. When smart motion detection (people/motor vehicle checked) and AI events by IPC (people/motor vehicle/non-motor vehicle checked) are enabled, target record will be triggered upon detection of moving people /motor vehicle.

**Note:** Target record cannot be triggered by AI events by NVR. The third-party IPCs also do not support target record.

**POS Record:** POS contents will be recorded if the POS terminal is triggered.

Select one auto mode for the corresponding window to open. Set the encode, GOP, resolution, FPS, bitrate type, quality, max bitrate and audio of each camera and then click “OK” to save your settings. Please adjust the parameters according to the actual condition.

Always(24x7) Record+All Events Record											
Camera Name	Stream Type	Encode	Resolution	FPS	Bitrate Type	Quality	Max Bitrate	Bitrate Limit	Recommended Range	Audio	GOP
IP01	Main Stream	H.265	2592x1520	25	VBR	Higher	4896Kbps	4480-7468Kbps		ON	50
IP Camera01	Main Stream	H.265	1920x1080	25	VBR	Higher	3872Kbps	2358-3930Kbps		ON	50
IPC	Main Stream	H.265	2592x1944	25	VBR	Higher	5120Kbps	5632-9826Kbps		ON	50

**Video Encode:** the available options will be H.265S, H.265+, H.265 and H.264 depending on what the camera supports.

**Resolution:** the higher the resolution is, the clearer the image is.

**FPS:** the higher the frame rate is, the more fluency the video has, with the tradeoff of using more storage.

**Bitrate Type:** CBR and VBR are optional. CBR means that no matter how much change is seen in the video scene, the compression bitrate will be kept constant. VBR means that the compression bitrate will be adjusted according scene changes. For example, for scenes that do not have much movement, the bitrate will be kept at a lower value. This will help to optimize the network bandwidth.


**Quality:** when VBR is selected, you need to choose image quality. The higher the image quality you choose, the more bitrate will be required.

**Max Bitrate:** 32Kbps ~10240Kbps are optional.

**GOP:** group of pictures.

### ➤ Customization Mode

If the customization mode is selected, you need to set the schedule of AI events record and schedule record for each camera. See [Schedule Settings](#) for details.




In this interface, you can also set the record period of the manual record in the live view interface.


## 7.1.2 Schedule Settings



### ➤ Add Schedule

Click **Start** → **Settings** → **Record** → **Mode Setting** to go to the mode setting interface. Then select “Customization” mode and click “Schedule Management” to set the schedule as shown below. “24×7”, “24×5” and “24×2” are the default schedules; you cannot edit or delete “24×7” while “24×5” and “24×2” can be edited and deleted. Click the schedule name to display the detailed schedule information on the left side of the interface. The seven rows stand for seven days in a week and each row stands for 24 hours in a day. Blue stands for the selected time and gray stands for unselected time.







Click “Add” to add a new schedule. Refer to the picture below.




Set the schedule name and schedule time and then click “Add” to save the schedule. You can set day schedule or week schedule. : add button; : delete button.

### ➤ Set Day Schedule


Click  and then drag the cursor on the time scale to set record time; click  and then drag the cursor on the time scale to delete the selected area.

You can manually set the recording start time and end time. Click  or  and then click “Manual” on each day to open a window as shown below. Set the start and end time in the window and then click “OK” to save the settings.







Click “All” to set all day recording; click “Reverse” to swap the selected and unselected time in a day; click “Clear All” to clear all the selected area in a day.

Click “Copy To” to copy the schedule of the day to other days. Refer to the picture below. Check the days in the window and then click “OK” to save the settings.



### ➤ Set Week Schedule


Click  or  and then click “Manual” beside  to set the week schedule. Refer to the picture below. Set the start and end time, check the days in the window and then click “OK” to save the settings.



Click “All” to set all week recording; click “Reverse” to swap the selected and unselected time in a week; click “Clear All” to clear all the selected area in a week.

### 7.1.3 Advanced Configuration

Click *Start*→*Settings*→*Record*→*Advanced* to go to the following interface. Enable or disable cycle record (cycle record: the earliest record data will be replaced by the latest when the disks are full). Choose the record stream. Set the pre-alarm record time, post-alarm record time and expiration time of each camera and then click “Apply” to save the settings.



**Pre-alarm Record Time:** set the time to record before the actual recording begins.

**Post-alarm Record Time:** set the time to record after the actual recording is finished.

**Expiration Time:** set the expiration time for recorded video. If the set date is overdue, the recorded data will be deleted automatically.

## 7.2 Encode Parameters Settings

Click *Start*→*Settings*→*Record*→*Encode Parameters* to go to the interface as shown below. Set the encode, resolution, FPS, GOP, bitrate type, quality, max bitrate and audio of main stream for each camera in “Event Recording Settings” and “Schedule Recording Settings” interfaces.

Additionally, the record sub stream of each camera can be viewed. Click “Apply” to save the settings. You can set the record stream of each camera one by one or set them in batches for all cameras.


Camera Name	Stream Type	Encode	Resolution	FPS	Bitrate Type	Quality	Max Bitrate	Bitrate Limit Recommendation
IP01	Main Stream	H.265	1920x1080	25	VBR	Higher	2048Kbps	2358-3938Kbps
IP05	Main Stream	H.265	1920x1080	25	VBR	Higher	2048Kbps	2358-3938Kbps
IP03	Main Stream	H.265	1920x1080	25	VBR	Higher	2048Kbps	2358-3938Kbps
IP04	Main Stream	H.265	3840x2160	30	VBR	Higher	5120Kbps	5632-19338Kbps


Remain Bandwidth: 54 / 80 Mb

Apply

## 7.3 Record Mode

### 7.3.1 Manual Recording

**Method One:** Click  on the tool bar at the bottom of the live view interface to enable recording of the camera.

**Method Two:** Go to the live view interface and then click the right-click menu “Manually Record On” in the camera window or click  on the tool bar under the camera window to start recording.

*Note: Click Start → Settings → Record → Mode Settings and then set the manual record time in the interface. Click “Apply” to save the settings.*

### 7.3.2 Timing Recording

**Timing Recording:** the system will record automatically according to the schedule. Set the timing record schedule of each camera. See [Schedule Settings](#) for details.

### 7.3.3 Motion-based Recording

**Motion-based Recording:** the system will start motion-based recording when the motion object appears in the setup schedule. The setup steps are as follows:

- ① Set the motion-based recording schedule of each camera. See [Schedule Settings](#) for details.
- ② Enable the motion and set the motion area of each camera. See [Motion Alarm](#) for details. The camera will start motion-based recording once you finish the above settings.

### 7.3.4 Sensor Based Recording

- ① Set the sensor-based recording schedule of each camera. See [Schedule Settings](#) for details.
- ② Set the NO/NC type of the sensor, enable the sensor alarm and then check and configure the “Record”. See [Sensor Alarm](#) for details.

### 7.3.5 AI Event Recording

- ① Set the analytics recording schedule of each IP camera. See [Schedule Settings](#) for details.
- ② Enable the intelligent alarm detection (object detection, exception, line crossing, intrusion or face detection) and draw alert surface or warning area of each IP camera. See [AI Event Management](#) for details.

The camera will start analytic recording once you finish the above steps. This function is only available for some IPCs.

## 7.4 Disk


### 7.4.1 Disk Management

The HDD can be plugged in or pulled out when the NVR is on. When the HDD is in abnormal status, the abnormal information will be prompted on the screen (such as “No HDD”, “Only read”, “Unformatted”, “The HDD is unavailable”, etc.)

For the model with 8HDDs or more, in order to avoid video frame loss, it is recommended to use 7200RPM HDDs or above and add cameras to different disk groups or create one or more RAIDs (if applicable) to record.

#### ➤ Disk Management

Click **Start** → **Settings** → **Disk** → **Disk Management** to go to disk management interface. You can view the NVR’s disk number and disk status and so on in the interface. Click “Format” to format the HDD.



Data Encryption:

- ① Click “Data Encrypt”.
- ② Enter the username and password used to log into the NVR. This username and password must have the permission of disk management.
- ③ Check the disk you want to encrypt and then enter the password.

After you encrypt the data of a disk, this disk cannot be read by other NVRs unless it is unlocked.

Data Decryption:

- ① Click “Change Encryption”.
- ② Enter the username and password used to log into the NVR. This user must have the

permission of disk management.

- ③ Check the disk you want to decrypt and then clear the password.
- ④ Click “Close Encryption”.


Unlock the disk: when one encrypted disk is transferred from another NVR to this NVR, it will be locked. You can select this locked disk and click “Unlock”. After you enter the password of its data encryption, its status will be “Read Only”. Now you can read the data of this disk but nothing can be written to it.

Some models may not support RAID function. RAID settings are as follows. Please skip the settings of physical disk, array and disk mode if the NVR doesn't support this function. Check the datasheet for your model to confirm if it supports RAID.

➤ RAID


- ① Enable RAID

(Go to *Start*→*Settings*→*Disk*→*Disk Mode*)




- ② Create an array. (Go to *Start*→*Settings*→*Disk*→*Physical Disk*)


- a. Click “Physical Disk” tab and then click “Create an array”.
- b. Enter the user name and password which has the authority of Disk Management. If you don't have one, you can use the user name and password for system login (the default username: admin).
- c. Enter array name and select array type (like RAID5).








d. Select physical disk.

If you have 16 disks, please check 15 disks. The remaining one should be set to a hot spare. If higher data security is needed, you can decrease physic disks and increase hot spare disks. Please set them as needed.




e. Select a hot spare. In the physical disk interface, select the disk that is not in the array and click  as shown in the following pictures.

Disk	Capacity[GB]	Array	Type	Status	Disk Model	Hot Spare
1	931	test	Array disk	Normal	xxxxxx	
2	931	test	Array disk	Normal	xxxxxx	
3	931	test	Array disk	Normal	xxxxxx	
4	931		Ordinary plate	Normal	xxxxxx	




- RAID Rebuilding

If one of your disks is defective, the disk indicator on the front panel will turn red. A warning tip will pop up if the relevant HDD exception alarm is set. You need to rebuild the RAID after you replace the broken disk with a new one.

Disk Management							
Physical Disk		Array		Disk Mode			
No.	Name	Capacity[GB]	Physical Disk	Hot Spare Position	Status	Type	Rebuild
1	test	1862	2 3	4	Downgrade	RAID5	

Click the above circled icon and then select the physical disk to rebuild.



**Note:** If the HDD you want to install has been used in a RAID of another device, it is recommended to install it after the device starts up. Having installed the HDD, you can set it as a hot spare disk or add it to a new RAID. If you have installed the HDD in shutdown state, the RAID you have created before is unavailable after the device runs. Now, you need to reboot your device to solve this problem.

- RAID Migration

After the NVR is restored to the factory default settings, you can restore RAID here.

If a NVR fails to work and you need to read the RAID data stored on it, you can perform a RAID migration by following the steps below.

1. Power off the fault device (A). Then remove all the disks that form the RAID array from Device A.

**Note:** Ensure that the RAID array on Device A is in a normal working state before removal.

2. Power on Device B. Complete the basic configuration settings and enable the RAID function.

The device will automatically restart after the function is enabled.

**Note:** Ensure the time on Device B is configured accurately. If the current time on Device B is earlier than that on Device A, the video recording data may be erased.

3. After Device B restarts, install all the disks removed from Device A to it. Navigate to the Physical Disks interface, where you can confirm that all installed disks are online.


**Note:** If the number of online disks is incorrect or any disk shows an abnormal status, contact the relevant technical support personnel for assistance.

4. Go to the Physical Disks interface and click “Restore Array” to restore the recording data.


**Note:** If the button is not available, it indicates that Device B already contains existing RAID configuration information. Please use another new device and repeat the process starting from Step 1.

## 7.4.2 Storage Mode Configuration


Click *Start* → *Settings* → *Disk* → *Storage Mode* to go to the interface as shown below.




By using disk group, you can correspond a camera to disk (the record data of the camera in the group will be stored into the disks in the same group). The NVR with e-SATA interface supports e-SATA recording.


The added disks and cameras will be added into group one automatically. The disks and cameras in the groups can be deleted except group one (select a disk group and then click  on the top right corner of the added disk or camera to delete it from the group). The deleted disks and cameras will be moved into group one automatically.

Each group can add disks and cameras from other groups. Each disk and camera can only be

added into one group. Select a disk group and then click  in the disk or camera row to open a window. Check the disks or cameras in the window and then click “Add”.

For the model with 2 or 4 HDD slots, BK group can be added as shown below.



Click  to add the backup HDD. After account verification, select a HDD and then this HDD will be removed from the normal group to the backup group. Simultaneously, it will be formatted. Please back up all data of this HDD in advance when you want to remove it to the backup group.

You can add cameras to this HDD. The added cameras can exist and be recorded both in one HDD of the normal group and the backup group.

**Note:** Each HDD only can exist in one group.

### 7.4.3 View Disk Information

Click *Start* → *Settings* → *Disk* → *View Disk Information* to view the HDD information; click “S.M.A.R.T. Information” to view the working status of the HDD (refer to the picture below); click “Health Status Check” to check the western digital purple disks’ health status.



View Disk Information		S.M.A.R.T. Information		Health Status Check		
Disk	Disk1					
Disk Serial No.	Z3T8QMCM					
Disk Model	ST500DM002-1BD142					
Temperature	46					
Power-on Time (day)	758					
S.M.A.R.T. Status	In good health					
ID	Attribution	Value	Worst Value	Threshold	Raw Value	Status
0x01	Read Error Rate	109	99	6	22129616	Normal
0x03	Spin-Up Time	100	97	0	0	Normal
0x04	Start/Stop Count	88	88	20	12317	Normal
0x05	Reallocated Sector Count	100	100	36	0	Normal
0x07	Seek Error Rate	80	60	30	658989752	Normal
0x09	Power-On Hours	80	80	0	18179	Normal
0x0a	Spin Retry Count	100	100	97	0	Normal
0x0c	Power Cycle Count	99	99	20	1345	Normal
0xb7	SATA Downshift Error Count	90	90	0	10	Normal
0xb8	End-to-End error	100	100	99	0	Normal
0xbb	Reported Uncorrectable Errors	97	97	0	3	Normal
0xbc	Command Timeout	100	100	0	0	Normal
0xbd	High Fly Writes	100	100	0	0	Normal

In addition, you can view the plug-in or pull-out details of the HDD from the logs to check whether someone moves your HDD or not. Click **Start** → **Settings** → **System** → **View Log**.

View Log		Factory Default		Upgrade		Backup and Restore		Auto Maintenance		
Main Type	All	Alarm	Operation	Settings	Exception					
Start Time	2021/01/04 00:00:00		End Time	2021/01/06 23:59:59		<input type="button" value="Search"/>	<input type="button" value="Export"/>			
No.	Main Type	Log Time	Content	Details	Play					
1	Operation	2021/01/06 18:13:50	LocalMaintenance	Log Search						
2	Operation	2021/01/06 18:13:45	LocalInsert a new HDD	Disk2(Z3T6S6BE)						
3	Exception	2021/01/06 18:13:44	HDD is pulled out	Disk1(Z3T6S6BE)						
4	Exception	2021/01/06 18:13:43	Disk IO Error	Disk1(Z3T6S6BE) IO Error						



## 8 Playback & Backup


### 8.1 Instant Playback

Click  on the tool bar at the bottom of the preview camera window to play back the record (click  on the tool bar at the bottom of the live view interface to set the default playback time). Refer to the picture below. Drag the playback progress bar to change the playback time. You can also click the right-click menu “Instant Playback” in the camera window and then set the instant playback time to play back the record.



### 8.2 Playback Interface Introduction







Click  on the tool bar at the bottom of the live view interface or click **Start→Playback** to go to the playback interface as shown below (click  on the tool bar at the bottom of the live view interface to set the default playback time).


























The panel on the right will show you the channel number and the recorded data coded by color. The bar that runs across them represents the playback time being viewed. You can move this bar around. To export, highlight a section of the desired recording, click export and follow the prompts. You can export single or multiple channels at the same time.



The added cameras will playback their recordings in the playback interface automatically. You can also add the playback camera manually. Click **+** in the playback window to open the “Add Camera” window. Check the cameras in the window and then click “Add” to add playback camera. The system supports a maximum of 16 synchronous playback cameras.


The buttons on the tool bar (area ①) at the bottom of the playback interface are introduced in the table below.

Button	Meaning
	Start button. Click to pop up area ②.
	Full screen button. Click to show full screen; click again to exit the full screen.
	Screen display mode button. 1/4/9/16 screen display mode can be selected (depending on models); in addition, the playback channel will be switched by continuous selection of the same screen display mode, for example, after selecting 1-screen display mode, click this mode again and then the current playback channel will switch to the next playback channel.
	OSD ON button. Click to enable OSD; click again to disable OSD.
	Quick channel selection button
	Stop button.












Button	Meaning
	Rewind button. Click to play video backward.
	Play button. Click to play video forward.
	Pause button.
	Slow Play button. Click to decrease the playing speed.
	Fast Play button. Click to increase the playing speed
	Normal speed. Click to restore the normal speed after fast forwarding or rewinding.
	Previous frame button. It works only when the forward playing is paused in single screen mode.
	Next frame button. It works only when the forward playing is paused in single screen mode.
	Select the time, for example 30s, and click  to step backward 30s
	Select the time, for example 30s, and click  to step forward 30s.
	PicSearch (See PicSearch for details)
	Click to enter the rules search interface
	Play strategy button. You can enable “Play filtered recording only”.
	 Tag button. Click to view the tag information.
	 Watermark button. Click to enable watermark; click it again to disable watermark.
	 Open/close POS information
	 Backup status button. Click to view the backup status.
	 Backup button. Drag the mouse on the time scale to select the time periods and cameras, and then click the button to back up the record.
	 In 1-screen/4-screen display mode, select it to display target box and rule lines.
	Back button. Click to return.

Introduction of area ②:



Button	Meaning
 Intelligent Analytics	Click to go to the intelligent analytics interface.
 Search and Backup	Click to go to record search and backup interface; see <a href="#">Record Search, Playback &amp; Backup</a> for details.

Button	Meaning
 Live Display	Click to go to the live view interface; see <a href="#">Live View Introduction</a> for details.

Click on the playback window to show the tool bar as shown in area ③; right click on the window to show the menu list. The tool bar and menu list are introduced in the table below.

Button	Menu List	Meaning
	--	Move tool. Click to move the tool bar anywhere.
	<b>Enable Audio</b>	Click to enable audio. You can listen to the camera audio by enabling audio.
	<b>Snap</b>	Click to take a snapshot.
	<b>Zoom In</b>	Click to go to the zoom in interface. The zoom in interface is similar to that of the camera window in the live view interface. Click  to pause the record playing; click  to play the record. When the record is paused in forward playing mode, you can click  to view the previous frame and click  to view the next frame.
	<b>Add Tag</b>	Click to add tag. You can play back the record by searching the added tag. Click and then enter the tag name in the popup window. Click “Add” to add tag.
	<b>Switch Camera</b>	Click to switch the playback camera. Click it and then check the camera in the popup window. Click “OK” to change the camera.
	<b>Close Camera</b>	Click to close the playback camera.

Introduction of area ④:


Click  to set the date; click  to set the time and then the playback camera will play the record from the time you set.


There are two types of playback: Normal Playback and Event Playback.


- Normal Playback


Normal playback is the default playback type. In normal playback mode, you can play the recorded videos by filtering people or vehicles. The record time scale shows different record types with different colors. Light blue stands for AI record based on people/vehicle; Blue stands for other records (without people/vehicle classification).


- Event Playback:







Click  as shown above and select events.




In event playback mode, you can choose different event type as needed. All events are selected by default. Select the desired event type (for example, general events, AI Event). Click  to select the detailed event and view the color meanings. Different event types have different colors. In addition, you can choose view records by event or by category.

Finally, click  in the playback window to add camera for playback (the record time scale will show the record data of the checked record type only after the above operations).



Introduction of the record time scale (area ⑤):


A tool bar will appear after moving the mouse to the record time scale. Click  /  to zoom the timeline; click  to recover the timeline to 24 hours' ratio. Drag the timeline or slide the scroll wheel of the mouse on the time scale to show the hidden time on the top or bottom of the timeline. You can also click  to show the hidden time on the top of the

timeline or click  to show the hidden time on the bottom of the timeline. Drag the slider at the bottom of the time scale to show the hidden playback cameras.

The record time scale shows different record types with different colors. Click the record block to set the time and then the playback camera will play the record from the time you set.

### Backup Introduction:


Insert the storage device into the device. Drag the color block on the time scale to select the backup area and then right click the area or click  and select  to pop up a backup information window. Click the “Backup” button in the window to pop up the backup window. Select the device, backup path and backup format and then click the “Backup” button.



In the backup window, you can select backup path and format. Then click “Backup”.


Backup format: Private, AVI or MP4.

Please select “Encryption” or “No Encryption” as needed. After that, click “OK”.





After that, you can click “More” and select the “Backup Status” to view the backup progress.

Delete the video record of backup disk group






In the playback interface, click  to select the backup disk group. Then use the left mouse button to drag on the timetable to select the records you want to delete. Then right click and select [Delete] to delete it.

### 8.3 Rules Playback


In the playback interface, click  to go to the smart playback interface as shown below.




The descriptions of buttons in the smart playback interface


Button		Description
		Full screen motion button.
		Draw grid. You can search the record of motion detection in the pre-defined area.
		Draw line. You can search the record of crossing the line after drawing the line.
		Draw quadrilateral. You can search the record in this quadrilateral after drawing it.

- **Smart Playback by Drawing Grid**


Click  and draw a rectangle in the desired area. The system will automatically search the record files of this area. The cyan blocks indicate that there are intelligent recording files. Move the cursor to such block and click to play the recording.

- **Smart Playback by Drawing Line**

Click  and draw a line in the desired area. Then the system will automatically search for the record files where this line was crossed. The cyan blocks indicate that there are intelligent recording files. Move the cursor to such block and click to play the recording.



- **Smart Playback by Drawing Quadrilateral**

Click  and draw a quadrangle in the desired area. Then the system will automatically search the record files of this area. The cyan blocks indicate that there are intelligent recording files. Move the cursor to such block and click to play the recording.




## 8.4 Record Search, Playback & Backup


The record data and the captured pictures can be backed up through the network or USB (U disk or USB mobile HDD). The file system of the backup devices should be FAT32 format.

### 8.4.1 Search, Playback & Backup by Time-sliced Image

① Click **Start**→**Search and Backup**→**By Time-sliced Image** to go to “By Time-sliced Image” tab. There are two view modes: by time and by camera. In the time view mode, a maximum of 64 camera thumbnails can be shown. If the camera thumbnail number is more than 64, the cameras will be listed directly by their camera name, not the thumbnail. A maximum of 196 camera names can be listed. If the camera names exceed 196, the time view mode will be disabled and only the camera view mode will be available.




- ② Select one camera in the interface and then click the “Open” button.
- ③ Click the image box to play the recording in the small playback box on the left side of the interface (the box which has image inside indicates that the recording data exists).
- ④ Refer to the picture below. Drag the color blocks on the time scale to select the recording data and then click the “Backup” button to open the “Record Backup” window as shown below. Select the device name, backup format and path and then click the “Backup” button to start the backup.



*Note: If you back up the record in private format, the system will back up a RPAS player to USB device automatically. The private format record can be played by RPAS player only.*

- ⑤ Click “Playback” to play the record in the playback interface (refer to [Playback Interface Introduction](#) for details). Click “Close” to close the interface.



**Time Slice Search:**


**Method One:** Click “Year”, “Month” or “Day” button under the record time scale to select the time slice mode. In “Day” mode, click ◀ / ▶ on the left/right side of the time scale to view the record of the last/next day; click “Minute” in the “Picture” option under the time scale to select “Minute” mode (in “Minute” mode, click the time scale to change the time of the 60 display windows) and click “Hour” to select “Hour” mode.

**Method Two:** Click ▶ beside “Camera Thumbnail” on the left top corner of the interface to select the time slice mode.

**Method Three:** Right-click the mouse on any area of the time-sliced interface to go back to the upper interface.

**8.4.2 Search, Playback & Backup by Time**


- ① Click **Start** → **Search and Backup** → **By Time** to go to “By Time” tab as shown below.
- ② Click **+** on the bottom of the interface to add playback camera. A maximum of 16 cameras can be added for playback. Click “Modify” on the top right corner of the camera window to change the camera and click “Clear” to remove the camera.
- ③ Click the camera window to play the recording in the small playback box on the left side of the interface. You can set the date on the top left of the interface, check the event type as needed and click the time scale or click **🕒** under the time scale to set the time. The camera window will play the recording according to the time and event type you set.
- ④ Drag the color blocks on the time scale to select the record data (or click “Set Backup Time” on the bottom left corner of the interface to set the backup start time and end time) and then click “Backup” for record backup. Click “Playback” to play the recording in the playback interface. Click “Delete” to delete the selected record file.



### 8.4.3 Search, Playback & Backup by Event

Some models may support searching POS event.

- 1 Click **Start** → **Search and Backup** → **By Event** to go to “By Event” tab as shown below.



- 2 Check the event type in the interface as needed.
- 3 Click to set the start time and end time on the top left of the interface. Click to filter events. Click next to “Type” to select “People” or “Motor Vehicle” to show motion (people) or (motor vehicle) as shown below. If “None” is selected, all events will be searched except motion (people) or (motor vehicle).

Note: Only the camera with SMD function has the data of motion (people/vehicle)

classification).

No.	Camera Name	Type	Time Period	Duration	Data Size	Playback	Backup
1	IP Camera01	Motion	2025/03/17 04:57:04-2025/03/17 04:57:45	41s	11MB		
2	IP Camera01	Motion	2025/03/17 04:57:47-2025/03/17 04:58:33	46s	13MB		
3	IP Camera01	Motion	2025/03/17 04:58:53-2025/03/17 04:59:45	52s	14MB		
4	IP Camera01	Face Dete...	2025/03/17 04:59:07-2025/03/17 05:00:04	57s	15MB		

- ④ Check cameras on the left side of the interface or check “All” to select all the cameras and then click to search the record. The searched record will be displayed in the list.
- ⑤ Click in the list to play back the record in the popup window. Click to back up one record data or check multiple record data in the list and then click “Backup” for record batch backup.
- ⑥ Select one record data in the list and then click “Playback” to play the record in the playback interface.

### 8.4.4 Search & Playback by Tag

Only if you add the tags can you play the record by tag search. Click **Start→Playback** to go to the playback interface and then click on the bottom of the camera window to add tag when you want to mark the playback time point of the selected camera. Click **Start→Search and Backup→Tag Management** to go to “Tag Management” tab.

No.	Name	Camera Name	Time	Playback	Edit	Delete
1	IP06_20181126160423	IP01	11/26/2018 08:04:23			
2	IP07_20181126160430	IPC256	11/26/2018 08:04:30			

Click in the interface to play the record. Click to edit the tag name. Click to delete the tag.







### 8.4.5 Image Management


Click **Start→Search and Backup→Image Management** to go to “Image Management” tab. The system will display all the snapped images automatically in the list.

No.	Camera Name	Snapshot Mode	Snapshot Time	Creator	Browse	Export	Delete
<input type="checkbox"/>	1	IP Camera01	Motion	2021/07/08 10:54:22	IP Camera01		
<input type="checkbox"/>	2	IPC	Motion	2021/07/08 10:54:21	IPC		
<input type="checkbox"/>	3	IP Camera02	Motion	2021/07/08 10:54:15	IP Camera02		


Click to delete the image. Click to open the “Export” window. Select the device

name and save path in the window and then click the “Save” button.

Click  to pop up the “View Image” window. Click  to export the image. Click  to view the previous image; click  to view the next image; click  to delete the image; click  to play all the images.



#### 8.4.6 View Backup Status

Click *Start*→*Search and Backup*→*Backup Status* or click  on the tool bar at the bottom of the playback interface to view the backup status.

# 9 AI Event Management

## 9.1 Face Recognition

Only some models support alarm trigger based on face comparison. Some models under AI mode support face comparison (For enabling the AI mode, please refer to [Enabling AI Mode](#)). If your device doesn't support face recognition function, please skip the face database and face recognition instructions.


The following are instructions on how to set up the Face Recognition function for the first time:

Set face detection and alarm linkage → Add face group → Add faces to the face group → Enable and set successful recognition (or stranger) alarm linkage → Set successful recognition (or stranger) alarm linkage

### 9.1.1 Face Detection Settings

**Face Detection:** Alarms will be triggered if someone intrudes into the pre-defined alarm areas.

① Click *Start* → *Settings* → *AI/Event* → *AI Event* → *Face Recognition* → *Detection* to go to the following interface.



② Select the camera, check “Enable Detection by IPC” and set the duration.

**Note:** 1. Some models may support face detection by NVR under AI mode (For enabling the AI mode, refer to [Enabling AI Mode](#)).

After enabling detection by NVR, click “Intelligent Configuration” to view the details of PicSearch as shown below.



You can view which cameras have AI enabled by the NVR.


AI by Camera: Enable AI function by camera.

AI by NVR: Enable AI function by NVR.

PicSearch (AI by Camera): “Face Detection” and/or “Video Metadata” of the desired cameras must be enabled, or the picture comparison function is not available.

**Note:** Only when the PicSearch function is enabled, can PicSearch be available.

2. Some AI cameras support event type classification. If the event type is not face event, you need to select face event by clicking **Start** → **Setting** → **AI/Event** → **Enable Event**. After the camera restarts, face detection of the IPC can be enabled.




③ Set the schedule. Click “Manage” to set the desired schedule. Please refer to [Schedule Settings](#) for details.

④ Set the snapshot interval and snapshot number. The snapshot interval refers to the time interval that the camera captures the same face during its continuous tracking period. The snapshot number refers to the picture number of the same face captured during its continuous tracking period (For example: the snapshot interval is set to “30 seconds” and the snapshot number is set to “3”; then the camera will capture the same face once every 30 seconds and it will capture this face 3 times at most during its continuous tracking period).

⑤ Enable face match exposure as needed. When the brightness of the captured face is not enough, it can be enabled. (Only some IPCs support this function)

⑥ Set the alarm area. Drag the mouse to draw a detection area. Click “Clear” to delete the alarm area. Then set the detectable face size by defining the maximum value and the minimum value (The default size range of a single face image occupies from 3% to 50% of the entire image).



- ⑦ Enable “Original picture” or/and “Target picture” as needed. If enabled, the system will automatically save the corresponding images on the SD card.
- ⑧ Click “Apply” to save the settings.
- ⑨ Click “Trigger Mode” to go to face detection alarm linkage setting interface:




### Face Detection Alarm Linkage Configuration:

- Trigger “Voice Prompt”, “Record”, “Snapshot”, “Push”, “Alarm-out”, “Preset”, “Buzzer”, “Pop-up Video”, “E-mail”, and “IP Speaker” as needed.

**Voice Prompt:** Please upload the audio file in local audio alarm interface first (click **Start**→**Settings**→**AI/Event**→**Event Notification**→**Audio**). Please see [Audio](#) for details.

**Record:** Click the “Configure” button to open the window. Select a camera on the left side and then click  to set the camera as the trigger camera. Select a trigger camera on the right side and then click  to cancel the trigger camera. Click “OK” to save the settings. The trigger cameras will record automatically when faces are detected.

**Alarm-out:** Click the “Configure” button to open the window. Then the “Trigger Alarm-out” window will pop up automatically. Configure the local alarm output, IPC alarm output (if supported) or relay alarm output (if supported) in the window as needed. The system will trigger the alarm-out automatically when faces are detected. You need to set the delay time and the schedule of the alarm outputs. See [Alarm-out](#) for details.

**Preset:** Click  and then select the preset for each camera. To add presets, please see [Preset Setting](#) for details.

**Snapshot:** If it is enabled, the current camera will capture images automatically when faces are detected.

**Push:** If it is enabled, the system will send messages when faces are detected.

**Buzzer:** if it is enabled, the system will begin to buzz when faces are detected. To set the delay

time of the buzzer, please see [Buzzer](#) for details.

**Pop-up Video:** if it is enabled, the system will open the corresponding video automatically when faces are detected. To set the duration time of the video, please see [Display](#) for details.

**E-mail:** if it is enabled, the system will send an e-mail when faces are detected. In the meanwhile, it will attach the captured face picture and the original picture so that you can view the whole scene when the alarm occurs. Before you enable the email, please configure the recipient's e-mail address first (see [E-mail Configuration](#) for details).


**IP-Speaker:** After you add IP speaker to the NVR and link the corresponding camera, you can select the IP speaker to play the selected local audio file. See [IP Speaker Management](#) for IP speaker adding and camera linkage. See [Audio](#) for local audio import setup.

Enable “IPC\_Audio” or “IPC\_Light” as needed (only some IPCs support these two functions). To set the IPC voice and its times and volume, please refer to [Audio](#) for details. To set the light flashing time and frequency of the IPC, please refer to [Light](#) for details.

⑩ Click “Apply” to save the settings.

### 9.1.2 Face Database Management


① Click **Start**→**Settings**→**AI/Event**→**AI Event**→**Face Recognition**→**Face Database** to go to the following interface as shown below.



For the first time, you can click “+” or “Add Group” to add groups.

② To add targets for each group.


- Select a list and then click  to expand the list as shown below.



- Click “Add” and then click “Select Face” to add face images. You can add faces from snapshot gallery or external faces.


**Adding faces from snapshot gallery:** Select search time or self-define the search time and then click “Search” to search target faces. Then select the desired faces and click “Select”.

**Note:** The picture marked with a green icon can be added to the face database. Those pictures can’t likely have resolution issues.



### Add external faces

Save the face pictures on your USB storage device and then insert the USB storage device into the USB port of the NVR.


Go to the face database interface. Click  to expand the group and then click “Add”. Select “External faces” to select face pictures. You can select one face to add or multiple faces to add.

To add multiple faces: a. put face pictures and the description file (.csv or .txt) to one specific folder (please edit the detailed descriptions of these pictures according to the personal information description); b. click “All” to select all face pictures; c. click “Full Entry”.

**Note:** the added image must be less than 70KB and the image format shall be “.jpg” and “.jpeg”.

- After that, add the corresponding information, like name, gender, birthday, ID number, phone number and so on.

Having saved the target image, click the image and then the detailed information will be listed on the right.




- Import and Export Face database

Insert your mobile storage device into the USB interface of the NVR and then click “Import and Export” to import or export the face database settings.


The exported face database file (csv+jpg) can be directly imported to the face database to make it very convenient for you to transfer one NVRs face database file to other NVRs.

### 9.1.3 Face Recognition Settings

After the face database and face pictures are added, click “Face Recognition” to return to the face recognition setting interface. Click the “Recognition” tab to go to the following interface.




- ① Enable “Successful Recognition” or “Stranger”. Click “Parameter Settings” to set the similarity of the matching face group.



Disable live display: if checked, the live view interface (target detection tab) will not display captured faces in real time.


- ② Set the alarm linkage items for successful recognition.
- Select one or more face groups and then choose the schedule. Click “Manage” to set the schedule.
  - Set the text prompt and voice prompt. When the captured face is matched successfully, the text will appear on the right of the live view interface and broadcast the audio.
  - Enable alarm output pulse (access control) as needed. Should you wish to enable alarm output pulse, you must configure the corresponding alarm output of NVR/IPC (you can choose the alarm output of NVR or IPC according to the actual application scenario). Once a human face is successfully matched, the pulse signal will be sent via the corresponding alarm output.
  - Trigger record, snapshot, alarm-out, buzzer, push, pop-up video, E-mail, pop-up message box, and IP speaker as needed. The alarm linkage settings are similar to the face detection alarm (see [Face Detection Settings](#) for details).

If access control devices are added to the NVR, you can also trigger door unlocking as needed. If an access control device has multiple locks, you can select them as needed. When a human face is successfully matched, the relevant door will be opened automatically.



- Click “Apply” to save the settings.

③ Set the stranger alarm linkage items. When the captured face picture doesn’t match the face pictures in the face database or their similarity is lower than the set value, the captured person will be regarded as a stranger.



- Configure the schedule
- Set the text prompt and voice prompt. The text will show on the captured picture and the voice will be broadcasted when detecting a stranger.
- Trigger record, snapshot, alarm-out, buzzer, push, pop-up video, E-mail, Preset, pop-up message box, and IP speaker as needed. The alarm linkage settings are similar to the face detection alarm (See [Face Detection Settings](#) for details).
- Click “Apply” to save the settings.

④ Click “+” to add more successful recognition tasks. Select the added task and then click “-” to delete it.

## 9.2 License Plate Recognition


Please add an ANPR camera before you use this function. If your camera doesn't support this function, please skip the following instructions.

When setting up an LPR for the first time, please use the following procedures:

Enable and set plate detection → Add plate group → Add plates to the plate group → Enable license plate recognition → Set successful recognition (or strange plate) alarm linkage

### 9.2.1 License Plate Detection Settings

Click **Start** → **AI/Event** → **AI Event** → **LPR** to go to the following interface. Select an ANPR camera and click the “Detection” tab as shown below.



- Set the schedule.
- Set the area and plate exposure as needed.
  - Set the alarm area. Drag the mouse to draw a detection area. Click “Clear” to delete the alarm area.
  - Set the blocked area. Select the number and then draw a blocked area. Up to 4 areas can be set up. After you set the blocked area, this area will not be detected.
  - Click “Display all area” to view all blocked and detection areas.
  - Click “Clear All” to clear all blocked and detection areas.
- Check “Capture plate absence vehicle” as needed.
- Set the plate size by defining the maximum value and the minimum value (The default size range of a single plate occupies from 5% to 50% of the entire image).
- Display range: if enabled, the set maximum detection box and the minimum detection


box can be displayed on the left window.

- Click “Advanced” to set the recognition mode as needed (only some LPR cameras support).


## 9.2.2 Plate Database Management


In the LPR interface, click the “Plate Database” tab to go to the plate database management interface as shown below.

For the first time, you can click “+” or “Add Group” to add groups.





### Add plates to each group:

- ① Click  to extend the group. Click “Add Plate” to display the following window.




- ② Enter the plate, vehicle owner, valid entering/exiting time and mobile phone number.
- ③ Select the vehicle type and group.
- ④ Finally, click “OK” to complete.

Select the added plate and then click  to modify its information; click  to delete this plate. The plates can be imported and exported in bulk by clicking “Import and Export”. You

can click “Plate Information Description” to view the detailed information about how to import or export the plate list.


### 9.2.3 License Plate Recognition Settings

- ① In the LPR interface, click the “Recognition” tab. Then enable “Successful Recognition” or “Strange Plate”.



- ② Set the successful recognition alarm linkage.
  - Select one or more plate groups and then choose the schedule. Click “Manage” to set the schedule.
  - Set the text prompt. When the captured plate is matched successfully, the text will appear on the right of the live view interface.


Enable alarm output pulse (access control). Enable alarm output pulse (access control) as needed. Should you wish to enable alarm output pulse, you must configure the corresponding alarm output of NVR/IPC (you can choose the alarm output of NVR or IPC according to the actual application scenario). Once a license plate is successfully matched, the pulse signal will be sent via the corresponding alarm output. Take the NVR with four alarm outputs for example: The gate can connect with one of 4 alarm outputs. Configure Alarm-out, choose the alarm out that is connected by the gate. When the license plate is detected in front of the gate, the gate should open immediately.



- Trigger record, snapshot, alarm-out, buzzer, push, pop-up video, E-mail, pop-up message box, and IP speaker as needed. The alarm linkage settings are similar to the face detection alarm (See [Face Detection Settings](#) for details).
- ③ Set the strange plate alarm linkage. When the captured plate picture doesn't match the plates in the plate database or their similarity is lower than the set value, the captured plate will be regarded as a strange plate.

## 9.3 Perimeter Detection

### Note:


1. Some models may support perimeter detection (line crossing, region intrusion/entrance/exiting) by NVR under AI mode (For enabling the AI mode, refer to [Enabling AI Mode](#)).
2. Some AI cameras support event type classification. If the event type is face event, you need to select  by clicking **Start**→**Setting**→**AI/Event**→**Enable Event**. After the camera restarts, perimeter detection of the IPC can be enabled.

### 9.3.1 Line Crossing Detection

#### Tripwire/Line Crossing Detection Configuration:

Alarms will be triggered if the people or vehicles cross the pre-defined alarm line.

- ① Click **Start**→**Settings**→**AI/Event**→**AI Event** →**Perimeter Detection**→**Line Crossing** to go to the following interface.



② Select the camera, enable line crossing detection by IPC and set the duration (alarm holding time).

**Note:** Some models may support line crossing detection by NVR.

③ Set the schedule and trigger mode (only some cameras support the trigger mode setting). Trigger Mode: “Moving object” or “All objects” can be selected. If “Moving object” is selected, alarms will be triggered when an object is crossing over the alarm line; if the object stops moving on the alarm line, the line crossing alarm stops too. If “All objects” is selected, alarms will be triggered when an object stops on the alarm line or crosses over the alarm line.

④ Select the direction.

**Direction:** A<->B, A->B and A<-B optional. It is the crossing direction of the target that crosses over the alert line.

**A<->B:** the alarm triggers when the target crosses over the alert line from B to A or from A to B.

**A->B:** the alarm triggers when the target crosses over the alert line from A to B.

**A<-B:** the alarm triggers when the target crosses over the alert line from B to A.

⑤ Draw line. Refer to the interface as shown above. Drag the mouse in the image to draw an alert line. Click the “Clear” to delete the alert line.

⑥ Set the event-triggered sensitivity (only some cameras support the event-triggered sensitivity).

**Event Triggered Sensitivity:** It refers to the percentage of the body part of an object that goes across the alarm line. The higher the value of sensitivity is, the more easily the alarm can be triggered.

⑦ Set target size. Check “Display range” and then select target. Enter the width and height value to set the size; click the set min./max. box and then four dots will be shown at the four corners of the min./max. box. Now, drag any one dot to change the min./max. box size; drag

one of the four lines of the min./max box to change its position. Note that only some IPCs support target size settings. If the added camera doesn't support this function, please skip this step.


- ⑧ Click “Detection Target” to choose the detection target and the target detection sensitivity. The detection target includes people, motor vehicles and non-motor vehicles. Target Detection Sensitivity: The higher the value is, the easier the alarm can be triggered by targets.
- ⑨ Click “Advanced” to choose “Save original picture” or “Save target picture” on the SD card of the camera. (If your camera doesn't support this function, please skip this step).
- ⑩ Click the “Trigger Mode” tab to configure line crossing alarm linkage items.
  - The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).
  - Enable “IPC\_Audio” or “IPC\_Light” as needed (only some IPCs support these two functions). To set the IPC voice and its times and volume, please refer to [Audio](#) for details. To set the light flashing time and frequency of the IPC, please refer to [Light](#) for details.
- ⑪ Click “Apply” to save the settings.

### 9.3.2 Region Intrusion Detection

#### Region Intrusion Detection Configuration:

Alarms will be triggered if the people or vehicles intrude into the pre-defined area.

- ① Click **Start→Settings→AI/Event →AI Event→Perimeter Detection→Region Intrusion** to go to the following interface.
- ② Select the camera, enable region intrusion detection by IPC and set the duration.  
**Note:** Some models may support region intrusion detection by NVR.
- ③ Set the schedule and trigger mode (only some cameras support the trigger mode setting).  
Trigger Mode: Choose “Moving object” or “All objects” as needed. If “Moving object” is selected, alarms will be triggered when an object intrudes into the pre-defined area; if the object stops moving on the alarm line, the region intrusion alarm stops too. If “All objects” is selected, alarms will be triggered when an object keeps still on the alarm line or intrudes into the pre-defined area.
- ④ Select the alarm area. Up to 4 alarm areas can be set up. Draw the alarm area of region intrusion detection. Refer to the interface as shown below. Click around the area where you want to set as the alarm area in the image (the alarm area should be a closed area).



**Note:** Some thermal network cameras support blocked area settings (a maximum 4 block areas can be set).

⑤ Set the event-triggered sensitivity (only some cameras support the event-triggered sensitivity).

**Event Triggered Sensitivity:** It refers to the percentage of the body part of an object that enters the alarm area. The higher the value of sensitivity is, the more easily the alarm can be triggered.

⑥ Set target size. Please refer to [the target size setup of line crossing](#) for details. Note that only some IPCs support target size settings. If the added camera doesn't support this function, please skip this step.

⑦ Click “Detection Target” to choose the detection target and the target detection sensitivity. The detection target includes people, motor vehicles and non-motor vehicles.

**Target Detection Sensitivity:** The higher the value is, the easier the alarm can be triggered by targets.

⑧ Click the “Trigger Mode” tab to configure intrusion detection alarm linkage items.

- Trigger “Record”, “Snapshot”, “Push”, “Alarm-out”, “Preset”, “Buzzer”, “Pop-up Video” “E-mail” and “IP Speaker” as needed. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).

- Enable “IPC\_Audio” or “IPC\_Light” as needed. (only some IPCs support these two functions). To set the IPC voice and its times and volume, please refer to [Audio](#) for details. To set the light flashing time and frequency of the IPC, please refer to [Light](#) for details.

⑨ Click “Copy To” to copy all settings to other cameras.

⑩ Click “Apply” to save the settings.

### 9.3.3 Region Entrance Detection

**Region Entrance:** Alarms will be triggered if the target enters the pre-defined areas.

Click *Start* → *Settings* → *AI/Event* → *AI Event* → *Perimeter Detection* → *Region Entrance*. The setup steps are the same as Region Intrusion. See [Region Intrusion Detection](#) for details.

### 9.3.4 Region Exiting Detection

**Region Exiting:** Alarms will be triggered if the target exits from the pre-defined areas.

Click *Start*→*Settings*→*AI/Event*→*AI Event* →*Perimeter Detection*→*Regional Exiting*. The setup steps are the same as Region Intrusion. See [Region Intrusion Detection](#) for details.

## 9.4 Abandoned/Missing Object Detection

① Click *Start*→*Settings*→*AI/Event*→*AI Event*→*More*→*Object Abandoned/Missing* to go to the following interface.

② Set the schedule.


③ Select the camera, enable the object detection and set the duration and detect type. There are two detection types: Abandoned object and missing object.

**Abandoned object:** Alarms will be triggered if there are items left in the pre-defined detection area.

**Missing object:** Alarms will be triggered if items are missing in the detection area drew by the users.

④ Select the alarm area and area name. A maximum of 4 alarm areas can be set.

⑤ Draw the alarm area of the object detection. Refer to the interface as shown below. Click around the area where you want to set as the alarm area in the image (the alarm area should be a closed area). Click the “Clear” to delete the alarm area.



⑥ Click “Trigger Mode” to configure abandoned/missing object detection alarm linkage items. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).

⑦ Click “Apply” to save the settings.


## 9.5 Crowd Density Detection

Only some IPCs may support this function.

### Crowd Density Configuration:

Alarms will be triggered if the crowd density exceeds the set threshold value in the pre-defined area.

① Click **Start**→**Settings**→**AI/Event**→**AI Event**→**More**→**Crowd Density** to go to the following interface.



② Select the camera, enable crowd density detection and set the schedule, duration, refresh frequency and alarm threshold.

**Refresh Frequency:** Refers to the refresh time of the detection result report.

**Alarm Threshold:** Alarms will be triggered once the percentage of the crowd density in a specified area exceeds the pre-defined threshold value.

③ Select the alarm area. Draw the alarm area for the crowd density detection. Refer to the interface as shown above. Drag the mouse to draw a rectangle area. Click the “Clear” to delete the alarm area.

④ Configure crowd density detection alarm linkage items. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).

⑤ Click “Apply” to save the settings.

## 9.6 Target Counting by Line


Only some IPCs may support this function.

- **People/Motor Vehicle/Non-Motor Vehicle Counting**

The information of people/motor vehicle/non-motor vehicle can be calculated and sent by day, by week and by month, so that you can receive and analyze these statistics on time.

Only some IPCs support this function. If your camera doesn't support this function, please skip the following instructions.

① Click **Start**→**Settings**→**AI/Event**→**AI Event**→**More**→**Target Counting by Line** to go to the following interface.



② Enable target counting by line and set the duration and time threshold(s).

**Duration:** it is the time that the alarm extends after an alarm ends.

**Time Threshold:** The duration time that the number of targets exceeds the staying threshold. Alarms will not be triggered even if the targets staying in the specified area exceed the threshold within the set delay alarm duration. But if you set it to "0", alarms will be triggered immediately when the targets staying in the specified area exceed the threshold.

③ Set the schedule.

④ Select the direction and drag the mouse on the small window to draw the crossing line. Click "Clear" to delete the alert line.

**Direction:** A->B and A<-B are optional. It is the crossing direction of the target that crosses over the alert line.

⑤ Set target size. Please refer to [the target size setup of line crossing](#) for details. Note that only some IPCs support target size settings. If the added camera doesn't support this function, please skip this step.

⑥ Set the detection target and target detection sensitivity. The detection target including people, motor vehicle and non-motor vehicle.

**Target Detection Sensitivity:** The higher the value is, the easier the alarm can be triggered by targets.

⑦ Click "Advanced" to open a window. You can select "Original picture" or "Target picture",

and set reset information manually or enable “Auto Reset” as needed.

In the above interface, you can send Email to a specified person on a daily/weekly/monthly basis regarding the target counting. Click “Add” to add the recipient”, and then enable “Send Email” and select “Send mode” and time.


- ⑧ Click “OSD Overlay” to set the OSD information. If enabled, the statistical information will be displayed on the live view interface.
- ⑨ Configure the alarm linkage items for target counting. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).
- ⑩ Click “Apply” to save the settings.

## 9.7 Target Counting by Area

Only some IPCs may support this function.

This function is used to detect, track and count the number of people or vehicles intruding into a pre-defined area.

- ① Click *Start* → *Settings* → *AI/Event* → *AI Event* → *More* → *Target Counting by Area* to go to the following interface.




- ② Enable target counting by area and set the duration and time threshold(s). The setting steps are similar to target counting by line.
- ③ Set the schedule.
- ⑪ Draw the area. Refer to the interface as shown above. Click around the area where you want to set as the counting area in the image (the area should be a closed area).
- ④ Set target size. Please refer to [the target size setup of line crossing](#) for details. Note that only some IPCs support target size settings. If the added camera doesn't support this function, please skip this step.
- ⑤ Set the detection target and target detection sensitivity. The detection target includes people, motor vehicles and non-motor vehicles.  
Target Detection Sensitivity: The higher the value is, the easier the alarm can be triggered by targets.
- ⑥ Click “Advanced” to open the following window. You can select “Original picture” or “Target picture”, and set reset information manually or enable “Auto Reset” as needed.
- ⑦ Click “OSD Overlay” to set the OSD information. If enabled, the statistical information will be displayed on the live view interface.
- ⑧ Configure the alarm linkage items for target counting. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).
- ⑨ Click “Apply” to save the settings.

## 9.8 Exception Detection

### Exception Detection Configuration:

- ① Click *Start*→*Settings*→*AI/Event*→*AI Event*→*More*→*Exception Detection* to go to the following interface.




- ② Select the camera and detection duration and then enable the relevant detection as needed.
  - Scene Change:** Alarms will be triggered if the scene of the monitor video has changed.
  - Video Blurred:** Alarms will be triggered if the video becomes blurry.
  - Video Color Cast:** Alarms will be triggered if the image is abnormal caused by color deviation.
- ③ Set the sensitivity of the exception detection.
- ④ Click “Trigger Mode” to configure exception alarm linkage items. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).
- ⑤ Click “Apply” to save the settings.

## 9.9 Fire Detection

Only when the security thermal cameras are connected, can the fire detection be available. Please note this is only intended as a supplement to official fire detection methods and should not be relied on as a primary alert source.

Fire Detection: Alarms will be triggered when the camera detects a fire source through the thermal imaging.

- ① Click *Start* → *Settings* → *AI/Event* → *AI Event* → *More* → *Fire Detection* to go to the following interface.



② Set the schedule and the alarm duration time.

③ Set the sensitivity and time threshold.

Some models may support fire point detection or flame detection.

**Sensitivity:** the higher the value is, the easier a fire can be detected, but the false rate is higher. Please adjust the sensitivity as needed.

**Time threshold:** For example: set it to “2 seconds”; Alarms will be triggered when the fire source is detected for 2 seconds, or alarms will not be triggered.

④ Set the block area as needed. A maximum of 4 block areas can be set. (Only some thermal network cameras support this function).

⑤ Click “Trigger Mode” to configure alarm linkage items. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).


⑥ Click “Apply” to save the settings.

## 9.10 Temperature Detection

Only when the security thermal cameras are connected, can the temperature detection be available.

Temperature Measurement: When a temperature of the pre-defined point/line/area exceeds the temperature threshold value, alarms will be triggered.

① Click *Start* → *Settings* → *AI/Event* → *AI Event* → *More* → *Temperature Detection* to go to the following interface.



② Set the schedule, the alarm duration time, temperature unit and distance.

③ Set the block area as needed. A maximum of 4 block areas can be set. (Only some thermal network cameras support this function).

④ Overlay temperature information on stream.

**Thermal/optical:** if enabled, the temperature information will overlay on the video stream.

When playing the live video or the recorded video, you can view the temperature information.

⑤ Advanced settings. Click “Advanced” on the top right corner.

**Temperature Bar:** if enabled, a color reference temperature bar will appear on the right of the thermal image.

**Enable Temp Reading by Clicking:** if enabled, you can read the real-time temperature of any point you click on the thermal image in the single channel display mode.

**Emissivity:** Set the emissivity of the target. The emissivity of each object is different.

**Distance:** The distance between the target and the camera.

**Reflected temperature:** If there is any object with high emissivity in the scene, set the reflective temperature to correct the ambient temperature. The reflective temperature should be set the same as the temperature of the high emissivity object.

**Highest temperature:** if checked, the Max. Temperature in the set area/line will be displayed in real time.

**Average temperature:** if checked, the Avg. Temperature in the set point/area/line will be displayed in real time.

**Lowest Temperature:** if checked, the Min. Temperature in the set area/line will be displayed in real time.

⑥ Set thermography rule. Select the rule type, including Point, Line and Area.

Set the point, line or area on the small window.

**Point setup:** After the type is set to “Point”, click on the image to set the point. Up to 10 points can be set in the above interface.

**Line setup:** After the type is set to “Line”, drag the mouse on the image to draw a line. To ensure the accuracy of temperature measurement, it is recommended to set not more than two lines at the same time.

**Area setup:** Click around the area where you want to set as the alarm area on the image (the

alarm area should be a closed area). To ensure the accuracy of temperature measurement, it is recommended to set not more than two areas at the same time.

Set the alarm rule, alarm temperature and alarm output. For example, select Alarm Rule as Above (Average Temperature), set the alarm temperature to 100°C and check alarm output. Alarms will be triggered when the average temperature of the target is higher than 100°C.

- ⑦ Click “Trigger Mode” to configure alarm linkage items. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).
- ⑧ Click “Apply” to save the settings.

## 9.11 Audio Exception

Only some IPCs support this function. If the camera you added doesn't support this function, please skip the following instructions.

**Audio Exception:** Alarms will be triggered when the abnormal sound is detected in the surveillance scene, such as the sudden increase/decrease of the sound intensity.

- ① Click *Start*→*Settings*→*AI/Event*→*AI Event*→*More*→ *Audio Exception* to go to the following interface.

The screenshot displays the 'Audio Exception' configuration window. At the top left, there is a checked 'Enable' checkbox. Below it are two tabs: 'Parameter Settings' (active) and 'Trigger Mode'. The main area is divided into two columns. The left column features a 'Real time audio' graph with a y-axis from 0 to 100. It shows three data series: 'Sound Intensity' (red line), 'Background Sound Intensity' (blue line), and 'Sound Intensity Threshold' (green line). The right column contains several settings: a 'Schedule' dropdown set to '24x7' with a 'Manage' button; a 'Rule' dropdown set to '20 Secs'; two checkboxes for 'Sudden Increase of Sound Intensity Detection' and 'Sudden Decrease of Sound Intensity Detection'; and three 'Sensitivity' sliders, all currently set to 50.

- ② Set the schedule and alarm duration.

**Sudden Increase of Sound Intensity Detection:** Detect sudden increase of sound intensity. If enabled, sensitivity and sound intensity threshold are configurable. Alarms will be triggered when the detected sound intensity exceeds the sound threshold.

**Sensitivity:** The higher the value is, the easier the alarm will be triggered.

**Sound Intensity Threshold:** It is the sound intensity reference for the detection. The lower the value is, the easier the alarm will be triggered. It is recommended to set the average sound intensity in the environment. The louder the environment sounds, the higher the value should be. Please adjust it according to the actual environmental condition.

**Sudden Decrease of Sound Intensity Detection:** Detect sudden decrease of sound intensity. Please set the sensitivity as needed. The higher the value is, the easier the alarm will be triggered.

**Real-time audio graphic:**

Red wavy line stands for the current detected sound intensity.

Navy blue line stands for the environment (background) sound intensity.

Green line stands for the sound intensity threshold.

In order to reduce false alarms, it is recommended to set the sensitivity and sound intensity threshold according to the real-time audio graphic.

③ Click “Trigger Mode” to configure audio exception alarm linkage items. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).


④ Click “Apply” to save the settings.

## 9.12 Loitering Detection

Only some IPCs support this function. If the camera you added doesn't support this function, please skip the following instructions.

Loitering Detection: when someone entering and loitering in a pre-defined area exceeds the threshold, alarms will be triggered until the object leaves this area.

① Click *Start*→*Settings*→*AI/Event*→*AI Event*→*More*→*Loitering Detection* to go to the following interface.



② Set the schedule, duration, time threshold and target detection sensitivity. (Some cameras support trigger mode setup)

**Target Detection Sensitivity:** The higher the value is, the easier the alarm can be triggered.

**Time Threshold:** the time that a person is allowed to stay in the area. If a person staying in the specified area exceeds the threshold, alarms will be triggered until this person leaves.

For example: Trigger mode is set to “Moving object” and the threshold is set to “60seconds”; when a person staying and moving in the specified area exceeds 60seconds, an alarm is triggered and continues unless the person leaves this area.

**Trigger Mode:** Choose “Moving object” or “All objects” as needed. If “Moving object” is

selected, alarms will be triggered when a person staying and moving in the specified area exceeds the threshold. If “All objects” is selected, alarms will be triggered when a person keeping still or moving in the specified area exceeds the threshold.


- ③ Set the alarm area. Up to four alarm areas can be set. Click around the area where you want to set as the alarm area in the image (the alarm area should be a closed area).
- ④ Set target size. Please refer to [the target size setup of line crossing](#) for details. Note that only some IPCs support target size settings. If the added camera doesn't support this function, please skip this step.
- ⑤ Click “Trigger Mode” to configure loitering detection alarm linkage items. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).
- ⑥ Click “Apply” to save the settings.

### 9.13 Illegal Parking Detection

Only some IPCs support this function. If the camera you added doesn't support this function, please skip the following instructions.

Illegal Parking Detection: when a vehicle (like a car, truck, motorcycle, etc.) staying in a no-parking zone exceeds the threshold, alarms will be triggered until the vehicle is driven away.

- ① Click *Start* → *Settings* → *AI/Event* → *AI Event* → *More* → *Illegal Parking Detection* to go to the following interface.



- ② Set the schedule, alarm duration and time threshold.

**Duration:** it is the time that the alarm extends after the overstaying vehicle leaves.

**Time Threshold:** the time that a vehicle is allowed to stay in the specified area. If a vehicle staying in the area exceeds the threshold, alarms will be triggered until it is driven away. For example, the time threshold is set to 30s. When the system detects a vehicle stopping in the set

no-parking zone, it will start counting. Alarms will be triggered after it stays for more than 30s. And the illegal parking alarm will not stop until the vehicle is driven away from the non-parking zone.

③ Set the event-triggered sensitivity (only some cameras support the event-triggered sensitivity).

**Event Triggered Sensitivity:** It refers to the percentage of the body part of an object that enters the alarm area. The higher the value of sensitivity is, the more easily the alarm can be triggered.

④ Set the alarm area. Up to four alarm areas can be set. Click around the area where you want to set as the alarm area in the image (the alarm area should be a closed area).

⑤ Set target size. Please refer to [the target size setup of line crossing](#) for details. Note that only some IPCs support target size settings. If the added camera doesn't support this function, please skip this step.

⑥ Select the detection target and set the target detection sensitivity. The detection target includes "Motor vehicle" and "Non-motor vehicle".

**Target Detection Sensitivity:** The higher the value is, the easier the alarm can be triggered by targets.


⑦ Click "Trigger Mode" to configure exception alarm linkage items. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).

## 9.14 People Counting

Only some IPCs support this function. If the camera you added doesn't support this function, please skip the following instructions.

**People Counting:** This function is to calculate the number of the people entering or exiting from the detected area through detecting, tracking and counting the head shapes of the people.

① Click *Start* → *Settings* → *AI/Event* → *More* → *People Counting* to go to the following interface.



- ② Enable people counting and click “Advanced” to set the SD card storage information and the reset information.

**Original picture:** If it is enabled, the detected original pictures will be captured and saved to the SD card when the staying threshold exceeds the set value.

**Auto Reset:** The current number of the people counting can be reset. You can choose to reset the counting daily, weekly or monthly. Click “Reset” to manually reset the current number of people counting.

- ③ Set detection rule. Two detection rules can be selected. Please select one of them as needed.

● **To set alarm line**

Set the alarm line number and direction. Only one line can be added.

**Direction:** A->B and A<-B can be optional. The direction of the arrow is entrance.

Drag the mouse in the image to draw a line. Click the “Clear” button to delete the line.

Click the “Apply” button to save the settings.

If the target crosses the line along the direction of the arrow, it is counted as one entering target. If the target crosses the line along the reverse direction of the arrow, it is counted as one exiting target.

● **To set detection area**

Select the area number and direction.

**Direction:** A->B and A<-B can be optional. For example: “A->B” is selected. If the target enters from area A to area B, it is counted as one entering target. If the target enters from area B to area A, it is counted as one exiting target.

Click the “Draw A Area” or “Draw B Area” button and then click around the area where you want to set as the detection area in the image on the left side (the area should be a closed area).

Click the “Stop Draw” button to stop drawing. Click the “Clear” button to delete the alarm area. After both area A and B are set and make sure these two areas don’t overlap, click the “Save” button to save the settings.

**Target Detection Sensitivity:** The higher the value is, the easier the false detection will occur. The lower the value is, the camera is easier to miss the target.

**Staying Threshold:** When the targets staying in the specified area exceed the threshold, alarms will be triggered.

- ④ Set the camera calibration. Auto calibration and manual calibration are selectable.

● **Auto Calibration**

Select “Auto” and draw a box in the middle of the image. After that, click “Calibrate”. The camera will return the lens height automatically. Compare the returned lens height with the actual measurement height. If the height from the lens to the ground is within 4m, the margin of error within  $\pm 15\text{cm}$  is allowed. If the height from the lens to the ground is 4m ~6m, the margin of error within  $\pm 25\text{cm}$  is allowed. If exceeding the above-mentioned value, repeat the above steps or use manual calibration.

 **Caution:**

- ✓ Please select the flat ground as the calibration area.
- ✓ The calibration area with adequate and even light is recommended, avoiding overexposure area or reflective surface.

✓ Please select the middle of the image as the calibration area.

- **Manual Calibration**

Manually measure the height from the lens to the ground.

Select “Manual”, enter the lens height value and click “Calibrate”.

⑤ **OSD overlay.** If disabled, the statistical information will not be displayed in the live view interface.

Check “Display OSD” and move the red OSD to change the position of the statistical information displayed on the screen. The statistical OSD information can be customized as needed.

Children counting: Please set its name as needed. Before using this function, please enable children counting and set the height of children counting first

⑥ Height filtering settings.

**Height Filtering:** Enable the function and set a height value. The target whose height is lower than the set value will not be counted.

**Children Counting:** Enable the function and set a height value. The target whose height is higher than the set value will not be counted.

**Note:** In order to get more accurate statistics, it is suggested to disable height filtering and children counting if the installation height of the camera ranges from 210 to 250cm. When the installation height of the camera ranges from 251~600cm, it is recommended to check height filtering and children counting.


⑦ Click “Apply” to save the settings.

## 9.15 Heat Map

Only some IPCs support this function. If the camera you added doesn't support this function, please skip the following instructions.

Heat Map is to display the flow distribution of people/vehicles in pre-defined areas by different colors.

① Click *Start* → *Settings* → *AI/Event* → *More* → *Heat Map* to go to the following interface.




- ② Set the schedule.
- ③ Select the area. Up to 4 alarm areas can be set up. Click around the area where you want to set as the detection area in the image (the detection area should be a closed area).
- ④ Set target size. Please refer to [the target size setup of line crossing](#) for details. Note that only some IPCs support target size settings. If the added camera doesn't support this function, please skip this step.
- ⑤ Choose the detection target and set the target detection sensitivity. The detection target includes people, motor vehicles and non-motor vehicles.

## 9.16 People Gathering Detection

People Gathering Detection: It detects the people density in a pre-defined area. If the people density exceeds the set sensitivity (percentage) for over the set time threshold, alarms will be triggered.

- ① Click **Start** → **Settings** → **AI/Event** → **More** → **People Gathering** to go to the following interface.



- ② Set the schedule, duration and time threshold.

**Sensitivity:** the sensitivity is related to the local density. The higher the value is, the easier the alarm can be triggered.

**Time threshold:** When the people density in the pre-defined area exceeds the percentage of the sensitivity for over the set time threshold, alarms will be triggered.

③ Select the alarm area. Up to 4 alarm areas can be set up. Draw the alarm area of region intrusion detection. Refer to the interface as shown below. Click around the area where you want to set as the alarm area in the image (the alarm area should be a closed area).


④ Configure the alarm linkage items for target counting. The alarm linkage settings are the same as the face detection alarm (see [Face Detection Settings](#) for details).

## 9.17 Video Metadata

Only some IPCs support this function. If the camera you added doesn't support this function, please skip the following instructions.

**Video Metadata:** People, motor vehicle and non-motor vehicle in the video can be classified, counted and captured and the relevant features can be extracted and displayed on the live interface.

① Click **Start**→**Settings**→**AI/Event**→**AI Event**→**Video Metadata** to go to the following interface.



② Enable video metadata and then set the schedule.

③ Set the detection area and blocked area.


**Detection Area:** 4 detection areas can be set. Targets that enter the pre-defined detection area will be counted and captured.

**Blocked Area:** 4 blocked areas can be set. Targets that enter the pre-defined blocked area will not be counted and captured.

**To set detection area:** Select the number and then set the detection area. Then click around the area where you want to set as the alarm area on the image (the alarm area should be a closed area).

**To set blocked area:** Select the number and then set the blocked area. The setting steps are the same as detection area settings.

- ④ Advanced settings. Click “Advanced” to enter the advanced setting interface. Select SD card storage type and the reset information. Auto reset or manual reset can be set as needed.
- ⑤ Set target size. Please refer to [the target size setup of line crossing](#) for details. Note that only some IPCs support target size settings. If the added camera doesn’t support this function, please skip this step.
- ⑥ Set the detection target and target detection sensitivity.
- ⑦ Select the attribute information of the target. Click “Image Overlay” to select the attributes of people/motor vehicle/non-motor vehicle.



For people, you can select the above attribute information.

For Motor Vehicle, color, type and brand can be selected.

For Non-motor Vehicle, only type can be selected.

When a target is detected, the information you select will be displayed beside the captured image.

- ⑧ Click “Apply” to save the settings.



# 10 Intelligent Analytics


## 10.1 Target Detection View

Only some models support target detection view. If your device doesn't support it, please skip the following instructions.







### 10.1.1 People/Vehicle Detection View

Only when the camera supports people/vehicle detection, can you view the real-time captured pictures of people or vehicles. The setting steps are as follows:

- ① Enable the Line crossing/Region Intrusion/Region Entrance/Region Exiting/Loitering Detection/Target counting/Video Metadata function of IPCs/NVR, draw the line or area and choose the detection target (see the corresponding sections for details).
- ② Go to live view interface and then click  to go to the target detection interface of this channel. In this interface, you can switch the channel on the top right. You can also click  on the top right corner of the live view interface and then choose the target detection tab to go to the target detection interface of multi-channel as shown below. Note that only some models support multi-channel target detection function. Click the captured picture on the right of the live interface to see the snapshot detailed information.





In the above detail window, you can view captured people/vehicle pictures, original picture, snapshot time, camera, event type, target type, etc. Move the mouse to the detailed image window. The target snapshot will be shown on the left/right top of the detail window and “Previous/Next” will appear. Click “Previous/Next” to view the previous/next snapshot. Click

 to perform PicSearch (only human face/body supports PicSearch). See PicSearch for details. Click  to go to the people/vehicle search interface; click  to export the captured original picture and target picture; click  to go to the playback interface; click  to view the target ID information; click  to exit the detail window.


### 10.1.2 Face Detection/Match View




Only the face recognition NVR supports the following functions. If your NVR doesn't support them, please skip the following instructions.


The setting steps are as follows:


- ① Enable face detection function (see [Face Detection Settings](#) for details).
- ② Enable face recognition function and set the alarm linkage items (see [Face Recognition Settings](#) for details).
- ③ Go to live view interface and click on a face detection channel. This will bring a toolbar under the channel. Then click  to go to the target detection interface of this channel. In this interface, you can switch the channel on the top right. You can also click  on the top right corner of the live view interface and then choose the target detection tab to go to the target detection interface of multi-channel as shown below.

**Note:** Multi-channel target detection function is only available for some models.




For unknown faces, you can select this face and click  under the captured face to register this face (see the following picture); click  to quickly go to the smart face search interface where you can search the matching facial information; click  to quickly go to the







smart face playback interface; click  to view snapshot details.




Before registering face pictures, please add groups for them in advance (see [Face Database Management](#) for details).

After the face pictures are registered, the system will compare them automatically the next time the corresponding faces are captured.



Click a captured face picture to see the snapshot details, such as snapshot picture, original picture, snapshot time and camera. Click  to register the current snapshot; click  to perform PicSearch; click  to go to face search interface. Click  to go to the playback interface. Click  to export this snapshot picture and the original picture; click  to view target ID and face score; click  to exit the detail window.

In the face match interface, click “Settings” to open the following window.




**Target Detection Display:** Face, people, vehicle, plate or fire point can be enabled. If disabled, the captured target picture will not be displayed under the target detection tab in the live view interface.

**Display Strategy:** Two options: Comparison priority and only comparison

#### Video Overlay Display:

If “Target box” is clicked, you will see the target traced by a little red box.

If “Rule Line and Area” is checked, you will see the rule line of line crossing detection and detection area of intrusion detection displayed on the screen. You can select the color of the rule line and area as needed.



When a captured face picture is successfully recognized, click the picture on the right to open a face detail window as shown above. In this window, you can see the captured face picture, the matched picture from face library and the relevant information. You also can view the original image, search image by snapshot, play back by snapshot and export the face details, etc.

Additionally, you can view the history of captured face pictures and face match information in


the face match interface by clicking “History” tab. Besides registering face pictures in the live view interface, you can also add target face pictures in the face database interface.


**Note:** if you enter a remark when adding a face picture to the face database, the remark information (instead of the person’s name) will be shown under the picture after a successful recognition.

### 10.1.3 License Plate Detection/Recognition View

Only when the ANPR camera is added and enabled, can license plates be captured and matched. The setting steps are as follows

- ① Enable the plate detection function (See [License Plate Detection Settings](#) for details). Then you can see the captured plates displayed in the live view interface as shown below.




Put the cursor on the captured plate picture and then click  to register this plate as shown below.

Click to view the captured detail information. Click to quickly enter the vehicle search interface. You can search the matched plate information in this interface. Click to go to the smart playback interface.

② Enable license plate recognition function and set the alarm linkage items (see [License Plate Recognition Settings](#) for details).

③ Go to live view interface and click on the top right corner of the live view interface and then choose the target detection tab to go to the target detection interface of multi-channel as shown below. When a plate is captured, it will be displayed on the right panel. A strange plate will show “Strange plate” under the plate picture.






Click the captured plate picture and then it will open a detailed information window. You can view the snapshot picture, original picture, snapshot time, camera, vehicle attributes, etc. Click the corresponding buttons to search/register/export/playback/view the ID information of the target.

### 10.1.4 Object Attribute View

① Enable video metadata function and then select the detection target and display attributes

(see [Video Metadata](#) for details).

② Go to live view interface and click on an AI camera channel (which supports video metadata function). This will bring a toolbar under the channel. Then click  to go to the target detection interface of this channel. In this interface, you can switch the channel on the top right. You can also click  on the top right corner of the live view interface and then choose the target detection tab to go to the target detection interface of multi-channel. Click “Settings” at the bottom right to select the attribute information of people/motor vehicle/non-motor vehicle/plate you want to view under the captured picture.





Click the captured picture to view the details. In the detail interface, you can view the captured picture, original picture, object attributes, etc.

## 10.2 Smart Search

### 10.2.1 Face Search

Only some models support this function. If your device doesn't support it, please skip the following instructions.

- ① Click **Start** → **Intelligent Analytics** → **Search** → **People** → **Face** to go to the following interface. Set the time and date by clicking the Today tab.
- ② Choose face detection cameras.
- ③ Click  to add the target face which can be searched and added from recent, face database snapshot gallery and external faces. A single face picture or multiple face pictures can be added and searched. (Taking a single face picture for example)



To add a single target face from recent faces

- a. Choose the face.
- b. Click “Select”.

To add a single target face from the face database:



- a. Click “More” to choose groups.
- b. Select a target face and click “Select”.

To add a single target face from the snapshot gallery:


- a. Select time and click “More” to choose cameras.
- b. Click “Search”.
- c. Check a face and click “Select”.

To add a single target face from external faces:


- a. Save the target face to the mobile storage device and then insert this device into the USB interface of NVR.
- b. Select “External Face” to import the face in this interface.

After the picture is selected, you can modify or delete the added picture. Put the cursor onto the picture and click  to change another picture; click  to delete the picture.


- ② Set similarity and then click “Search”.













③ You can view the face comparison result after search. Click “Sort” to search the match picture by similarity or time. Click the searched picture to view the face details.




In the above interface, you can view the people information and target events. In the target events list, click the capture picture to play the record in the small window. Or click “Record” to play.



You can set the playback time and perform the corresponding operations as needed. Descriptions of the buttons on the small playback window

Button	Description
	Stop
	Click to choose the play speed.
	Click to step backward 30s
	Click to step forward 30s
	PicSearch, see PicSearch for details
	Click to close smart information (for example: click it to close the face detection box)
	Click to enable audio
	Click to view the POS information
	Click to back up.
	Full screen button. Click to show full screen; click it again to exit the full screen.


**Note:** if you search face picture without adding a face picture, you only can view the face pictures based on face detection as shown below.



④ Select the searched image and click “Backup” to back up the selected pictures. Click “Backup All” to backup all pictures you have searched. Click “Playback” to go to the playback interface.





## 10.2.2 Track

Select “Track” to go to the following interface.





**Note:** Tracking will only work if two or more cameras have viewed and recorded the subject.

Descriptions of buttons on the track interface

	Start/Stop Track
	Edit Map
	Edit Color
	Click to view the detailed position information


Click on a camera name and then an event list appears. Click one item to play the recording.



Before playing the track, you need to add a map first. Click  button to go to the following interface.




Click “Load Map” to add a map. Then drag the camera names onto and around the map to change their locations. Choose a color from the left color list to set your favorite color for camera names.

Load Map: ① Save the map to the USB storage device and then insert the USB storage device into the NVR. ② Click “Load Map” button to upload the map.


Click  button to modify the colors of camera names and track lines and set the line width.

Click  on the right of the track interface to play the track video. Click  to return to the map track interface.

### 10.2.3 Face Search by Snapshot

In the live or playback interface, click on a face detection camera and then select  on the

toolbar. This will bring the following window.




Drag the mouse to select a face and then click “Search by Face” to go to the face search by face interface. You can see its snapshot pictures, match pictures, original pictures and so on by clicking the corresponding tab.

### 10.2.4 People Search

Click *Start* → *Intelligent Analytics* → *Search* → *People* → *People* to go to the people search interface.

Select the search time, camera and then click “Search” to view the searched pictures.



## 10.2.5 Human Attribute Search

Click **Start** → **Intelligent Analytics** → **Search** → **People** → **Attribute** to go to the human attribute search interface. You can select the attributes of people to filter (like gender, age, mask-wearing status, glasses-wearing status, color of clothes, etc.). Note that only the searched camera with video metadata function can filter attributes.

Click a searched picture to view the details (including target events, snapshot picture and records).

## 10.2.6 Vehicle Search

Click **Start** → **Intelligent Analytics** → **Search** → **Vehicle** to go to the vehicle search interface. You can search motor vehicles, non-motor vehicles and plates separately.

- **Motor Vehicle/Non-motor Vehicle Search**


Select the time, camera, and attribute. Then click “Search” to search vehicles.

Attributes of motor vehicles: including color, brand or type.

Attributes of non-motor vehicles: you can select the type as needed.

Note that only the searched camera with video metadata function can filter attributes.

You can view vehicle pictures by time or by camera.



Click a searched vehicle picture to view its details on the left. You can view the picture and play the records as needed.

- **Plate Search**

Click the “Plate” tag and select the time, camera to search vehicles. You can also enter the plate number to search the plate pictures. Then you can view the track of this vehicle.




Click “Track” to view the track of the vehicle.

**Note:** Only one plate can be traced at a time and two or more ANPR cameras must have detected this vehicle to create a track to follow.

The track setting steps are similar to the face track setup steps. Please refer to face track settings for details.

### 10.2.7 Event Search

Click *Start* → *Intelligent Analytics* → *Search* → *Event* to go to the event search interface. You can search for people or vehicles by events.



Click a searched picture to view the details (including target events, snapshot picture and records).

## 10.2.8 PicSearch

Only some models support PicSearch. If your device doesn't support this function, please skip the following instructions.

Some models under AI mode support PicSearch (For enabling the AI mode, refer to [Enabling AI Mode](#)).


The PicSearch function extracts pictures of human face or body from a video scene during live view or playback, then compares the extracted picture with recorded videos, and eventually finds out videos that contain the target.

**Note:** Before using the PicSearch function, you need to enable PicSearch first (See [the note of PicSearch](#) for details). In addition, face detection and/or video metadata of the relevant cameras must be enabled.


If you want to extract pictures of human face via PicSearch, the face detection function of the relevant cameras must be enabled (See [Face Detection](#) for details).

If you want to extract pictures of human body via PicSearch, the video metadata function of the relevant cameras must be enabled (See [Video Metadata](#) for details).


- PicSearch via Live View

1. In the live view interface, click on a human face/body detection channel and then you can view  on the toolbar of the interface. Click it and then you can view its single channel image which is still.


2. Click this button and then the human face/body frame can be viewed. If the human face and body can be detected simultaneously, you can view the human face and body frames at the same time as shown below.



3. Move the cursor to the face frame or human body frame, a PicSearch button will appear. Click this button to jump to the PicSearch interface.




4. If the results are not satisfied, you can adjust the time range, channel or similarity to search again.


5. Click a searched picture, you can view its original picture and recorded video on the right, and export the picture and video as needed. After searching, click  to exit.


#### ● PicSearch via Playback

You can perform PicSearch during normal, event or rules search playback as needed. The PicSearch method is similar to the PicSearch via Live View.



- PicSearch via Target Detection


In the live view interface, select a human face/body picture under the target detection tab to display the following detail window. Click  to identify the human face or/and face as shown below.





Move the cursor to the face frame or human body frame, a PicSearch button will appear. Click this button to jump to the PicSearch interface.

- PicSearch via Smart Search

In the smart search interface (*Start* → *Intelligent Analytics* → *Search* → *People* → *Face*), click the searched human face/body picture.




Click  to extract the following picture. Move the cursor to the face frame or human body frame, a PicSearch button will appear. Click this button to jump to the PicSearch interface.



### 10.3 View Statistical Information

Click **Start** → **Intelligent Analytics** → **Statistics** to go to the following interface. Through this interface, you can view the statistical information for people and vehicles, and you can customize the statistical information.



View People Information:


**Note:** The person information includes face information and figure information.

- ① Select the time.
- ② Select cameras.
- ③ Select events as needed, such as face detection, face recognition, region intrusion, region entrance, region exiting, loitering detection, line crossing, target counting, etc.

**Note:** Face recognition events (successful recognition & stranger) are available for some models. If Face Recognition-Successful Recognition event is selected, you can choose “Detail Chart” to view.

View Vehicle Information:

- Click “Vehicle”
- Select “Vehicle”, “No-motor Vehicle” or “Plate” as needed.
- Select the time and cameras.
- Select events as needed.




If “Plate” is selected and “Remove duplicate license plate numbers” is checked, the duplicate statistics of the same license plate in the same day will not be displayed in the chart.

## 10.4 Enabling AI Mode

Only some models support this function.

For these models, the IP camera without AI function added to the NVR may realize AI functions, like face detection, line crossing and region intrusion by enabling AI mode in the NVR. If AI mode is enabled, the secondary output will be disabled for some models. If AI mode is not enabled, AI by NVR, face comparison and PicSearch will not be available.

Click **Start** → **Intelligent Analytics** → **Engine Configuration**.




# 11 General Event Management

## 11.1 Sensor Alarm

To ensure complete setup of the Sensor Alarm function, you should enable the sensor alarm of each camera and then immediately set up the alarm handling for that camera.

- Click **Start**→**Settings**→**AI/Event**→**General Event**→**Sensor** to go to the following interface.





In the above interface, you can configure the local sensors, sensors connected to the IPCs, virtual alarm and relay alarm input as needed.

- Select the alarm type (NO or NC) according to trigger type of the sensor.
- Enable the sensor alarm of each camera and select the schedule.
- Check the “Duration”, “Record”, “Snapshot”, “Push”, “Alarm-out” and “Preset” and enable or disable the “Buzzer”, “Pop-up Video”, “Pop-up Message Box” and “E-mail” as needed.
- Click “Apply” to save the settings.

The configuration steps of the above-mentioned alarm linkages are as follows.

**Duration:** it refers to the interval time between the adjacent motion detections. For instance, if the duration time is set to 10 seconds, once the system detects a motion, it will go to alarm and will not detect any other motion (specific to camera) in 10 seconds. If there is another motion detected during this period, it will be considered as continuous movement; otherwise it will be considered as a single motion.

**Record:** If checked, the “Trigger Record” window will open automatically (you can also click the “Configure” button to open the window). Select a camera on the left side and then click  to set the camera as the trigger camera. Select the trigger camera on the right side or click  to cancel the trigger camera. Click “OK” to save your settings. The trigger camera will record automatically when the sensor alarm is triggered.

**Snapshot:** If checked, the “Trigger Snapshot” window will open automatically. You can configure the trigger camera in this window. The trigger camera will capture images

automatically when the sensor alarm is activated.

**Push:** If checked, choose ON or OFF. If ON, the system will send messages when the sensor alarm is triggered.

**Alarm-out:** If checked, the “Trigger Alarm-out” window will open automatically. The system will trigger the alarm-out automatically when the sensor alarm is tripped. You need to set the delay time and the schedule of the alarm outputs. See [Alarm-out](#) for details.

**Preset:** If checked, the “Trigger Preset” window will open automatically. Here you can configure the trigger preset for each camera. To add presets, please see [Preset Setting](#) for details.

**Buzzer:** if enabled, the system will emit an audible buzz when the sensor alarm is triggered. To set the delay time of the buzzer, please see [Buzzer](#) for details.

**Pop-up Video:** After camera setup, the corresponding video will pop up automatically when the sensor alarm is triggered. To set the duration time of the video, please see [Display](#) for details.

**Pop-up Message Box:** if enabled, the system will pop up the corresponding alarm message box automatically when the sensor alarm is triggered. To set the duration time of the message box, please see [Display](#) for details.

**E-mail:** if enabled, the system will send an e-mail when the sensor alarm is triggered. Before you enable email, please configure the recipient’s e- mail address first (see [E-mail Configuration](#) for details).


**Virtual alarm:** This function should be used with API server. If you want to enable it, please make sure the API Server is enabled first (*Start→Network→Port*) and then set the authentication as “Digest”.

## 11.2 Motion Alarm

**Motion Alarm:** when a motion object appears in the specified area, it will trigger the alarm. You should enable the motion of each camera first and then set the alarm handling of the camera to complete the whole configuration of the motion alarm.

### 11.2.1 Motion Configuration

- ① Click *Start→Settings→Camera→Motion Settings* to go to the following interface.



② Select a camera, enable motion and set the sensitivity and duration of the camera.

**Sensitivity:** the higher the value is, the more sensitive it will be to motion. You should adjust the value according to the practical conditions since the sensitivity is influenced by background color and time (day or night).

**Duration:** The interval time between adjacent motion detections. For instance, if the duration time is set to 10 seconds, once the system detects a motion, it will trigger the alarm and will not detect any other motion (specific to that camera) for 10 seconds. If there is another motion detected during this period, it will be considered as continuous movement.

**Detection Target:** For the camera with SMD function, you can check the detection target as needed. If “People/Motor Vehicle” is enabled, the camera will only detect the movement of people/motor vehicle. If no target is enabled, alarms will be triggered when the moving object appears on the image, including people, vehicle or other moving objects.

③ Drag the camera image to set the motion area. You can set more than one motion area. Click “All” to set the whole camera image as the motion area. Click “Reverse” to swap the motion area and the non-motion area. Click “Clear” to clear all the motion areas.

④ Click “Apply” to save the settings. Click “Processing Mode” to go to the alarm handling configuration interface of the motion alarm.

## 11.2.2 Motion Alarm Handling Configuration

① Click *Start*→*Settings*→*AI/Event*→*General Event*→*Motion Alarm* to go to the following interface.

Camera Name	Schedule	Record	Snapshot	Audio	Push	Alarm-out	Preset	
IPC	24x7	<input checked="" type="checkbox"/> Configure	<input checked="" type="checkbox"/> Configure	<None>	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> Configure	OFF
IPC2	24x7	<input checked="" type="checkbox"/> Configure	<input checked="" type="checkbox"/> Configure	<None>	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> Configure	OFF
IP Camera01	24x7	<input checked="" type="checkbox"/> Configure	<input checked="" type="checkbox"/> Configure	<None>	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> Configure	OFF
IP Camera02	24x7	<input checked="" type="checkbox"/> Configure	<input checked="" type="checkbox"/> Configure	<None>	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> Configure	OFF

Motion Settings    Apply

- ② Enable or disable “Record”, “Snapshot”, “Push”, “Alarm-out”, “Audio”, “Preset”, “Buzzer”, “Pop-up Video”, “Pop-up Message Box” and “E-mail”. The alarm handling setting of motion alarm is similar to that of the sensor alarm (see [Sensor Alarm](#) for details).
- ③ Click “Apply” to save the settings. You can click “Motion Settings” to go to the motion configuration interface.

## 11.3 Combination Alarm

- ① Click *Start* → *Settings* → *AI/Event* → *General Event* → *Combination Alarm* to go to the following interface.
- ② Customize combination alarm. Set alarm name and click “Configure” under the Combined Alarm Configuration item (motion/sensor/intrusion/face recognition/line crossing). Then select alarm type and alarm source. Finally, click “OK” to save the settings.  
(Only some models support face recognition)

Alarm Name	Combination Alarm	Record	Snapshot	Audio	Push	Alarm-out	Pr
Customized Alarm0	Combined Alarm Configuration			None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm1				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm2				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm3				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm4				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm5				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm6				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm7				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm8				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm9	Condition description			None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm10	Motion			None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm11	and			None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm12	Sensor			None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C
Customized Alarm13				None	ON	<input type="checkbox"/> Configure	<input type="checkbox"/> C

OK    Cancel


- ③ Enable or disable “Record”, “Snapshot”, “Push”, “Alarm-out”, “Preset”, “Buzzer”, “Audio”, “Pop-up Video”, “Pop-up Message Box”, “E-mail”, “IPC\_audio” and “IPC\_light”. The alarm handling setting of combination alarm is similar to that of the sensor alarm (see [Sensor Alarm](#) for details).

Click “Apply” to save the settings.

## 11.4 Exception Alarm


### 11.4.1 Camera Offline Settings

- ① Click **Start**→**Settings**→**AI/Event**→**General Event**→**Camera Offline Settings** to go to the interface as shown below.
- ② Enable or disable “Snapshot”, “Push”, “Alarm-out”, “Preset”, “Buzzer”, “Pop-up Video”, “Pop-up Message Box” and “E-mail”. The camera Offline Settings are similar to that of the sensor alarm (see [Sensor Alarm](#) for details).
- ③ Click “Apply” to save the settings.



### 11.4.2 Exception Alarm Settings

- ① Click **Start**→**Settings**→**AI/Event**→**General Event**→**Exception Alarm** to go to the interface as shown below.




- ② Enable or disable “Push”, “Alarm-out”, “Buzzer”, “Pop-up Message Box” and “E-mail”. The exception handling settings are similar to that of the sensor alarm (see [Sensor Alarm](#) for details).
- ③ Click “Apply” to save the settings.

### 11.4.3 Relay

You can add Dingtain and Shelly relays by entering the IPv4 address and port.

Click **Start**→**Settings**→**AI/Event**→**General Event**→**Relay** to go to the relay management interface.



Taking adding a Dingtian Relay as an example:

Enter the IPv4 address and port. You can go to the web client of the relay and enter the local port (Click **Rely Connect** → **TCP Server** → **Dingtian String** to view the local port).

**Note:** If you want to add a Shelly relay, you need to verify the password.

For the added device: if the device is online, you only can edit the device name; if the device is offline, you can edit the device name, IP address, port, etc.

After the relay is added and online, the alarm input and output of the relay can be triggered normally.

In the “Sensor” page, you can set the alarm linkage items (buzzer, popup video, E-mail, etc.) after the relay is triggered.



In the “Alarm-out” page, you can set the delay time and schedule as needed.

No.	Name	Delay	Schedule	Type	Test
Local-1	AlarmOut1	10 Secs	24x7	NO	Test
Local-2	AlarmOut2	10 Secs	24x7	NO	Test
Local-3	AlarmOut3	10 Secs	24x7	NO	Test
Local-4	AlarmOut4	10 Secs	24x7	NO	Test
IPC-1	AlarmOut1	10 Secs	24x7	--	Test
Dingtian String1-1	AlarmOut1	10 Secs	24x7	--	Test
Dingtian String1-2	AlarmOut2	10 Secs	24x7	--	Test

## 11.5 Alarm Event Notification

### 11.5.1 Alarm-out

- ① Click **Start** → **Settings** → **AI/Event** → **Event Notification** to go to the following interface.

No.	Name	Delay	Schedule	Type	Test
Local-1	AlarmOut1	10 Secs	24x7	NO	Test
Local-2	AlarmOut2	10 Secs	24x7	NO	Test
Local-3	AlarmOut3	10 Secs	24x7	NO	Test
Local-4	AlarmOut4	10 Secs	24x7	NO	Test

- ② Set the delay time the schedule and type of each alarm-out. You can click “Edit Schedules” to edit the schedules (see [Schedule Settings](#) for details).
- ③ Click “Apply” to save the settings. You can click “Test” to test the alarm output.

### 11.5.2 E-mail

Click **Start** → **Settings** → **AI/Event** → **Event Notification** → **E-mail** to go to the e-mail configuration interface. Set the e-mail address of the recipients. See [E-mail Configuration](#) for details.

### 11.5.3 Display

Click **Start** → **Settings** → **AI/Event** → **Event Notification** → **Display** to go to the display configuration interface. Set the duration time of the pop-up video and the pop-up message box. If your device supports two outputs, please set the output of the pop-up video as needed. After that, click “Apply” to save the settings.

The screenshot shows two configuration sections. The first section, titled "Pop-up Video", contains two dropdown menus: "Duration" set to "10 Secs" and "Output" set to "Main Output". The second section, titled "Pop-up Message Box", contains a checked checkbox labeled "Don't show later" and a "Duration" dropdown menu set to "10 Secs". An "Apply" button is located at the bottom right of the interface.

### 11.5.4 Buzzer

Click *Start* → *Settings* → *AI/Event* → *Event Notification* → *Buzzer* to go to the buzzer configuration interface. Set the delay time of the buzzer and then click “Apply” to save the setting. You can click “Test” to test the buzzer.

The screenshot shows the "Buzzer" configuration interface. It features a "Delay" dropdown menu set to "5 Secs". At the bottom, there are two buttons: "Test" and "Apply".

### 11.5.5 Push

Click *Start* → *Settings* → *AI/Event* → *Event Notification* → *Push* to go to the interface as shown below. Check “Enable”, select the schedule and then click “Apply” to save the settings. If Push Server is online, it will push text to the mobile clients according to the set schedule.

The screenshot shows the "Push" configuration interface. It includes a checked checkbox labeled "Enable" and a "Push Schedule" dropdown menu set to "24x7". At the bottom, there are three buttons: "Schedule Management", "Test", and "Apply".

### 11.5.6 Audio

Click *Start* → *Settings* → *AI/Event* → *Event Notification* → *Audio* to go to the interface as shown below.

Camera Audio Local Audio Alarm IP Speaker Audio

Voice Broadcast Audio Device

Camera IPC

Audio  Enable

Language Customized

Voice Add Delete Listen

Times 5  Follow the alarm holding time

Volume 75

Schedule 24x7 Manage

Apply

**Camera audio settings:**

For perimeter alert cameras, voice broadcast can be set up. Select the camera, voice, broadcast times, volume, language, and schedule. Then click “Apply” to save the settings. When an alarm is triggered, the camera will broadcast the voice you set.

**Follow the alarm holding time:** if enabled, the warning voice will stop when the alarm holding time ends.


**Audio:** please enable or disable as needed. If your camera doesn’t support this switch, this function is not available.

**Voice:** click “Add” to add the alarm voice in WAV format. Click “Listen” to listen to the uploaded audio.

**Schedule:** Set the schedule of audio linkage alarm. After the schedule is set, the audio alarm will be triggered by events within the schedule.

**Note:** Only some perimeter alert cameras support schedule settings for audio alarm linkage.

Click “Audio Device” to set the audio of the camera.



Select the camera and then enable audio device.

Audio IN Device: Please select it according to the actual device configuration.

Speaker (built-in): Please select its function as needed.

LOUT (external line output): Select the function of the external audio device as needed.


Audio Input Encode: G711A/G711U

**Note: The speaker (built-in) and LOUT (external) cannot be enabled simultaneously for some cameras. Please select it as needed.**

Environmental Noise Filter: Choose “Normal” or “Enhanced” mode as needed. Only some cameras support this function.

### Local Audio Alarm

Set the audio alarm of local NVR.




In this interface, you can set the schedule and volume of the local audio alarm. Click “Add” to upload the audio file (.mp3/.wav format). Note that only some models support MP3 audio files. Choose the uploaded audio file and then click “Listen” to listen to it; click “Delete” to delete this file.

- IP Speaker Audio


1. Select the IP Speaker you have added.
2. Set the audio out volume, schedule and add an audio as needed.
3. Click “Add” to upload the audio file (.wav format). Choose the uploaded audio file and then click “Listen” to listen to it; click “Delete” to delete this file.

The local wav audios also can be listed here.



### 11.5.7 Light

Click *Start* → *Settings* → *Alarm* → *Event Notification* → *Light* to go to the interface as shown below.



In this interface, you can enable and set “Flashing Time (s)”, “Follow the alarm holding time”, “Flashing Frequency” and “Schedule” as needed.

**Follow the alarm holding time:** if enabled, the light will stop flashing when the alarm holding time ends.

**Schedule:** Set the schedule of light linkage alarm. After the schedule is set, the light alarm will be triggered by events within the schedule.

**Note:** Only some perimeter alert cameras support schedule settings for light alarm linkage.


### 11.5.8 Alarm Server

Go to **Alarm** → **Alarm Server** interface as shown below.

Enable the alarm server and enter the server address, URL and port of the alarm server. Next, select the protocol. If “Send Heartbeat” is enabled, set the interval times. After that, test the effectiveness of the alarm server. After a successful test, please click “Apply”. When an alarm occurs, the device will transfer the alarm event to the alarm server. If an alarm server is not needed, there is no need to configure this section.

The screenshot shows the 'Alarm Server' configuration window. It includes a checked 'Enable' checkbox, input fields for 'Server Address', 'URL', and 'Port' (set to 80), a 'Protocol' dropdown set to 'XML', an unchecked 'Send Heartbeat' checkbox, an 'Interval Time[s]' field set to 10, and a 'Schedule' dropdown set to '24x7' with a 'Manage' button. An 'Alarm Type' section is expanded, showing a list of options: Motion Alarm, Sensor Alarm, Camera Offline, Object Abandoned/Missing, Video Exception, and Line Crossing. At the bottom, there are 'Test' and 'Apply' buttons.


### 11.6 Manual Alarm


Click  on the tool bar at the bottom of the live view interface to open a window. Click “Trigger” to start alarm. Click “Clear” to stop alarm. If a relay is connected, you can also trigger the relay alarm output as needed.


Alarm-out Name	Status	Trigger	Clear
AlarmOut1	Normal	Trigger	Clear
AlarmOut2	Normal	Trigger	Clear
AlarmOut3	Normal	Trigger	Clear
AlarmOut4	Normal	Trigger	Clear
Dingtian String1_AlarmOut1	Normal	Trigger	Clear
Dingtian String1_AlarmOut2	Normal	Trigger	Clear


Close




## 11.7 View Alarm Status

Click *Start* → *Settings* → *Alarm* → *Alarm Status* or click  on the tool bar at the bottom of the live view interface to view the alarm status.



Click “Clear” to stop the buzzer when a buzzer alarm is triggered. Click  to view the detailed information as shown below.



If the exception information is more than one page, you can enter the number in the box and then click  to jump to the specified page. Click  /  to view the exception

alarm information in the previous/next page.

## 11.8 System Disarming

You can quickly disarm the device through the alarm host or a remote client (such as the mobile APP).

Control Method/Mode

Alarm Host  
\*The remote control of Disarm/Close Disarm is valid when the alarm host is enabled, please make sure the selected sensor is enabled and in the schedule

Input Sensor:

Remote Client  
\*The remote control of Disarm/Close Disarm and parameters setting is valid when the remote switch is enabled

Disarm Settings

Status: Arming

Scheduled Close Disarm

Disarm Channel/Sensor

Camera/Sensor	Disarm Link Item	Configure	Delete

\*At the State of disarm, the parameters of channel and sensor is invalid

You can self-define the channels and sensors you want to disarm by clicking “Add”. Only the selected channels and sensors can be disarmed by clicking “One Key Disarm”.

**Note:** If you want to control system disarm by a client, you must check “Remote client” in the above interface, or “One key disarm” function cannot be used in the client (like Web/APP client).


**Scheduled Close Disarm:** if enable and set the time, the system will close disarming in the set time point.

## 12 Application


### 12.1 Face Attendance

This function is only available for some models. If your device doesn't support it, please skip the following instructions.

Click **Start** → **Application** → **Face Attendance** to go to the following interface.






To search attendance information

- ① Click  behind camera and group to choose the desired cameras and groups.
- ② Set the attendance date. You can choose day, week, month and today or customize the time period.
- ③ Set the start time and the end time of working.
- ④ Click “Search” to view the attendance state.

If you need to know the attendance status of a specific person, you can click “Advanced” and then enter the name and choose the type.

Click “Export” to export the searched attendance information.


Click  to view the detailed information of attendance. In this interface, click  to go to the face search interface.




## 12.2 Face Check-In


Click **Start** → **Application** → **Face Check-In** to go to the following interface.

The search steps of face check-in are as follows.


- ① Click  behind camera and group to choose the desired cameras and groups.
- ② Set the check-in date. You can choose day, week, month and today or customize the time period.
- ③ Set the start time and the end time of face check-in.
- ④ Click “Search” to view the check-in state.



If you want to know the check-in status of a specific person, please click “Advanced” and then enter the name and choose the type to search.

Click  to view the detailed information. In this interface, the checked image can be viewed.

Click  to view the registered face picture of this person.



## 12.3 Parking Lot Settings

You can manage the parking lot through the NVR. Before using this function, please add the professional ANPR camera.

Click **Start** → **Application** → **Parking Lot Management** to go to the parking lot setting interface.

This system only supports 1 parking lot management.

**Parking Lot Name**

Name

**Parking Space**

Please make sure to edit under the premise that there are no vehicles passing through the entrance and exit to ensure the accuracy of the parking space

Total Parking Space

Remaining Parking Space

**Parking Full Alert**

Enable

Alarm-out

\* Connect signal lights etc. Sustains alarm output when parking is full; stops when space is available.

**Automatic Release**

Enable

The vehicles whose plates start with the following characters will be automatically released; separate plate characters by a comma.

Plates starting with

**Open the gate**

Manual Release Remark

### 12.3.1 Basic Settings

The recorder only supports one parking lot management. Please enter the parking lot name, total parking spaces and remaining parking spaces as needed. To ensure the accuracy of the parking spaces, please enter the parking space information when there are no vehicles entering

or exiting.


**Parking Full Alert:** When enabled and the alarm output is configured, the selected alarm output will be continuously triggered if all parking spaces in the parking lot are occupied. The alarm output will stop triggering once there are available parking spaces.

**Automatic Release:** The barrier gate can be automatically opened for special vehicles after enabling automatic release and entering the special characters. If you want to automatically release multiple vehicle types whose plates start with special characters, you can enter and separate them with commas (,).

**Manual Release:** If “Manual Release Remark” is checked, each time you check “Correct and Open” or “Open the gate-channel name”, you can enter the reason for opening the gate.

### 12.3.2 Parking Space Settings


Only the vehicles added into the plate database are allowed to pass through automatically. You can set the parking spaces according to the vehicle groups or directly use the total parking spaces. For the block list, you can set “No parking allowed”. After that, set the schedule and Email as needed.



No.	Parking Group Name	Parking Options	Group Total P...	Group Rema...	Schedule	E-mail
1	vip	Use the total parking space to park			24x7	

### 12.3.3 Entrance/Exit Management

Set the passing direction of vehicles (Enter/Exit/Enter and Exit) and bind LED screen as needed.



No.	Lane Name	Direction	Camera	Status	Alarm-out	Enable LED screen	Associated LED screen
1	IP Camera04	Enter	IP Camera04(172.28.74.201)	Online	IP Camera04_Alar...	<input type="checkbox"/>	

**Direction:** choose “Close”, “Enter”, “Exit” or “Enter and Exit” as needed.

If “Close” is selected, the LPR/ANPR camera is only used to recognize plates and doesn't trigger the relevant parking management function.

If you want to manage vehicles entering and leaving a park by one LPR/ANPR camera, it is suggested to select “Enter and Exit”. In this way, vehicles entering the park trigger alarms by default, but vehicles leaving the park don't trigger alarms. Vehicles entering/leaving are classified by recognition mode of the LPR/ANPR camera (recognizing when approaching or driving away). When there is a vehicle approaching, the LPR/ANPR camera captures and reports its license plate, the direction is recognized as “Enter” and the NVR analyzes whether the parking spaces are full. If there are remaining parking spaces, the parking system opens the

gate barrier and reduces the remaining parking space. If the parking spaces are full, the gate barrier cannot be opened. When a vehicle is been driving away, the barrier gate can be controlled by the ground sense coil, the LPR/ANPR camera captures and reports its license plate, the direction is recognized as “Exit/Leave” and the NVR increases a parking space.

Note: Only some LPR/ANPR cameras can simultaneously manage the entry and exiting of vehicles.

If “Enter” or “Exit” is selected, the set direction shall prevail.

### 12.3.4 Parking Lot Management


After the above settings are completed, click “Parking Lot” on the left menu to go to the following interface.

Plate	Parking Duration	Entry/Exit Results	Entrance	Entering Time	Entrance Gate-o...	Exit	Exiting Time	Exit Gate-oper...	Detail
72T	--	Not Enter	IP01	--	--	--	--	--	
7948	--	Not Enter	IP01	--	--	--	--	--	
IM9J	--	Not Enter	IP01	--	--	--	--	--	
737P	--	Not Enter	IP01	--	--	--	--	--	
1935	--	Not Enter	IP01	--	--	--	--	--	
2985	--	Not Enter	IP01	--	--	--	--	--	


In this interface, you can view the detailed information of the parking lot, including the total parking space, remaining parking space, number of vehicle entering today, number of vehicle exiting today, valid entering/exiting time, and vehicle entry/exit records.

Only vehicles added into the plate database are allowed to pass automatically. If the vehicle is a stranger/unknown vehicle, it cannot be allowed to enter. You can release it manually by clicking “Open the gate”. If the plate number captured is not matched with the actual one, you can click “Correct and Open” to correct it and open the gate manually. If “Manual Release Remark” is checked in the configuration interface, the release reason also can be entered. For a strange vehicle or when the gate cannot be automatically opened because of other reasons, you can click “Open the gate” to manually open the gate. If “Manual Release Remark” is checked, you can click the camera name and enter the manual release reason for subsequent tracing.


Click to view the detail information of vehicle entry/exiting.





Put the cursor onto the image to view the captured plate picture.

If the capture plate is a stranger plate, click  to add it to the plate database.


Click “Previous/Next” to view the previous/next entering/exiting record of this vehicle.

Click  to exit the detailed entering/exiting page.


In the parking lot management window, click  to go to search the records of vehicles entering/exiting.

Click “” to return to the live view interface.

### 12.3.5 Search Vehicle Entry/Exiting Records


In the parking lot management interface, click  to search the records of vehicles entering/exiting the park lot.


You can search these records by setting filtering conditions (including time/direction/license plate).



Select the image and click “Backup” to export the searched picture.

Click the searched vehicle to view the detailed vehicle entry/exiting records as shown below. In addition, you can add the stranger vehicle and view the target ID as needed. Click “Close” or

 to return to the parking lot management interface.



## 12.4 Access Control Management

The recorder supports access control parameter configuration and remote door opening. Before

using the access control function, please add access control devices (face recognition & access control terminal/panel). Go to **Start → Settings → Camera → Add Camera** interface to add devices.

### 12.4.1 Access Control Settings

Click **Start → Application → Access Control Management** to go to the following interface.

Select the access control device you want to configure the parameters.

Lock: Choose the lock you want to control.

Unlocking Mode: if “Mask On” is selected, the door will be opened when the matched person wearing a mask

List Type: Allow list, visitor (including allow list), stranger (including visitor and allow list).

Unlocking Delay Time: Set the door unlocking delay time. The time range is from 0 to 10 seconds. For example, the unlocking mode is “Face only” and the delay time is set to “2” seconds; the door will be opened 2 seconds later after face recognition.

Unlocking Duration: Set the unlocking duration. The time range is from 0 to 10 seconds. For example, the unlocking mode is “Face only” and the duration is set to “3” seconds; the door will be opened after successfully face comparison, but the opening door will be automatically locked 3 seconds later.

Door Lock Setting: Choose “Auto”, “NO” or “NC”. Please select it according to your door lock type.


Alarm Linkage Type: Open/close the door

Wiegand Config: Wiegand Input, Wiegand Output or Off can be selected. If the card reader is connected to the Wiegand interface, please select “Wiegand Input”. If the access controller is connected to the Wiegand interface, please select “Wiegand Output”.

Wiegand Mode: 26bit (8), 26bit (10), 34bit, 37bit, 42bit, 46bit, 58bit or 66bit can be selectable. After clicking “Apply”, the configuration will be synchronized with the camera. When someone wants to enter, the access control device will open the door according to the set condition.

## 12.4.2 Open the Door Manually

In the live view interface, select an access control camera. Right click on the window to show a dropdown list. Select “Manually Open the Door” to open the door via the NVR.




If you want to view the real-time face snapshots and comparison of access control devices, please enable face detection or comparison function as needed. Then the corresponding results will display under the target detection tab in the live interface.

## 12.5 People Flow

After the people counting cameras are accessed and configured, you can go to the people counting interface to view the detailed counting data. Before viewing the people flow data, please set the people counting function first (See [people counting](#) section for details).

- ① Go to Start→Application→People Flow→Configure interface to set the statistical channel and reset information.




Select the people counting channel you want view the statistical information.


Set the reset information as needed. Auto or manual reset can be set.

Auto Reset: The current number of the people counting can be reset. You can choose to reset the counting daily, weekly or monthly.

Click “Reset” to manually reset the current number of people counting.

After that, click “Apply” to save the settings.


② Click  to view the detailed statistical information as shown below.



# 13 Account & Permission Management

## 13.1 Account Management

Click **Start**→**Settings**→**Account and Authority**→**Account**→**Edit User** to go to the interface as shown below.




Area ① displays the user permissions. Area ② displays the user list. Click the user in the list to display its user permissions in area ①.

There are three default permission groups (“Administrator”, “Advanced” and “Common”) available when adding accounts. You can manually add new permission group (see [Add Permission Group](#) for details).

Only **admin** and the users that have the “Account and Authority” permission can manage the system’s accounts. Group “Administrator” owns all the permissions displayed in area ① except “Account and Authority” and its permissions cannot be changed while the permissions of “Advanced” and “Common” can be changed.

### 13.1.1 Add User

① Click **Start**→**Settings**→**Account and Authority**→**Account**→**Add User** or click  beside the search box to open a window as shown below.

The 'Add User' dialog box includes the following fields and options:

- Username:** Enter Username
- Password:** Enter Password
- Confirm Password:** Enter Password
- Display Password
- Pattern Lock:**  Enable Edit
- Group:** Administrator
- Allow Modify Password:**  Enable
- Remote access without v...:**  Enable
- Remark:** [Empty text field]
- Login Management:**  Schedule Schedule 24x7

**Requirements:**

- 1) 1 to 16 characters
- 2) Contains one or more numbers/lowercase/uppercase letters/symbols.

Buttons: Add Cancel

② Set the username, password, group and login schedule. Enable or disable “Allow modify password” or “Remote access without verification code”. Users can also set the pattern lock as needed. Click “Add” to add the user.



**Remote access without verification code:** If enabled, there is no need for you to enter the verification code when visiting the NAT website after the device is bound.







**Login Management:** Choose “Schedule” or “System Disarm” as needed.

**Login Schedule:** If enabled, the added user has access to the NVR within the scheduled period.

**System Disarm:** If enabled, you are not allowed to log in when the system is in a disarmed state. You can log in normally when the system is in the armed state.

### 13.1.2 Edit User

Click *Start*→*Settings*→*Account and Authority*→*Account*→*Edit User* and then click  in the user list or double click the user to edit the user information. Click  to delete the user (the user *admin* cannot be deleted).


Username	Group	Edit	Delete
admin			
<div style="display: flex; justify-content: space-around;"> <span>Modify Password</span> <span>Modify Pattern Lock</span> <span>Edit User</span> </div>			
2	Advanced		
<div style="display: flex; justify-content: space-around;"> <span>Edit User</span> <span>Reset Password</span> </div>			
1	Administrator		

#### ➤ Modify Password


The password of **admin** can be modified. Click “Modify Password” to pop up a window. Enter the current password and then set new password. Click “OK” to save the settings.  
In addition, the admin user can modify the common/advanced user’s password.

### ➤ **Modify Pattern Lock**

Some models may not support this function.  
Click “Modify Pattern Lock” to pop up a window.




Input current password and then check “Enable” to set pattern lock.



### ➤ **Edit User**

Click “Edit User” to pop up the window as shown below. The **admin** is enabled, its permission is closed and permission group cannot be changed by default. You can open or close permission control (if closed, the user will get all the permissions which **admin** has) and set their permission groups. Click “OK” to save the settings.



## 13.2 User Login & Logout


**Login:** Click *Start* → *Login* or directly click the preview interface and then select username and enter the password in the popup window. Click the “Login” button to log in the system.

**Logout:** Click *Start* → *Logout* or click *Start* → *Shutdown* to pop up the “Shutdown” window. Select “Logout” in the window and then click “OK” to log out the system.


## 13.3 Permission Management

### 13.3.1 Add Permission Group




Click *Start* → *Settings* → *Account and Authority* → *Account* → *Edit Permission Group* to go to the interface as shown below.



Click **+** to add permission group. Set the group name, check the permissions as needed and then set the “Local” and “Remote” permissions. Click “Add” to save the settings.






### 13.3.2 Edit Permission Group

Go to “Edit Permission Group” interface and then click  in the group list to edit the permission group (the operations of the “Edit Permission Group” are similar to that of the “Add Permission Group”, please see [Add Permission Group](#) for details). Click  to save the group as another group. Click  to delete the permission group. The three default permission groups (“Administrator”, “Advanced” and “Common”) cannot be deleted.

## 13.4 Black and White List

① Click **Start**→**Settings**→**Account and Authority**→**Security** to go to the following interface.




- ② Check “Enable” and then choose “Enable Allow List (white list)” or “Enable Block List (black list)” (the PC client of which the IP address is in the white list can access NVR remotely while the PC client in the black list cannot).
- ③ Add IP/IP segment/MAC. Click “Add IP” or “Add MAC” and then check “Enable” in the popup window (only if you check it can the IP/IP segment/MAC you add be effective). Enter the IP/IP segment/MAC and then click “OK”. In the above interface, click  to edit IP/IP segment/MAC, click  to delete it. Click “Apply” to save the settings.

## 13.5 Preview on Logout


Click *Start*→*Settings*→*Account and Authority*→*Security*→*Preview on Logout* to go to the following interface.

Set a camera and then enable or disable the preview permission on logout as needed. If a camera’s preview permission on logout is “ON”, you can view the live image of the camera when the system is logged out, or the live image of the camera cannot be seen when logged out.



## 13.6 Network Security

Click *Start*→*Settings*→*Account and Authority*→*Security*→*Network Security* to go to the following interface. You can enable APR Guard.



ARP (Address Resolution Protocol) Guard: This function can protect the LAN from ARP attacks and increase the network stability. If it is enabled, you can enable auto gateway MAC or manually set gateway MAC. Additionally, detection defense also can be enabled as needed.

## 13.7 Password Security

Click **Start**→**Settings**→**Account and Authority**→**Security**→**Password Security** to go to the following interface.




In this interface, you can set the security level and expiration time of the password. It's recommended to force a new password periodically to enhance system security.

## 13.8 Password Retrieval Settings

You can reset your admin password by E-mail or security question. Click **Start**→**Settings**→**Account and Authority**→**Edit Security Question** to enter the password retrieval setting interface. You can set reset the password via E-mail or security question. If you forget your admin password, you can click “Retreuve Password” in the login interface to reset your password.


## 13.9 Double Verification

This device allows you to create a double verification user. That's to say, you can create a user who want to log in must be verified by the other specified user.



Click “Add” to add a double verification user. Enter the username and password and select the login user. When you use the login user set above to log in the NVR, the user you added in the double verification interface must be verified, or the login failure will occur.

### 13.10 View Online User

Click *Start*→*Settings*→*Account and Authority*→*User Status* to view the online user information (you can view the online user name, login type, IP address and login time; click  to open a window showing the preview occupied channel number and playback occupied channel number).

# 14 Device Management

## 14.1 Network Configuration

### 14.1.1 TCP/IP Configuration

Click **Start**→**Settings**→**Network**→**TCP/IP** to go to the following interface. Check “Obtain an IP address automatically”, and “Obtain DNS automatically” to get the IPv4/IPv6 (if IPv6 is enabled) address automatically, or manually enter the network addresses. You can modify the MTU value according to the network condition (MTU, Maximum Transmission Unit, can be modified according to network condition for higher network transmission efficiency). Click “Apply” to save your settings.

Additionally, if you want to configure multiple IP addresses for a single network card (for example: add devices from different network segments under the same switch), you can click “Advanced” to set a secondary IP address.


Note:

#### Internal Ethernet Port

If you use an NVR with PoE network ports, click “Internal Ethernet Port” to go to the interface below.

The internal Ethernet port is the port which connects all PoE ports with the NVR system. The PoE ports are available if the internal Ethernet port is online; if it is offline, all the PoE ports will be unavailable and it’s possible there’s an issue with the Ethernet port. The network address of the internal Ethernet port can be changed to be in the same network segment as IP cameras which are directly connected to the PoE ports of the NVR (Note that it is not recommended to change the network address of the internal Ethernet port).

Mode: Non-long line mode or long line mode can be selectable. The non-line mode is the default setting. If you want to run your PoE cameras longer than the standard 100M distance, you can choose long line mode. The tradeoff will be that your network speed on all PoE ports will drop to 10MBPs.



● **Multiple Ethernet Ports Setting**


If the NVR has two network ports or above, you can select the network work pattern as required.

**TOE:** Some models may support TOE mode. It is a technology for improving the network transmission speed. Please enable it according to the actual network situation. If TOE is enabled, it shall be high speed mode. Then multiple address setting or network fault tolerance can be chosen and configured. If TOE is not enabled, it shall be compatible mode. Then the network fault tolerance cannot be selected and set up.

**Network Fault Tolerance:**

The two network ports will be bound to one IP address if you select the “Network Fault Tolerance” pattern. There are many advantages of this work pattern: 1. increase the bandwidth; 2. form a network redundant array to share the load. When a failure happens to one network port, the other port will take over the entire load immediately. The takeover process is seamless and the network service will not be broken off.

Refer to the figure as shown below. If “Network Fault Tolerance” is selected, check “Obtain an IPv4 address automatically”, and “Obtain DNS automatically” to get the network addresses automatically, or manually enter IPv4/IPv6(if IPv6 is enabled) address select one Ethernet port as the primary card and then click “Apply” to save the settings.



### Multiple Address Setting:

If “Multiple Address Setting” is selected, the IP addresses of the two Ethernet ports should be set respectively. Refer to the picture as shown below.

Check “Obtain an IP address automatically” and “Obtain DNS automatically” to get the network addresses automatically, or manually enter IPv4/IPv6(if IPv6 is enabled) address; select one Ethernet port as the default route and then click “Apply” to save the settings.

**Note:** The above interface may be different for different models. The above picture are for reference only.

## 14.1.2 Port Configuration

Click *Start* → *Settings* → *Network* → *Port* to go to the interface as shown below. Enter the HTTP port, HTTPS port, server port and POS port of the NVR, and then click “Apply” to save the settings. You can also enable and set RTSP port (please check “Anonymous” as required).

The screenshot shows a configuration page with the following sections:

- Port**
  - HTTP Port: 80
  - HTTPS Port: 443  Enable Please install the certificate on the web beforehand
  - Server Port: 8036
  - POS Port: 9936
  - Auto Report Port: 2009
- API Server**
  - Enable
  - Authentication: Digest
- RTSP**
  - Enable
  - Authentication: Digest
  - RTSP Port: 554  Anonymous
  - URL Example: rtsp://IP:Port/chID=1&streamType=main

An **Apply** button is located at the bottom center of the form.


**HTTP Port:** the default HTTP port of the NVR is 80. The port number can be changed to another number such as 81. The port is mainly used for web client access. If you want to access the NVR through a web browser, you should enter the IP address plus HTTP port in the address bar of the web browser like <http://192.168.11.61:81>.

Note: The HTTP port and server port of the NVR should be mapped to the router before you access the NVR via WAN.

**HTTPS Port:** the default HTTPS port of the NVR is 443.


HTTPS provides authentication of the web site and protects user privacy. You can enter IP address plus HTTPS port in the address bar of the web browser. Then enter username and password to log in. Click **Functional Panel** → **Network** → **HTTPS** to go to the following interface. There are three ways to enable HTTPS service.

#### A. Create a private certificate.



- ① Select “Create a private certificate”.
- ② Click “Create”.
- ③ Fill out the corresponding information in the above creation box. Enter the country (only two letters available), domain (NVR’s IP address/domain), validity date, password, province/state, region and so on.
- ④ Click “OK”.
- ⑤ Check “Enable” checkbox.
- ⑥ Click “Apply” to save the setting.

## B. Install a signed certificate




- ① Check “Signed certificate already...”.
- ② Click “Browse” to select the certificate you want to import.
- ③ Click “Import”.
- ④ Check “Enable”.
- ⑤ Click “Apply” to save the settings.

Please note that the certificate uploaded here shall be a certificate with private key.

To attach the private key to the certificate, please open the certificate and the private key files

with an editor (like Notepad++) and then copy the private key to the certificate.

### C. Create a certificate request



- ① Check “Create a certificate request”.
- ② Click “Create”.
- ③ Fill out the corresponding information in the above creation box. Enter the country (only two letters available), domain (NVR’s IP address/domain), validity date, password, province/state, region and so on.
- ④ Click “OK”. Then a certificate request file (CSR) will be created.
- ⑤ Click “Export” to export the certificate request file. Then send this file to the trusted third-party CA to apply a signed certificate.
- ⑥ Click “Browse” and select the signed certificate issued by the CA and then import this certificate.
- ⑦ Click “Enable”.
- ⑧ Click “Apply” to save the settings.

After that, the device can be accessed by entering [https://IP: https port](https://IP:https port) via the web browser (eg. <https://192.168.1.201:443>).

**Server Port:** the default server port of the NVR is 6036. The server port number can be changed as needed. The port is mainly used in network video management system.

**POS Port:** the default POS port of the NVR is 9036.

**Auto Report Port:** the default auto report port of the NVR is 2009. The server port number can be changed as needed. This port is used when the NVR automatically reports to the NVMS.

**API Server:** You can log into a media player which supports the RTSP protocol. Moreover, the third party can further develop performance through an API service.

**Authentication:** Basic authentication and digest authentication are optional.


**RTSP Port:** RTSP real-time stream protocol can be used to control the transfer of real-time data. Through a media player which supports the RTSP real-time stream protocol (Such as VLC

player), you can view live images synchronously. The default RTSP port is 554 and it can be changed as needed. (The address format: rtsp://IP address:554/chID=1&streamType=main or rtsp://IP address:554/chID=1&streamType=sub; main indicators main stream; sub indicators sub stream; chID indicators channel ID).

**Examples:** Enable RTSP and “Anonymous”. Then open the VLC player and enter the address (for example: rtsp://192.168.1.88:554/chID=1&streamType=main) in the network address bar of the VLC player. Then you can view the video of channel 1.

### 14.1.3 PPPoE Configuration

Click **Start** → **Settings** → **Network** → **PPPoE** to go to the interface as shown below. Check “Enable” in “PPPoE Settings” and then enter the username and password obtained from the dealer. Click “Apply” to save the settings.



PPPoE Settings

Enable

Username


Password

Apply

### 14.1.4 DDNS Configuration

The DDNS is used to control the dynamic IP address through a domain name. You can access the NVR easily if the DDNS is enabled and configured.

Click **Start** → **Settings** → **Network** → **DDNS** to go to the interface as shown below.



DDNS

Enable

DDNS Type

Server Address

Domain Name

Username

Password

Heartbeat Interval  s (Range : 5-3600)

Connection Status Failure

Test Apply

Check “Enable” and then select the DDNS type. Enter the server address, domain name, username and password according to the selected DDNS type. Click “Test” to test the effectiveness of the input information. Click “Apply” to save the settings. After that, the

successful connection status can be viewed.

Note: Only when the DDNS type is “dyndns”, can the heartbeat interval be configurable.

You will have to enter the server address and domain name if some DDNS types are selected.

Go to the relative DNS website to register domain name and then enter the registered domain information here). Now we take **www.dvrdydns.com** for example.

- ① Enter **www.NVRdydns.com** in the address bar to visit its DNS website.

- ② Click **Registration** to go to the interface as shown below. Set the DDNS account information (username, password and so on) and then click **Submit** to save the account.

- ③ Create domain name and then click **Request Domain**.

### Domain Name Creation

Enter a new domain name below.

---

*You must create a domain name to continue.*

Domain name must start with (a-z, 0-9), must be least 3 char! Cannot end or start, but may contain a hyphen and is not case-sensitive.

.dvrdydns.com

- ④ After you successfully request your domain name, you will see your domain name information in the list.

### My Domains

Your domain names are listed below. Choose create new domain to add additional domain names.

---

*Your domain was successfully created.*

*Click a name to edit your domain settings.*

NAME	STATUS	DOMAIN
REDSUNSHINE	✔	redsunshine.dvrdydns.com
Last Update: <i>Not yet updated</i> IP Address: 210.21.229.138		

Create additional domain names

[1]

- ⑤ Click **Start** → **Settings** → **Network** → **DDNS** to go to DDNS setting interface. Enable DDNS and then select the **www.dvrdydns.com** DDNS type. Enter the registered username, password and domain name and then click “Apply”.
- ⑥ Map the IP address and HTTP port in the router (you can skip this step if UPnP function is enabled).
- ⑦ Enter the registered domain name plus HTTP port like **http://www.xxx.dvrdydns.com:81** in the address bar and then press Enter key to go to the web client.

### 14.1.5 E-mail Configuration

Click **Start** → **Settings** → **Network** → **E-mail** to go to the following interface.

Sender

Sender Name

Email Address

SMTP Server

SMTP Port

Security

Attaching Image

Include XML in Email

Anonymous Login

Username

Password

Enter the sender's name, e-mail address, SMTP server and SMTP port (you can click "Default" to reset the SMTP port to the default value) and then enable or disable the SSL and attaching image.

Attaching Image: Choose "NO", "A Picture" or "Multiple Pictures". If "A Picture" or "Multiple Pictures" is selected, snapshot image or original image can be selected to attach.

Include XML in Email: If enabled, the sending email will include XML contents. Select the username (the username list will be updated automatically according to the email address you input) and enter the password of the sender and then click "Apply" to save your settings (you don't have to enter the username and password if "Anonymous Login" is enabled). Click "Test" to open a window. Enter the e-mail address of the recipient in the window and then click "OK." The e-mail address of the sender will send an e-mail to the recipient. If the e-mail is sent successfully, it indicates that the e-mail address of the sender is configured correctly.

Click "Edit Recipient" to go to the following interface:



E-mail Notification

Recipients

No.	Recipients	Schedule	Delete
1	a*c@***.com	24x7	<input type="button" value="Delete"/>

Sender:


Click "Add" and then enter the recipient's e-mail address and select the schedule (if a


schedule is selected, the system will send the alarm email, and the recipient will receive it only in the selected schedule time) in the popup window. Click “Add” in the window to add the recipient. You can also change the recipient’s receiving schedule by clicking  in the “Schedule” column. Click  to delete the recipient in the list. Click “Apply” to save your settings. Click “Edit Sender” to go to the e-mail configuration interface of the sender.





### 14.1.6 UPnP Configuration

By UPnP you can access the NVR through the web client which is on the WAN via a router without port mapping.

- ① Click **Start** → **Settings** → **Network** → **UPnP** to go to the following interface.
- ② Make sure the router supports UPnP function and the UPnP is enabled in the router.
- ③ Set the NVR’s IP address, subnet mask and gateway and so on corresponding to the router.
- ④ Check “Enable” in the interface as shown below and then click “Apply”.

Click “Refresh” button to refresh the UPnP status. If the UPnP status is still “Invalid UPnP” after refreshing, the port number is wrong. Please change the mapping type to “Manual” and then click  to modify the port until the UPnP status turns to “Valid UPnP”. Refer to the picture below. You can view the external IP address of the NVR. Enter the external IP address plus port in the address bar of your browser to access the NVR (example: <http://183.17.254.19:81>).



Port Type	External Port	External IP Address	Port	UPnP Status	Edit
HTTP Port	80		80	Not Ready	
HTTPS Port	443		443	Not Ready	
Server Port	6036		6036	Not Ready	
RTSP Port	554		554	Not Ready	

### 14.1.7 802.1X

If it is enabled, the NVR data can be protected. When the NVR is connected to the network protected by the IEEE 802.1X, user authentication is needed.

To use this function, the NVR shall be connected to a switch supporting the 802.1x protocol. The switch can be considered as an authentication system to identify the device in a local network. If the NVR connected to the network interface of the switch has passed the authentication of the switch, it can be accessed via the local network.

Protocol type and EAPOL version: Please use the default settings.

User name and password: The user name and password must be the same with the user name and password applied for and registered in the authentication server.

### 14.1.8 NAT Configuration

Click *Start*→*Settings*→*Network*→*NAT* to go to the interface for NAT configuration.

Check “Enable” and then select the NAT server address. Click “Apply” to save the settings.

You can scan the QRCode through mobile APP which is installed on a mobile phone or tablet PC to quickly add the device to the server list of the mobile APP.

Access Type: NAT or NAT2.0 can be selected.

Click “Advanced” to select the area as needed.

**Security Access:** Only some models upgraded from a lower version can display this function. New models support this function by default. After this function is enabled, it reduces malware damage and enables NAT2.0 push function.

The setup steps of enabling NAT2.0 message push are as follows:

1. Enable NAT and security access. If “Security Access” is not displayed, it means this function is supported by default.
2. Select NAT2.0 access type.
3. Log in your APP account and add the device by scanning the QR code and entering the verification code.
4. In the APP, select the device in the push setting interface and enable push message.

### Web login by NAT2.0

After you bind the device to your APP account and enable NAT2.0, a verification code will be required when logging onto the web client by using the above visit address (different areas and regions maybe have different visit addresses). Please enter the correct verification code that gets from the APP.

#### Note:

1. If you want to use the cloud upgrade, you must enable NAT2.0.
2. After the NAT is enabled, use the mobile APP to scan the QRcode and then the device can be added to the server list of the mobile APP.
3. The device can be added to the account of the mobile APP only when NAT2.0 is enabled. After the NAT2.0 is enabled, when you add the device to the account of the mobile APP, you must enter the verification code of the device here. Please refer to the mobile surveillance user manual for details.
4. Currently, only the latest APP version can receive the verification code.

After the device is bound to the account of the mobile APP, the blue binding information will be shown under the QR code. Click this blue information to unbind it.

## 14.1.9 FTP Configuration

Some models may not support this function.

Click **Start**→**Settings**→**Network**→**FTP** to go to the interface for FTP configuration. Check “Enable” and enter the server name, port, username and password, max file size and remote directory.

Please enable “Resume Uploading” as needed.

After that, you can choose the camera, set the schedule and then select the video records, images and alarm information to upload as needed in this interface.

FTP

Enable

Server Address  Port

Username  Password   Anonymous

Max File Size  M Remote Directory

Resume Uploading Note:After FTP is successfully reconnected , the device will automatically upload the videos shot during FTP disconnection period.

Uploading Settings

No.	Camera Name	Schedule	Uploading record				Uploading Image	Uploading File(txt)
			Motion	Intelligence	Sensor	Stream Type	Snapshot	Alarm Info
1	IPC	24x7	OFF	OFF	OFF	Sub Stream	OFF	OFF
2	IP camera 01	24x7	OFF	OFF	OFF	Sub Stream	OFF	OFF
3	IP camera 02	24x7	OFF	OFF	OFF	Sub Stream	OFF	OFF

### 14.1.10 SNMP

- ① Click **Start** → **Settings** → **Network** → **SNMP** to go to the interface for SNMP configuration.

SNMP

Enable SNMPv1

Enable SNMPv2

Enable SNMPv3

SNMP Port

Read Community

Write Community

Trap Address  . .

Trap Port

Username

Security Level

Auth Type

Auth Password

Privacy Type

Privacy Password

- ② Check SNMPv1, SNMPv2 or SNVMPv3 to enable this function.
- ③ Set the port of the SNMP.

- ④ Set the trap address and the trap port.
- ⑤ Click “Apply” to save the settings.

Trap Address: The IP address of SNMP host.

Trap Port: The port of SNMP host.

**Tips:** Before setting the SNMP, please download the SNMP software and manage to receive the device information via SNMP port. By setting the trap address, the device is allowed to send the alarm event and exception message to the monitoring center.


### 14.1.11 Cloud Upgrade

Note: Before you use cloud upgrade, please enable NAT2.0.

Click **Start**→**Settings**→**Network**→**Cloud Upgrade** as shown below.

**Note:** Only users with Network user authority can activate and use this feature. If the dealer does not wish to provide this capability to their users, they can ensure that only the main Admin login has network authority.

#### ➤ Device Upgrade



- ① Select “Accept Notification Only” or click “Check for Updates” to check whether the current version is the latest. If your software version is not the latest, click “Upgrade” to download and upgrade from the cloud server.
- ② Please don’t power off during the upgrade process.

#### ➤ Camera Upgrade

Click the “Channel Upgrade” tab to automatically check the added camera version. If cameras are not the latest version, click “Check for Updates” to get the latest version from the cloud server. You can upgrade cameras one by one or in batches as needed.

### 14.1.12 Platform Access

Some models may not support this function.

This function is mainly used for connecting ECMS/NVMS. The setting steps are as follows. Click **Start** → **Settings** → **Network** → **Integration** → **Platform Access** to go to the interface.

Platform Access

Access Type: Platform Software

Enable

Server Address: 192.168.1.200

Port: 2009

Report ID: Enter Report ID

Report Status: Disable

Apply

### Platform Access

- ① Set “Access Type” as “Platform Software” and select “Enable” as shown below.
- ② Check the IP address and port of the transfer media server in the NVMS. The default server port for auto report is 2009. If it is modified, please go to the transfer media interface to check.
- ③ Enable the auto report in the NVMS when adding a new device. Then self-define device ID and complete the remaining information of the device in the NVMS.
- ④ Enter the above-mentioned server address, port and report ID in the server interface. Then click “Apply” to save the settings.

### 14.1.13 UPnP Report Access

In this interface, you can also access the third-party platform by UPnP Report. Click **Start** → **Settings** → **Network** → **Integration** → **UPnP Report**. If this one is enabled, please enter the server address, port and manufacturer ID.

UPnP Report

Enable

Server Address: Enter Address

Port: 0


Manufacturer ID: Enter Manufacturer ID

Apply

### 14.1.14 ONVIF

The device supports ONVIF (Profile G/M/S/T) and the model name can be searched on the ONVIF official website. After ONVIF is enabled, it can be searched and connected to a third-party platform via ONVIF protocol.

Click **Start** → **Settings** → **Network** → **Integration** → **ONVIF** to enter the following interface.



The screenshot displays the ONVIF configuration interface. At the top, there is a checkbox labeled "Enable ONVIF" which is checked. Below this is a "User List" table with a header row containing "No." and a column for user details. A modal dialog box titled "Add User" is open in the center. It contains the following fields and options:

- Username:** A text input field with the placeholder "Enter Username".
- Password:** A password input field with the placeholder "Enter Password" and a visibility toggle icon.
- Confirm Password:** A password input field with the placeholder "Enter Password" and a visibility toggle icon.
- Validation:** Text indicating "1,8 to 16 characters" and "2 Contains two or more numbers/lowercase/uppercase letters/symbols."
- User Type:** Three radio button options: "Video User" (selected), "Operator", and "Admin".

Buttons for "Add", "OK", "Cancel", and "Apply" are visible at the bottom of the interface.

**Note:** when adding the device to a third-party platform with ONVIF protocol, please check "Enable ONVIF" first and then enter the username and password created in the above interface.

### 14.1.15 HTTP POST

HTTP POST

Enable

Server Address

Port

Path

Protocol

Username   Anonymous Login

Password

Connection

Interval Time[s]   Send Heartbeat

Schedule

Attaching Image  Snap  Original

Event Type

Motion Alarm

Sensor Alarm

Camera Offline

Object Abandoned/Missing

Server Address: the IP address of the third-party platform.

Server port: the server port of the third-party platform.

Path: enter the subdomain of the above server, for example, the URL of alarm information push: “/SendAlarmStatus”.

Protocol type: HTTP


Username and password: Please enable and enter as needed.

Connection: Persistent connection or non-persistent connection.

Enable “Send heartbeat” and set heartbeat interval, schedule, and attaching image as needed.

Click “Configure” to set the event type. After that, click “Apply” to save the settings. Then click “Test” to test the connection of the URL. Then the camera will automatically connect to the third-party platform. After the camera is successfully connected, it will send the selected alarm data to the third-party platform once the selected smart alarm is triggered.

### 14.1.16 Network Status

Click **Start** → **Settings** → **Network** → **Network Status** to view the network status or click  on the tool bar at the bottom of the live view interface to view network status conveniently.

Click **Start** → **Settings** → **Network** → **Network Status Detection**. Enter the IP address and then click “Test” to check the network connection status (like network delay, packet loss).

## 14.2 Basic Configuration

### 14.2.1 Common Configuration

Click **Start** → **Settings** → **System** → **Basic** → **General Settings** to go to the following interface. Set the device name, device No., language, video format and main output. Enable or disable wizard, “Log In Automatically”, “Log Out Automatically” (if checked, you can set the wait time), “App Live Self-Adaption” and “Dwell Automatically” (if checked, you can set the wait time). Click “Apply” to save the settings.

The screenshot shows the 'General Settings' configuration page. It includes the following fields and options:

- Device Name:** A text input field containing 'Device Name'.
- Device No.:** A text input field containing '1'.
- Language:** A dropdown menu set to 'English'.
- Video Format:** A dropdown menu set to 'PAL'.
- Fixed Display Resolution:** A checked checkbox.
- Main Output:** A dropdown menu set to '1920x1080'.
- Secondary Output:** A dropdown menu set to '1920x1080'.
- Enable Wizard:** A checked checkbox.
- Log In Automatically:** A checked checkbox.
- Log Out Automatically:** A checked checkbox.
- Wait Time (Log Out):** A dropdown menu set to '1 Min'.
- App Live Self-adaption:** A checked checkbox.
- Dwell Automatically:** An unchecked checkbox.
- Wait Time (Dwell):** A dropdown menu set to '10 Mins'.
- Live preview full screen time display:** A checked checkbox.
- Apply:** A button at the bottom right.

**Device Name:** The name of the device. It may display on the client end or CMS to help users to recognize the device remotely.

**Video Format:** Two modes: PAL and NTSC. Select the video format according to the camera.

**Dwell Automatically:** Switch automatically. Check it and set “wait time”. The system will sequence automatically if it is not operated during the time you set.

**Main Output:** Enable “Fixed display resolution” and then select the main output as needed.

**Note:**

If “Fixed display resolution” is disabled, press and hold the right mouse button for 5 seconds to

switch the resolution. The resolution can be changed after the beep.

If “Fixed display resolution” is enabled, press and hold the right mouse button for 5 seconds first and then press and hold the left mouse button for 5 seconds to switch the resolution. The resolution can be changed after the beep.


You can set the resolutions of the main output, secondary output (varies by models) respectively if the NVR has multiple outputs.

You can check “Support 8K” as needed for some models.


## 14.2.2 Date and Time Configuration


Click *Start* → *Settings* → *System* → *Basic* → *Date and Time* to go to the interface as shown below. Set the system time, date format, time format and time zone of the NVR. The default time zone is GMT+08 Beijing, Hong Kong, Shanghai, Taipei. If the selected time zone includes DST, the DST of the time zone will be checked by default. Click “Apply” to save the settings.

You can manually set the system time or synchronize system time with network through NTP.

**Manual:** select “Manual” in the “Synchronous” option and then click  after the “System Time” option to set the system time.

**NTP:** select “NTP” in the “Synchronous” option and then enter the NTP server.



Date and Time	
System Time	2019/07/31 05:01:29 
Date Format	Year/Month/Day
Time Format	24-Hour
Sync Time With Network	
Synchronous	Manual
NTP Server	time.windows.com
Time Zone / DST	
Time Zone	GMT-05 New York, Toronto, Wash
DST	<input checked="" type="checkbox"/> Enable

## 14.2.3 Recorder OSD Settings

Click *Start* → *Settings* → *System* → *Basic* → *Recorder OSD settings* to go to recorder OSD setting interface. OSD name and icon can be enabled here.

## 14.2.4 PoE Power Management

Click **Start** → **Settings** → **System** → **Basic Settings** → **PoE Power Management** to go to the following interface. This function is only available for the POE device.

PoE Port	Enable	Current Power
Poe[01]	ON	0.00W
Poe[02]	ON	0.00W
Poe[03]	ON	0.00W
Poe[04]	ON	0.00W
Poe[05]	ON	0.00W
Poe[06]	ON	0.00W
Poe[07]	ON	0.00W
Poe[08]	ON	0.00W

In this interface, you can view the the current power consumption of the added POE camera/panel. The PoE power supply of the PoE camera/panel can be enabled or disabled by selecting “ON” or “OFF” as needed.

### ● PoE Plug-and-Play Settings

The PoE function of each PoE port is enabled by default. You can directly connect the PoE IPC to the PoE port of the NVR with a network cable.

You can also connect the PoE IPC to the NVR via a PoE switch by referring to the following steps.

1. Go to **Start** → **Settings** → **System** → **PoE Settings** → **PoE Pug-and-Play Settings**. Disable the PnP function of a PoE Port.
2. Connect the PoE switch to this PoE port of the NVR with a network cable.
3. Connect the PoE IPCs to the PoE switch with network cables.
4. Go to **Start** → **Settings** → **Network** → **Internal Ethernet Port**. Set the IP address segment and mode as needed.
5. Go to **Start** → **Settings** → **Camera** → **Edit Camera**. Click “Add Camera” to add these PoE IPCs manually. Note that the IP address of these cameras must be in the same local network segment as the internal Ethernet port.


**Note:** If the above-mentioned PoE IPCs are added to the NVR successfully, the corresponding number of PoE ports will be occupied. For example, if the NVR has 16 PoE ports and one of them is used to connect a PoE switch which 8 PoE IPCs are connected to, then only 8 PoE ports of the NVR can be used to directly connect PoE cameras.

## 14.2.5 RS485 Settings

If your NVR supports RS485 interface, you can set the RS485 parameters to control the third-party device. For example: controlling roll-up doors through RS485 protocol. The setting steps are as follows:

1. Click **Start** → **Settings** → **System** → **Basic Settings** → **RS485**.
2. Check “Enable” and click “Apply” to enable RS485 settings.


3. Click “Add” to add the corresponding operation.




4. Add the operation name, for example: “Open”. Then set the baud rate, address, protocol and control.

5. Click “OK” to save the settings.


6. Click “Test” to test whether the settings are valid.

After the operation is successfully set, you can go to the live view interface and click  to choose the desired operation.



### 14.3 Factory Default

Click *Start* → *Settings* → *System* → *Maintenance* → *Factory Default* to go to the following interface. Please choose the item as needed.



**Note:** Restoring default parameters will not change time zone and video format, except that, the password of the admin will be preserved.

## 14.4 Device Software Upgrade

### ● Upgrade

You can click **Start** → **Settings** → **System** → **Information** → **Basic** to view MCU, kernel version and firmware version and so on. Before upgrading, please get the upgrade file from your dealer.

The upgrade steps are as follows:

- ① Copy the upgrade software onto the USB storage device.
- ② Insert the USB storage device into the USB interface of the NVR.
- ③ Click **Start** → **Settings** → **System** → **Maintenance** → **Upgrade** to go to “Upgrade” interface. Select the USB device in “Device Name” option and go to the path where the upgrade software resides. Select the upgrade software and then click “Upgrade”. The system may automatically restart during upgrading. Please wait for the upgrade to finish and it’s critical to not power off the NVR during the upgrade process.

*Note: The file system of the USB mobile device which is used for upgrade, backup and restoration should be FAT32/NTFS format (only some models support NTFS format).*

## 14.5 Backup and Restore

You can back up the configuration file of the NVR and export the file to other storage devices; in this way, you can implement the configuration to other NVRs of the same model and save setup time.

Insert the USB storage device into a USB interface on the NVR and then click **Start** → **Settings** → **System** → **Maintenance** → **Backup and Restore** to go to the interface.

- **Backup**


Select the USB device in “Device Name” option; go to the path where you want to store the configuration backup file and then click “Backup”; finally, click “OK” in the popup window.

- **Recover**

Select the USB device in “Device Name” option; find the configuration backup file and then click “Recover”; finally, click “OK” in the popup window.


## 14.6 Restart Automatically

You can set the automatic restart time for the NVR to maximize performance. Click *Start* → *Settings* → *System* → *Maintenance* → *Auto Maintenance* to go to the interface as shown below. Enable auto maintenance, set the interval days and point of time and then click “Apply” to save the settings. The NVR will restart automatically at the pointed time every \*interval\* days.



The screenshot shows the 'Auto Maintenance' settings window. It has a title bar 'Auto Maintenance'. Below the title bar, there is a checked checkbox labeled 'Enable'. Underneath, there are two input fields: 'Interval Days' with the value '10' and a 'Days' label to its right, and 'Point Of Time' with the value '23 : 59' and a clock icon to its right. At the bottom right of the window is an 'Apply' button.

## 14.7 View Log

Click *Start* → *Settings* → *System* → *Maintenance* → *View Log* to go to the log view interface. Select the log main type, click  to set start time and end time and then click “Search”. The searched log files will be displayed in the list.

No.	Main Type	Log Time	Content	Details	Play
1	Alarm	11/03/2015 15:58:53	Motion Alarm		
2	Settings	11/03/2015 15:43:01	Local Basic		—
3	Operation	11/03/2015 15:34:53	Local Search/Playback/Backup		—
4	Alarm	11/03/2015 15:25:43	Motion Alarm		
5	Settings	11/03/2015 15:25:38	Local Camera Parameters		—
6	Operation	11/03/2015 15:20:15	Local Search/Playback/Backup		—
7	Settings	11/03/2015 15:05:38	Local Camera Parameters		—
8	Settings	11/03/2015 15:05:06	Local Record Parameters		—
9	Exception	11/03/2015 15:04:48	IPC Offline		—
10	Settings	11/03/2015 15:04:46	Local Camera Parameters		—
11	Operation	11/03/2015 15:03:49	Local Login / Logout		—
12	Operation	11/03/2015 15:03:12	Local Maintenance		—

Choose the log file in the list and then click “Export” button to export the log file. Click on the “Content” title bar to pop up a menu list. Using the check box, check contents on the menu list and then the log list will show only the checked log contents. Click to play the video log.

## 14.8 View System Information

Click *Start* → *Settings* → *System* → *Information* and then click the corresponding menu to view the “Basic”, “Camera Status”, “Alarm Status”, “Record Status”, “Network Status” and “Disk” information of the system.

## 14.9 Diagnostic Data

Admin (default administrator) can enable diagnostic mode. An authorized account and password can be generated, which can be used to visit the web client for the collection of diagnostic data.

Check “Enable”, set the validity period and click “Apply” to generate an authorized account.

Diagnostic Mode

Enable

Validity Period (Day)

Access Authorization: Username (DevOps) | Password (\*\*\*\*\*)

Deadline: 2024/05/06 20:19:49

Apply

Export diagnostic data

Required diagnostic data

Optional diagnostic data


Export


The required diagnostic data or optional diagnostic data can be exported within the validity period by using the authorized account.

**Note:** When the NVR is bound by the APP, the verification code is not needed to log in the P2P web by using the authorized account generated above.

# 15 Remote Surveillance

## 15.1 Mobile Client Surveillance


- ① Enable NAT in the NVR. Refer to [NAT Configuration](#) for details.
- ② Download and install the mobile client (“SuperLive Plus” or “SuperLive Max”) into the mobile device with the Android or iOS system.
- ③ Run the mobile client, click  to scan the QRCode of the NVR (Go to Start→Settings→Network→NAT to view the QRCode and verification code of the NVR).



Please refer to the mobile surveillance user manual for details.

## 15.2 Web LAN Access

- ① Click **Start→Settings→Network→TCP/IP** to go to the “TCP/IP” interface. Set the IP address, subnet mask, gateway, preferred DNS and alternate DNS of the NVR.
- ② Open a web browser on your computer, enter the IP address of the NVR in the address bar and then press enter to go to the login interface as shown below. You can change the display language on the top right corner of the login interface. Enter the username and password of the NVR in the interface and then click “Login” to go to the live view interface.



*Notes:*


1. Please make sure that the IP address of the NVR and the computer are both in the same local network segment. For example, supposing that the IP address of the computer is 192.168.1.41, the IP address of the NVR shall be set to 192.168.1.XXX.
2. If the HTTP port of the NVR is not 80, but another number, you need to enter the IP address plus port number in the address bar when accessing the NVR over a network. For example, the HTTP port is 81. You should enter `http://192.168.1.42:81` in the address bar.

## 15.3 Web WAN Access


### ➤ NAT Access

- ① Set the network of the NVR. Please refer to [TCP/IP Configuration](#) for details.
- ② Enable NAT and then set the NAT server address. Please refer to [NAT Configuration](#) for details.
- ③ Open a web browser on your computer, enter the NAT server visit address (such as [www.autonat.us](http://www.autonat.us)) in the address bar and then press enter to go to the interface as shown below (download and install the relative plug-in according to the tip if you access the NVR through NAT for the first time).

**Note:** Different regions may have different visit addresses. Please go to the NAT interface to view the detailed visit address (click **Start** → **Settings** → **Network** → **NAT**).



The image shows a login interface for an NVR. It consists of three vertically stacked input fields. The first field is labeled 'Enter device serial number' and has a QR code icon to its left. The second field is labeled 'Enter Username' and has a person icon to its left. The third field is labeled 'Enter Password' and has a padlock icon to its left. Below these three fields is a large grey button labeled 'Login'.

Enter the serial number (click  on the tool bar at the bottom of the live view interface to see the serial number of the NVR), user name (the user name of the NVR, **admin** by default) and password of the NVR, select the display language on the top right corner of the interface and then click “Login” to go to the web client interface.

**Note:** If your device is bound to the APP, the verification code getting from the APP is needed.

#### ➤ PPPoE Access

- ① Click **Start**→**Settings**→**Network**→**PPPoE** to go to the “PPPoE” interface. Check “Enable” in the “PPPoE settings” and then enter the username and password you get from your ISP. Click “Apply” to save the settings.
- ② Click **Start**→**Settings**→**Network**→**Network Status** to view the IP address of the NVR.
- ③ Open a web browser on your computer, enter the IP address of the NVR like <http://210.21.229.138> in the address bar and then press enter to go to the login interface. Enter the username and password of the NVR in the interface and then click “Login” to go to the live view interface.

#### ➤ Router Access

- ① Click **Start**→**Settings**→**Network**→**TCP/IP** to go to the “TCP/IP” interface. Set the IP address, subnet mask, gateway, preferred DNS and alternate DNS of the NVR.
- ② Set the HTTP port (it is suggested to modify the HTTP port because the default HTTP port 80 might be taken up) and enable UPnP function in both the NVR and the router. If the UPnP function is not available in the router, you need to forward the LAN IP address, HTTP port and server port of the NVR to the router. Port mapping settings may be different in different routers, so please refer to the user manual of the router for details.
- ③ Get the WAN IP address of the NVR from the router. Open a web browser on your computer, enter the WAN IP address plus HTTP port like <http://116.30.18.215:100> in the address bar and then press enter to go to the login interface. Enter the username and password of the NVR in the interface and then click “Login” to go to the live view interface.

*Note: If the WAN IP address is a dynamic IP address, it is necessary for you to use the domain name to access the NVR. Click Start → Settings → Network → DDNS to set DDNS (see [DDNS Configuration](#) for details). By using DDNS function you can use the domain name plus HTTP port like <http://sunshine.NVRdydns.com:100> to access the NVR via the Internet.*

## 15.4 Web Remote Control

The NVR supports web client access with or without plug-in. The plug-in for HTML5 browsers offers much improved features and performance.

The supported browsers (green color) for remote access with the plug-in are as follows. The red color versions are not supported.

IE	Edge *	Firefox	Chrome	Safari	Opera	Safari on iOS *	Android Browser *	Opera Mobile *	Chrome for Android *	Firefox for Android	Samsung Internet
		2-6									
6-9		7-10		3.1-4	10-11.5	3.2-4.1	2.1-4.3	12			
10	12-98	11-97	4-98	5-15.3	12.1-82	4.2-15.3	4.4-4.4.4	12.1			4-15.0
11	99	98	99	15.4	83	15.4	99	64	99	96	16.0
		99-100	100-102	TP							

When you access the NVR through the above web browser for the first time, the browsers need to download and install the relative components for normal preview and playback.

If your browser asks for permission on the configuration modifications after the plug-in runs, please allow it, or the interface will not display normally; if the relevant ports of the plug-in (port 11563; port 12863; port 13863) are occupied, the system will tell you which program currently occupies the port. Please stop the occupying program.

The supported browsers (green color) for remote access without the plug-in are as follows. The red color versions are not supported.

IE	Edge *	Firefox	Chrome	Safari	Opera	IOS Safari *	Opera Mini *	Android Browser *	Opera Mobile *	Chrome for Android *	Firefox for Android	UC Browser for Android	Samsung Internet	QQ Browser	Baidu Browser	KaiOS Browser
		2-46														
	12-14	47-51	4-50		10-37											
	15	52	51-56	3.1-10.1	38-43	3.2-10.3							4-6.4			
6-10	16-84	53-79	57-84	11-13.1	44-69	11-13.7		2.1-4.4.4	12-12.1				7.2-11.2			
11	85	80	85	14	70	14.0	all	81	59	85	79	12.12	12.0	10.4	7.12	2.5
		81-82	86-88	TP												

Please refer to the tips in the remote interfaces for details. The buttons and icons on the top right corner of the remote interface are introduced as follows.

**admin:** the current login username.

**Logout:** click to log out and return to the login interface.

**Modify Password:** click to change the password of the currently active user. Enter the current password and then set a new password in the popup window. Click “OK” to save the new password.

**Local Settings:** click to change the local settings. Set the snapshot number and click “Browse” to set the snapshot path and record path as shown below. Click “Apply” to save the settings.


Snapshots number	5	▼
Save snapshots to	C:\Users\Administrator\Pictures	Browse
Save record files to	C:\Users\Administrator\Videos	Browse
Apply		

Below as an introduction is a web browser with the applicable plug-in installed.


### 15.4.1 Remote Preview

Click “Live Display” in the remote interface to go to the preview interface.



The preview interface consists of the four areas marked in the following picture.






#### ➤ Start Preview

Select a window in the preview area and then click one online camera on the left panel to preview the camera in the window. You can click  in the toolbar to preview all the cameras.


#### ➤ Left Panel Introduction

Click  on the left panel to hide the panel and click  to show the panel. You can view all the added cameras and groups on the left panel.


- **View Camera**

Click  to view the cameras. You can view the number of all the added cameras and the online cameras. For instance, the left number 3 in **Camera (3/4)** on the left panel stands for the number of online cameras; the right number 4 stands for the number of all the added cameras. Enter the camera name in the search box and then click  to search for the camera. Click  to refresh the camera list.















- **View Group**

Click  to view the groups. The top side of the left panel displays all groups, and the bottom displays all the cameras in the group.



- **View Scheme**


Click  to view the scheme. All schemes can be shown in the left panel. Double click the scheme name to invoke it quickly.

- **Tool Bar Introduction**

Button	Meaning
	Screen mode button.
	Click to enable/disable OSD.
	PicSearch (only some models support)
	Click to show full screen. Right click on the full screen to exit full screen.
	Click “All Main Stream” or “All Sub Stream” to set the stream of all the cameras.
	RS485 button, click to control the third-party device (only some models support)
	Manual alarm button. Click to open a window and then trigger and clear the alarm-out in the window manually.
	Click to preview all cameras.
	Click to close all the preview cameras.
	Click to start recording for all cameras to computer. Click  to stop recording.
	Click to start recording for all cameras to the NVR. Click  to stop recording.
	Click to enable talk through the NVR.


- **Right Panel Introduction**

Click  on the right panel to show the panel and click  to hide the panel.



































**Operation** panel introduction:

Button	Meaning
	Click to take snapshots
	Click to start recording to computer
	Click to start recording to the NVR.
	Click to zoom in the image of the camera and then drag the mouse on the camera image to view the hidden area.
	Click to zoom out the image of the camera.
	Click to start two-way talk.
	The 3D zoom in function is designed for P.T.Z. Click the button and then drag the image to zoom in or zoom out the image; click the image on different areas to view the image of the dome omni-directionally.
	Click to close the preview camera.
	Click to display original size

	Click to enable audio and then drag the slider bar to adjust the volume. You can listen to the camera audio by enabling audio.
---	--

Click one camera window in the preview area and then click Main Stream to set the camera's live preview stream and record stream to main stream in manual record mode; click Sub-stream to set the camera's live preview stream and record stream to sub stream. In sub stream tab, set the resolution, FPS and bitrate and then click "Apply" to save the settings.

**PTZ** panel introduction:

Button	Meaning
	Click  /  /  /  /  /  /  /  to rotate the dome; click  to stop rotating the dome.
	Drag the slider to adjust the rotating speed of dome.
	Click  /  to zoom in/out camera image.
	Click  /  to increase/ decrease the focal length.
	Click  /  to increase/decrease the iris of the dome.
Preset	Click to view the preset list and then click the button in the list to call the preset. Click  to add a preset; click  to save the preset setting; click  to delete the selected preset
Cruise	Click to view the cruise list. Click  to add a cruise; click  to play the cruise; click  to stop cruise.
Cruise Group	Click to view the cruise group list. Click  to add a cruise group; click  to play the cruise group; click  to stop cruise group.
Trace	Click to view the trace list. Click  to add a trace; click  to play the trace click  to start record.

If the camera you added is motorized lens camera, click the lens control icon to adjust the lens. If the camera you added is a fisheye camera, click the fisheye icon to set the relevant parameters as needed.



Click "Settings" to set video overlay display.


**Settings** ✕

---

Video Overlay Display

Target Box

Rule Line and Area 




OK Cancel

Check “Target Box” or “Rule Line and Area” as needed. Then you can view the target box or rule line/area in the video as shown below.



## 15.4.2 Remote Playback

Click “Playback” in the remote interface to go to the playback interface.






① Check the record event types and cameras on the left panel. Click  to select “Normal Playback” or “Event Playback”. Set the record date on the calendar beside the time scale.

② Click  to search the record data and then click  or directly click the time scale to play the record.

The operation of the playback time scale is similar to that of the time scale in the main program of the NVR. Please refer to [Playback Interface Introduction](#) for details.

### Introduction of playback control buttons:



Button	Meaning
	Stop button.
	Rewind button. Click to play video backwards.
	Play button. Click to play video forwards.
	Pause button.
	Deceleration button. Click to decrease the playing speed.
	Acceleration button. Click to increase the playing speed.
	Previous frame button. It works only when the forward playing is paused in single screen mode.
	Next frame button. It works only when the forward playing is paused in single screen mode.
	Select the time (for example: 30s); click it to step backward 30s
	Select the time (for example: 30s); click it to step forward 30s.
	PicSearch, refer to <a href="#">PicSearch</a> for details

Button	Meaning
	Backup start time button. Click the time scale and then click to set the backup start time.
	Backup end time button. Click the time scale and then click to set the backup end time.
	Backup button.
	Play strategy
	More operations (water mark/POS/Smart Information/backup status)



### 15.4.3 Remote Search and Backup





Click “Search and Backup” in the remote interface to go to the backup interface. You can back up the record by event or by time.

#### ➤ By Event

Click  to set the start time and end time on the left side of the interface; check the cameras; click  to select the desired events and then click “Search” to search the record (the searched record data will be displayed in the list); check the record data in the list and then click “Backup” to back up the record.

#### ➤ By Time

Click  to set the start time and end time on the left side of the interface; check the cameras and then click  on the right side to back up the record.

**Image Management:** Click “Image Management” to go to image management interface. The system will display all captured images automatically in the list. Click  to delete the image. Click  to open the “Export” window. Click  to open the “View Image” window. Click  to export the image.

**View Backup Status:** Click “Backup Status” to view the backup status. Click “Pause” to pause; click “Resume” to continue the backup; click “Delete” to delete the task.

### 15.4.4 Intelligent Analysis

Click “Intelligent Analysis” in the remote interface to configure smart search, statistics and sample database. All of these settings are similar to that of the NVR. See the configurations of the NVR for details.


### 15.4.5 Application

The application of this system includes parking lot management, access control management, face attendance, face check-in and so on. Note that face attendance and face check-in functions are only available for some modes. All of these settings are similar to that of the NVR. See the configurations of the NVR for details.














## 15.4.6 Remote Configuration


Click “Function Panel” in the remote interface and then configure the camera, record, alarm, disk, network, account and authority and system of the NVR remotely. All of these settings are similar to that of the NVR. See the configurations of the NVR for details.

### ➤ Jumping to IPC Web Client

Except for IPCs that access with RTSP protocol, the IPC can be directly jumped from the NVR web client to the IPC web client by clicking  in the above-mentioned interface.

1. Please login the Web Client of NVR (See [Web LAN Access](#) or [Web WAN Access](#) for details).
2. Click **Function Panel** → **Camera** → **Edit Camera** to go to the following interface.

No.	Camera Name	Address	Port	Status	Protocol	Model	Preview	Edit	Delete	Settings	Upgrac	Version
1	IPC	10.20.21.37	9008	Offline	IP Camera	IPC						
2	IP Camera01	10.10.10.153	9008	Online								7208)
3	IPC	10.20.52.201	9008	Online	IP Camera							8020)

3. Select the camera and click  to log into the web client of the camera. From there, you can set the parameters of the camera as needed.

## Appendix A FAQ

### Q1. Why can't I find the HDD?

- a. Please check the power and SATA data cables of the HDD to make sure they are properly connected.
- b. For some NVRs with the 1U or small 1U case, the power of the adapter may be not enough for operating your HDD. Please use the power adaptor supplied along with your specific NVR.
- c. Please make sure the HDDs are compatible with the NVR. See [Appendix C Compatible Device List](#) for details.
- d. The HDD could have gone bad.

### Q2. Why are there no images in some or all the camera windows?

- a. Please make sure the resolutions of the cameras are supported by the NVR.
- b. Please make sure the network cables of the IP camera and NVR are both connected properly and the network parameters are set correctly.
- c. Please make sure the network and the switch both work normally.

### Q3. Why does my screen have no output after booting the NVR normally?


- a. Please make sure the screen, HDMI or VGA cables are functioning and properly connected.
- b. Please make sure the screen supports the resolution of 1280\*1024, 1920\*1080 or 3840\*2160 (4K\*2K). The NVR cannot self-adapt to a screen of which the resolution is lower than 1280\*1024, In that event, the screen will remind you that the resolution is not supported by the NVR or just not display anything. Please change the screen to 1280\*1024, 1920\*1080 or 3840\*2160 resolution before booting the NVR.

### Q4. What do I do if I have forgotten my password?

- a. The password for *admin* can be reset through the security email or “Edit Security Question” function. Click “Retrieve Password” in the login window and enter the email address or enter the corresponding answer to the selected question in the popup window. After you receive the email or correctly answer all questions, you can reset the password for *admin*. If you forget the answers to these questions, or don't set the security email, there is no other way to restore the *admin* password, and you'll have to contact your dealer for assistance.
- b. The passwords of other users can be reset by *admin*, please refer to [Edit User](#) for details.

### Q5. Why will my NVR not accept the maximum number of IP cameras?

Take a 16 CH NVR as an example. Some 16 CH NVRs support a maximum of 120Mbps bandwidth input (please take the real device as a standard). Refer to the picture below. The remaining bandwidth should be larger than the bandwidth of the IP camera you want to add, or you would fail to add an IP camera. You should lower the added cameras' bitrate to relieve the bandwidth. It is recommended to add cameras by “Quickly Add” for batch adding.



**Q6. Why is an IP camera connected directly to the PoE port of my NVR not displayed automatically in the camera list?**

- a. Please check whether a PoE port is occupied by another IP camera that may have been added through the network (including a PoE switch).
  - Take a 16 CH NVR with 8 PoE ports as an example. The resource distribution of the 16 CH IP cameras is shown in the picture below.

CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8	CH9	CH10	CH11	CH12	CH13	CH14	CH15	CH16
								POE-1	POE-2	POE-3	POE-4	POE-5	POE-6	POE-7	POE-8

When you add IP cameras through network, the IP cameras will occupy the resource from CH1, CH2, CH3, CH4...in the sequence they are added; if you directly connect IP cameras to the PoE ports of the NVR, the IP cameras will occupy ports from CH9 to CH16 according to the number of the PoE port each IP camera is connecting to.

Let's say 12 IP cameras have been added to the NVR through the network and no IP cameras have been directly connected to a PoE port. The 12 CH IP cameras occupy the 8 network resources from CH1 to CH8 and 4 PoE resources from CH9 to CH12 which otherwise would have been occupied by connecting the IP cameras directly. In this situation, if you directly connect one IP camera to PoE5, PoE6, PoE7 or PoE8, the IP camera will be displayed in the camera list automatically; if you connect it to PoE1, PoE2, PoE3 or PoE4, it won't be displayed in the camera list and will show a resource conflict; if you need to connect it to PoE1, PoE2, PoE3 or PoE4, you should first delete the IP camera which occupies the PoE port resource and then reconnect your camera to the PoE port.

- Take a 8 CH NVR with 8 PoE ports as another example. The resource distribution of the 8 CH IP cameras is shown in the picture below and the addition rules of the IP cameras are similar to the rules mentioned above. Please refer to the above for details.

CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
POE-1	POE-2	POE-3	POE-4	POE-5	POE-6	POE-7	POE-8

b. Please make sure that the internal Ethernet port and an IP camera which directly connects to a PoE port through the ONVIF protocol are in the same network segment, or you will fail to add the camera.


Log into the IP camera's Web client and then enable DHCP (to obtain an IP address automatically); or manually change the IP address of the IP camera to put it in the same network segment as the internal Ethernet port.


c. Check whether the number of the added IP camera exceeds the maximum allowed.

If the number of IP cameras exceeds the maximum allowed, the system will alert you that the IP camera count exceeds the limit.


### Q7. Why do I have no image output on an IP camera directly connected to the PoE port of my NVR using the ONVIF protocol, even though it's shown on the camera list?

Please make sure the username and password of the IP camera are correct. The IP camera's username and password can be modified through the two ways mentioned below.

① Click "Edit Camera" in the Camera module of the setup panel to go to the interface. Click  to modify the username and password of the IP camera (enter the correct username and password of the IP camera in the popup window and then click "OK").



No.	Camera Name	Address	Sub-device ID	Remote Channel	Port	Status	Protocol	Model	Preview	Edit
1	IPC1	10.15.1.2	--	1	9008	Online	IP Camera	-A		
2	IPC	10.15.1.106	--	1	9008	Online				
3	IPOE-1]IP Camera01	10.15.1.106	1	1	--	Online		D		

② Go to the live view interface and then click  in the preview window of the IP camera to edit the IP camera's username and password.

### Q8. Why is my system not recording?

a. Make sure the HDD was formatted prior to use.

b. The recording schedule has not been set in customization mode. Please refer to [Schedule Settings](#) for details.

c. It's possible your HDD is full and the NVR cannot record. Check HDD information from Disk Management and if required, please enable the recycle function (please see [Advanced Configuration](#) for details).


d. There is no disk in the disk group, so please add at least one disk to the group. Refer to [Storage Mode Configuration](#) for details.


e. The HDD could have gone bad. Please change another one.

### Q9. Fail to access the NVR remotely through IE.

- a. Note that Internet Explorer is no longer supported by Microsoft and it's recommended to use another browser such as Chrome, Edge, Firefox, etc.
- b. Please make sure the IE version is IE8 or above.
- c. Please check whether the PC has enabled the firewall or installed the antivirus software. Please try to access the NVR again after you disable the firewall and stop the antivirus software.
- d. Allow & block list may have been set in Account and Authority setting. The PC of which the IP address is in the block list or out of the allow list cannot access the NVR remotely.

#### Q10. ActiveX control cannot be downloaded. What can I do?

- a. IE browser blocks ActiveX control. Please do setup as per the steps mentioned below.
  - ① Open IE browser. Click  → Internet Options.



- ② Select **Security** → **Custom Level**. Refer to Fig 10-1.
  - ③ Enable all the sub options under “ActiveX controls and plug-ins”. Refer to Fig 10-2.
  - ④ Then click “OK” to finish setup.
- b. Other plug-ins or anti-virus may block ActiveX. Please disable or do the required settings.




Fig 10-1





Fig 10-2

### Q11. How do I play backup files?

- a. Recorded video backed up by NVR: insert the USB device with the recorded video backup files into the USB interface of a PC and open the USB device path. The recorded video can be backed up in the private format and AVI format by NVR.
  - If you select the private format when backing up recorded video by NVR, a RPAS compression package will be backed up to the USB device automatically along with the recorded video data. Uncompress the “RPAS.zip” and then click “RPAS.exe” to set up RPAS. After the setup is completed, open RPAS player and then click “Open Folder” in the middle of the interface to select the record data. Refer to Fig 11-1.

Select a camera in the resource tree on the left side of the interface to play the camera record. Click  on the tool bar under the camera image to enable audio. Refer to Fig 11-2.

*Note: The record will not have audio output if you disable the audio when recording by NVR. Please see [Mode Configuration](#) and [Encode Parameters Settings](#) for details.*

- If you select the AVI format when backing up recorded video by NVR, the recorded video backup data can be played by a video player that supports this format.
- b. Recorded video backed up through web. The recorded video can only be backed up using AVI format. The recorded video can be backed up to PC and played by the video player which supports this format.




Fig 11-1




Fig 11-2

**Q12. HTTPS service cannot work normally after directly installing the signed certificate.**

- a. When importing the certificate, the private key is not attached to the certificate.
- b. When importing the certificate, the private key is attached to the certificate, but it is encrypted. At present, the NVR doesn't support the certificate with the encrypted private key.

**Q13. You are prompted with the unsafe statements/tips when using HTTPs service.**

- a. Please make sure your certificate is trusted.
- b. Make sure whether the Common Name (domain information) of the certificate matches with the domain name of the visiting website.
- c. Whether the certificate is within the period of validity.

## Appendix B Calculate Recording Capacity

The recording capacity is mainly up to the record resolution, record stream and bitrate. Different image quality parameters decide different disk capacity occupation under equal circumstances. The higher the recording resolution, recording stream and recording bitrate is, the more disk capacity is taken up under equal circumstances. The calculation format of the recording capacity is shown below.

$$\text{Recording Capacity (MB)} = \text{Bitrate (Kbps)} \div 1024 \div 8 \times 3600 \times \text{Recording hours per day} \times \text{Record Storage Days} \times \text{channel numbers}$$

3600 means record for an hour(1TB=1024GB, 1GB=1024MB, 1MB=1024KB, 1Byte=8bit).

Record Bitrate (Kbps)	Used Space (MB/H)	Used Space (MB/D)
10240	4500	108000
8192	3600	86400
6144	2700	64800
4096	1800	43200
3072	1350	32400
2048	900	21600
1024	450	10800
768	337.5	8100
512	225	5400
384	168.75	4050
256	112.5	2700

The table below shows the recording capacity requirements for record storage in 30 days.

Record Bitrate (Kbps)	Recording Capacity(TB)					
	1CH	4CH	8CH	16CH	32CH	64CH
10240	3.09	12.36	24.72	49.44	98.88	197.76
8192	2.48	9.89	19.78	39.56	79.11	158.21
6144	1.86	7.42	14.84	29.67	59.33	118.66
4096	1.24	4.95	9.89	19.78	39.56	79.11
3072	0.93	3.71	7.42	14.84	29.67	59.33
2048	0.62	2.48	4.95	9.89	19.78	39.56
1024	0.31	1.24	2.48	4.95	9.89	19.78
768	0.24	0.93	1.86	3.71	7.42	14.84
512	0.16	0.62	1.24	2.48	4.95	9.89
384	0.12	0.47	0.93	1.86	3.71	7.42
256	0.08	0.31	0.62	1.24	2.48	4.95

For instance, there is a 32CH NVR recording 24 hours per day and the recordings are stored for 30 days and the NVR adopts dual stream recording. If the main stream is 4096Kbps and the sub stream is 1024Kbps, then the total recording capacity is 49.45TB (39.56TB + 9.89TB).

Considering the format loss of the disk is about 10%, the required disk capacity will be 55TB (49.45TB ÷ (1-10%)).

## Appendix C Compatible Device List

### Compatible HDD list

Brand and Series		Capacity
Seagate	Barracuda Series	500GB /1TB /2TB /3TB
	SV35 Series (recommended)	1TB /2TB /3TB
	Surveillance HDD Series (recommended)	1TB /2TB /3TB /4TB /6TB/8TB/10TB
Western Digital	Blue Series	500GB /1TB
	Green Series	2TB /3TB /4TB
	Purple Series (recommended)	1TB /2TB /3TB /4TB /6TB/8TB/10TB

### Compatible USB mobile device

Brand	Capacity
SSK	2GB
Netac	4GB
Kingston	2GB/8GB/16GB/32GB
Aigo	2GB
Smatter vider	1GB
SanDisk	4GB/8GB/16GB/32GB

## Appendix D Communication Port List

Protocol/Service	Source Device	Source Port	Destination Device	Destination Port (Listening)	Connection Type	Enabled by Default (Yes/No)	Destination Port Configurable (Yes/No)	Description
HTTP	web/Onvif Client	-	IPC	80	TCP	Yes	Yes	Port 80 is used to provide HTTP WebServer and ONVIF services.
HTTPS	web Client	-	NVR	443	TCP	否	Yes	Port 443 is used to provide HTTPS WebServer and ONVIF services.
Data Communication Protocol	Private Protocol Client (SDK/NVMS/O CX Plug-in)	-	NVR	6036	TCP	Yes	Yes	Port 6036 can be used to transmit audio-video stream and the private protocol client can manage and control NVRs through this port.
POS Service	POS device	-	NVR	9036	TCP/UDP	No	Yes	As a POS Server, the NVR receives data through port 9036 of TCP or UDP.
IPC auto report	IPC (our company)	-	NVR	2009	TCP	Yes	Yes	Port 2009 is used to receive the auto report information of our company's IP cameras. The NVR can add IP cameras automatically reported from different network segments.
RTSP	RTSP Client	-	NVR	554	TCP	No	Yes	Port 554 is used to provide real-time RTSP streaming media transmission service.
ONVIF	Other ONVIF Devices	-	NVR	6699	TCP	No	No	Port 6699 is used to receive the event push of other ONVIF devices.
	NVR	N+1 Radom Ports (N: the quantities of the network card of the device; Port range:1024-65535), 3702	Other ONVIF Devices	-	UDP	No	No	It is used to find ONVIF devices. The NVR responds to the multicast search command and the unicast replies to the command of the multicast. Port 3702 is used to listen to the command of the ONVIF device discovery. N random ports ("N" is the quantities of the non-POE network cards) are used to reply to the search party by the unicast.
	Other ONVIF Devices	-	NVR	Random Port (1024-65535)	UDP	No	No	It is used to search ONVIF devices
UPnP	Web Client	-	NVR	Random Port (49152-65535)	TCP	No	No	Port 49152 is used to provide UPnP web service. If port 49152 is occupied, the port number will increment automatically until an available port is found.
	Other UPnP Devices	-	239.255.255.250	1900	UDP	No	No	Port 1900 is used to receive the multicast reports sent by other UPnP devices, so that these UPnP devices can be found from the network; The random port is used to send multicast to port 1900, so that the IPC can be found by other UPnP devices on the network (1900 is a default port of SSDP protocol).
	NVR	Random Port (1024-65535)	239.255.255.250	1900	UDP	No	No	
NAT	NVR	2 Random Ports (1024-65535)	NAT Server	-	UDP	No	No	These two random ports are used to communicate with NAT server, realizing P2P penetration function.
SNMP	Network Management System	-	NVR	161	UDP	No	Yes	Port 161 is used to provide SNMP service.
SNMP	NVR	162	Network Management System	-	UDP	No	Yes	As an SNMP client, the device uses port 162 send trap information to the network management system. (When enabling SNMP function, port 162 will not be enabled by default. Only when sending the trap information, can it be on temporarily. After the information is sent successfully, the port will be turned off.
Multicast Search Protocols	IPC	-	234.55.55.56:23456 (NVR)	23456	UDP	Yes	No	Port 23456 is used to receive the multicast sent by other devices to find IP cameras. In addition, it also used to send the multicast to 234.55.55.56:23456, which can be searched by IPTOOL/NVMS
	NVR	23456	234.55.55.56:23456 (IPTOOL/NVMS)	23456	UDP	Yes	No	
Hikvision's Device Discovery	Devices (Hikvision)	-	NVR	37020	UDP	No	No	Port 37020 is used to search and discover Hikvison's devices. It is opened when searching devices and closed after searching.
Dahua's Device Discovery	Devices (Dahua)	-	NVR	37810	UDP	No	No	Port 37810 is used to search and discover Dahua's devices. It is opened when searching devices and closed after searching.